



UP1100
User Manual

Part Number: 51-0048-1A



© 2000 Alpha Processor, Inc. All rights reserved.

Part #: 51-0048-1A

Date: 5/31/00

Alpha Processor, Inc.
A Samsung Company
130C Baker Avenue Extension
Concord, MA 01742
Tel: 978.318.1100
Fax: 978.371.3177

Alpha Processor, Inc. reserves the right to make changes in its products without notice in order to improve design or performance characteristics.

This document is considered to be preliminary with further revisions and corrections in process. Alpha Processor, Inc. makes no representations or warranties with respect to the accuracy or completeness of the contents of this publication or the information contained herein, and reserve the right to make changes at any time, without notice. Alpha Processor, Inc. disclaims responsibility for any consequences resulting from the use of the information included in this publication.

This publication neither states nor implies any representations or warranties of any kind, including but not limited to, any implied warranty of merchantability or fitness for a particular purpose. Alpha Processor, Inc. products are not authorized for use as critical components in life support devices or systems without Alpha Processor, Inc.'s written approval. Alpha Processor, Inc. assumes no liability whatsoever for claims associated with the sale or use (including the use of engineering samples) of Alpha Processor, Inc. products except as provided in Alpha Processor, Inc.'s Terms and Conditions of Sale for such products.

Trademarks

AMD-751 System Controller is a trademark of AMD.

Other product names used in this publication are for identification purposes only and may be trademarks of their respective companies.

Preliminary Product Information

The information in this publication is preliminary, and is believed to be accurate at the time of publication. Alpha Processor, Inc. makes no representations or warranties with respect to the accuracy or completeness of the contents of this publication or the information contained herein, and reserves the right to make changes at any time, without notice.

Revision History

Date	Rev	Description
05/31/00	51-0048-1A	UP1100 User Manual first product release. This document supports the UP1100-600-A product.

Table of Contents

	Revision History	iii
	Table of Contents	iv
	List of Figures	vii
	List of Tables	viii
	Preface	x
Chapter 1	UP1100 Introduction	1-1
	1.1 Features.	1-1
	1.2 System Components	1-2
Chapter 2	System Configuration	2-1
	2.1 Board Layout and Components	2-1
	2.2 Memory Subsystem	2-3
	2.2.1 Memory Configuration	2-3
	2.2.2 Memory Guidelines	2-4
	2.3 Configuration Settings.	2-5
	2.3.1 Firmware Image Selection	2-5
	2.3.2 Cache Size Selection	2-6
Chapter 3	Electrical, Environmental and Physical Data	3-1
	3.1 Power Specifications	3-1
	3.1.1 Power Consumption	3-1
	3.1.2 Power Supply	3-1
	3.1.3 Power Connectors	3-2
	3.2 Environmental Specifications	3-2
	3.2.1 Safety	3-3
	3.2.2 EMI	3-3
	3.2.3 Thermal	3-3
	3.3 Enclosure Requirements	3-5
	3.4 Physical Parameters	3-5
	3.4.1 UP1100 Parameters.	3-5
	3.4.2 UP1100 Mounting Hole Specification	3-5
	3.5 Rear Panel I/O Shield	3-6
Chapter 4	Software Support	4-1
	4.1 Software Overview	4-1

4.1.1	FSB	4-1
4.1.2	Reset PALcode	4-1
4.1.3	Alpha SRM Console	4-1
4.1.4	Operating System	4-2
4.2	Alpha SRM Console	4-2
4.2.1	Invoking the SRM Console	4-2
4.2.2	Command Summary	4-3
4.2.3	Displaying the System Configurations	4-7
4.2.4	Setting the System Date	4-11
4.2.5	Booting the Operating System	4-12
4.2.6	Updating Firmware	4-13
4.2.7	Using Environment Variables	4-15
4.2.8	Environment Variable Summary	4-16
4.2.9	Finding Help	4-25
4.3	FSB	4-26
4.4	Installing the Linux Operating System	4-26
4.4.1	Requirements.	4-27
4.4.2	Before Installing Linux	4-27
4.4.3	Setting Environmental Variables	4-28
4.4.4	Starting the Linux OS Installation.	4-29
4.4.5	After Installing Linux	4-30
Chapter 5	Troubleshooting	5-1
5.1	Hardware Startup	5-1
5.1.1	No Video Present	5-1
5.1.2	LED Status Indicators	5-1
5.1.3	Beep Code.	5-2
5.2	Error Recovery Procedures	5-3
5.2.1	Error Conditions	5-3
5.2.2	Error Recovery Switch Settings	5-3
5.2.3	Error Recovery Procedure	5-4
Appendix A	Connectors and Pinouts	A-1
A.1	Power Connector Pinouts	A-2
A.2	Nonstandard Connections	A-2
A.3	Standard Connectors	A-6
Appendix B	Support, Products and Documentation	B-1
B.1	Customer Support	B-2
B.2	Supporting Products	B-2
B.3	Alpha Products	B-2
B.4	Documentation	B-3

Index

Index-1

Publication Evaluation Form

Form-1

List of Figures

Figure:	1-1	UP1100 Functional Block Diagram	1-3
	2-1	UP1100 Layout	2-2
	3-1	Thermally-sensitive Components	3-4
	3-2	UP1100 Mounting Hole Specification	3-6
	3-3	Rear Panel Connectors	3-7
	5-1	LED Status Indicators	5-2
	5-2	Firmware Configuration Switches	5-3

List of Tables

Table: 1-1	UP1100 Product Features	1-1
2-1	UP1100 Connector Component List	2-2
2-2	Typical UP1100 Memory Configurations.	2-5
2-3	Firmware Configuration Settings (SW1, Switches 1 and 2)	2-6
2-4	Cache Size Configuration Settings (SW1, Switches 7 and 8)	2-6
3-1	UP1100 Typical Power Consumption	3-1
3-2	Recommended Power Supply	3-2
3-3	Environmental Requirements	3-3
3-4	Maximum Component Case Temperatures	3-5
3-5	UP1100 Physical Parameters	3-5
3-6	Rear Panel Connectors	3-7
4-1	Summary of SRM Console Commands	4-3
4-2	Syntax for SRM Console Commands	4-5
4-3	Special Characters for SRM Console	4-6
4-4	Device Naming Convention	4-10
4-5	PCI Address Assignments	4-10
4-6	Boot Command Options	4-13
4-7	Set Envar Options	4-15
4-8	Environment Variable Summary	4-16
4-9	Auto_Action Values	4-18
4-10	Boot_Osflags Options	4-19
4-11	ew*0_mode Options.	4-20
4-12	ew*0_protocols Options	4-21
4-13	Language Options	4-22
4-14	pk*0_soft_term Options	4-24
4-15	SRM Console Variables.	4-28
5-1	LED Status Indicators	5-2
5-2	Switch Settings for Various Error Conditions	5-4
A-1	ATX Power Connector Pinouts (J18)	A-2
A-2	Power LED Connector Pinouts (J19)	A-2
A-3	VID Port Pinouts (J21)	A-3
A-4	SM Bus Extender Port Connector Pinouts (J22)	A-3
A-5	Power Button Connector Pinouts (J23)	A-3

A-6	Speaker Cable Connector Pinouts (J25)	A-3
A-7	HDD Activity LED Connector Pinouts (J26)	A-4
A-8	Reset Button Connector Pinouts (J27)	A-4
A-9	Keyboard Lock Cable Connector Pinouts (J28)	A-4
A-10	System Fan Connector Pinouts (J29)	A-4
A-11	CPU Fan Connectors Pinouts (J30, J33)	A-5
A-12	Debug Port Connector Pinouts (J31)	A-5
A-13	EPLD Program Port Pinouts (J32)	A-5
A-14	UP1100 Standard Connectors	A-6

Preface

Overview

This manual describes the Alpha Processor, Inc. UP1100 product, including the Alpha 21264A Processor. The manual emphasizes the System Reference Manual (SRM) Console firmware user interface.

Topics include a description of how to:

- Install an operating system
- Check or change system configurations
- Troubleshoot basic system problems

Audience

This manual is intended for technicians and engineers who support resellers, dealers, system integrators, and OEM vendors who supply UP1100-based systems.

Scope

This manual describes the features, configuration options, functional operation, troubleshooting analysis and user interface of the system and its SRM Console firmware. It is a companion piece to Alpha Processor, Inc.'s UP1100 document set that includes the *UP1100 Quick Start Installation Guide* (51-0047) and the *UP1100 Technical Reference Manual* (51-0049).

Manual Organization

The *UP1100 User Manual* is organized as follows:

- Chapter 1, "UP1100 Introduction," presents the product features and includes a functional block diagram of the system.
- Chapter 2, "System Configuration," provides a pictorial layout of the UP1100 with its key components. Configuration elements include main memory guidelines and configuration jumper settings.
- Chapter 3, "Electrical, Environmental and Physical Data," furnishes electrical and environmental requirements, thermal characteristics, and physical board dimensions.

- Chapter 4, “Software Support,” describes the three major software components that form the UP1100 user interface. Topics include the Alpha System Reference Manual (SRM) Console and Fail Safe Booter (FSB) firmware, and procedures describing installation and upgrade of the operating system.
- Chapter 5, “Troubleshooting,” discusses solutions for hardware and software problems encountered during system startup.
- Appendix A, “Connectors and Pinouts,” describes the connectors and pinouts used on the UP1100.
- Appendix B, “Support, Products and Documentation,” provides directions for obtaining additional product information and technical support.

Conventions and Definitions

This section defines product-specific terminology, abbreviations, and other conventions used throughout this manual.

Typographic Conventions

This manual uses the following type conventions:

- Variable information and document titles appear in *italic* type.
- Text that you type is shown in **Courier font**.
- Type that appears on a screen, such as an example of computer output, is shown in **Courier font**.
- Two key names joined with a forward slash are simultaneous keystrokes. Press down the first key while you type the second key, as in press Ctrl/S.

Acronyms

The following is a list of the acronyms used in this document and their definitions.

Abbreviation	Meaning
AGP	Accelerated Graphics Port
ALI	Acer Laboratories, Inc.
AMD	Advanced Micro Devices, Inc.
CD	Compact Disk
CE	European Conforming
CPU	Central Processing Unit
cUL	Canadian Underwriters Laboratory
DDR	Double Data Rate
DIMM	Dual Inline Memory Module
DRAM	Dynamic Random Access Memory
ECC	Error Correction Code
ECP	Enhanced Capabilities Port
EMI	Electromagnetic Interference
EN	European Norm
EPLD	Electrically Programmable Logic Device
EPP	Enhanced Parallel Port
FAQ	Frequently Asked Questions
FCC	Federal Communications Commission
FDD	Floppy Disk Drive
FSB	Fail-Safe Booter
HDD	Hard Disk Drive
I ² C	Inter-integrated Circuit
IDE	Integrated Device Electronics
I/O	Input/Output
ISA	Industry Standard Architecture
KBD	Keyboard
LED	Light Emitting Diode
LW	Late Write
OEM	Original Equipment Manufacturer
OS	Operating System
PAL	Privileged Architecture Library
PCI	Peripheral Component Interconnect
PCB	Printed Circuit Board
PMU	Power Management Unit

Abbreviation	Meaning
ROM	Read-only Memory
RTC	Real Time Clock
SCSI	Small Computer System Interface
SDRAM	Synchronous Dynamic Random Access Memory
SEC	Samsung Electronics Co., Ltd.
SM	System Management
SPD	Serial Presence Detect
SRM	System Reference Manual
SROM	Serial Read-only Memory
SRAM	Static Random Access Memory
SSRAM	Synchronous SRAM
UL	Underwriters Laboratory
UART	Universal Asynchronous Receiver Transmitter
USB	Universal Serial Bus
VID	Voltage Identification
VRM	Voltage Regulator Module

Chapter 1 UP1100 Introduction

This chapter provides an overview of the UP1100 product, including its components and features.

The UP1100 product consists of an Alpha 21264A Processor Central Processing Unit (CPU), and a Peripheral Component Interconnect (PCI) bus interfacing the following components:

- Advanced Micro Devices, Inc. (AMD) AMD-751 System Controller
- Acer Laboratories, Inc. (ALI) M1535D PCI-ISA Bridge
- Samsung Electronics Co., Ltd. (SEC) KM736FV4011H L2 cache
- Intel Corp. 21143 PCI/CardBus 10/100 Mb/s LAN (Ethernet) Controller
- Creative Labs, Inc. Sound Blaster-compatible sound chip
- Voltage Regulator Module (VRM)

UP1100s are designed for use in uniprocessor workstation and low-end server platforms.

1.1 Features

Table 1-1 provides a summary of the UP1100 product features.

Table 1-1 UP1100 Product Features

Feature	Description	Manufacturer
Physical Form Factor:	ATX (12" X 9.6")	
CPU:	Supports one 600 MHz EV67 Alpha 21264A Processor	SEC
Cache:	External 2 MB L2 cache, 128-bit Late Write Synchronous Static Random Access Memory (SSRAMS)	SEC
Chipsets:	• AMD-751 System Controller	AMD
	• M1535D PCI-ISA Bridge	ALI
	• 21143 LAN Controller	Intel
Main Memory:	Three 168-pin, PC 100 Synchronous Direct Random Access Memory (SDRAM) unbuffered Serial Presence Detect (SPD) Dual Inline Memory Modules (DIMMs) of 64 MB, 128 MB, or 256 MB, providing 64 MB to 768 MB memory with Error Correcting Code (ECC)	

Table 1-1 UP1100 Product Features (Continued)

Feature	Description	Manufacturer
Power:	<ul style="list-style-type: none"> Requires 300W ATX power supply Uses ATX power connectors 	
System Interface:	<ul style="list-style-type: none"> 100 MHz clock with Double Data Rate (DDR) transfers Two Ultra DMA 33/66 Integrated Device Electronics (IDE) connectors, driven by the dual-channel IDE controllers in the M1535D PCI-ISA Bridge Inter-integrated Circuit (I²C) System Management (SM) bus Two external Universal Serial Bus (USB) ports, driven by the USB controller in the M1535D PCI-ISA Bridge 	
On-board Input/Output (I/O):	<ul style="list-style-type: none"> Two serial Universal Asynchronous Receiver Transmitter (UART) ports, driven by the Super I/O controller in the M1535D PCI-ISA Bridge One Enhanced Capabilities Port (ECP) / Enhanced Parallel Port (EPP) / SP parallel port, driven by the Super I/O controller in the M1535D PCI-ISA Bridge One dual-drive capable Floppy Disk Drive (FDD) controller driven by the Super I/O controller in the M1535D PCI-ISA Bridge PS/2 Keyboard and Mouse port 	
I/O Slots:	<ul style="list-style-type: none"> One 2x Accelerated Graphics Port (AGP) slot, driven by the AGP controller in the AMD-751 System Controller Three 33 MHz PCI slots, driven by the 32-bit PCI bus controller in the AMD-751 System Controller 	
Sound Card:	Sound Blaster-compatible sound controller driven by the M1535D PCI-ISA Bridge	
Firmware:	Embedded Alpha System Reference Manual (SRM) Console	

1.2 System Components

The UP1100 is implemented in industry-standard parts and uses an Alpha 21264A Processor. The functional components of the UP1100 are shown in block diagram form in Figure 1-1. A detailed description of system components is provided in the *UP1100 Technical Reference Manual*, P/N 51-0049.

Note: Refer to the list of Acronyms on page x of the Preface for an explanation of terminology used in the block diagram.




Figure 1-1 UP1100 Functional Block Diagram

Chapter 2 System Configuration

This chapter describes the layout and configuration of the UP1100. It includes information about switch settings used to determine the UP1100 configuration.

2.1 Board Layout and Components

On-board connectors are provided for the following:

- AGP and PCI cards
- IDE and FDD devices
- USB devices
- Memory DIMMs
- Serial and parallel peripherals
- LAN (Ethernet) port
- Audio In/Out and Mic In connections
- Power

These connectors and the configuration switchpack are shown in Figure 2-1, which depicts the UP1100 and its components. Table 2-1 specifies the components as indicated in Figure 2-1.

Refer to Appendix A for a complete description of the connectors and pinouts used in the UP1100.




Figure 2-1 UP1100 Layout

Table 2-1 UP1100 Connector Component List

Comp. No.	Specification	Comp. No.	Specification
J1	AGP Connector	J2	168-pin DIMM Socket, Slot 0
J3	168-pin DIMM Socket, Slot 1	J4	168-pin DIMM Socket, Slot 2
J5	32-bit PCI Connector, Slot 0	J6	32-bit PCI Connector, Slot 1
J7	32-bit PCI Connector, Slot 2	J8	Local Area Network (LAN—RJ-45 Ethernet) Connector

Table 2-1 UP1100 Connector Component List (Continued)

Comp. No.	Specification	Comp. No.	Specification
J9	Mic In Connector	J10	Primary IDE Connector
J11	Secondary IDE Connector	J12	FDD Connector
J13	Serial/Parallel I/O Port	J14	USB Port
J15	Keyboard/Mouse Port	J16	Audio In/Out Connector
J17	Compact Disk (CD) Audio In Connector	J18	ATX Power Connector
J19	Power LED Connector	J20	Not Used
J21	Voltage Identification (VID) Port	J22	System Management (SM) Bus Extender Port
J23	Power Button Connector	J25	Speaker Cable Connector
J26	Hard Disk Drive (HDD) Activity LED Connector	J27	Reset Button Connector
J28	Keyboard Lock Cable Connector	J29	System Fan Connector
J30	CPU Fan Connector 0	J31	Debug Port
J32	Electrically Programmable Logic Device (EPLD) Program Port		

2.2 Memory Subsystem

2.2.1 Memory Configuration

The memory subsystem has one DIMM bank with three independent slots. (See Figure 2-2.) Each slot accepts 168-pin, PC100 SDRAM Unbuffered SPD DIMM modules.




Figure 2-2 Memory Subsystem

2.2.2 Memory Guidelines

Use the following rules to populate the UP1100 memory subsystem:

- Populate Slot 1 (J3) first.
- DIMM size can be 64 MB, 128 MB or 256 MB.
- Each slot can use different sized DIMMs.
- Memory is supported in a size range between 64 MB (minimum) to 768 MB (maximum).

See Table 2-2 for typical memory configurations.

Note: For a list of supported memory manufacturer's and parts, check the Alpha Processor, Inc. website for the UP1100 Hardware Compatibility List (HCL):

<http://www.alpha-processor.com/>

Table 2-2 Typical UP1100 Memory Configurations

Total Memory	No. of DIMMs	Slot 1 (J3)	Slot 2 (J4)	Slot 0 (J2)
64 MB	1	64 MB		
128 MB	1	128 MB		
128 MB	2	64 MB	64 MB	
256 Mb	1	256 MB		
256 MB	2	128 MB	128 MB	
256 Mb	3	128 MB	64 MB	64 MB
384 MB	2	256 MB	128 MB	
512 MB	2	256 MB	256 MB	
512 MB	3	256 MB	128 MB	128 MB
768 MB	3	256 MB	256 MB	256 MB

2.3 Configuration Settings

The UP1100 has one configuration switchpack, SW1, which has selectable settings. These switch settings are organized as follows:

- Switches 1 and 2—Firmware image selection
- Switches 7 and 8—L2 cache size selection

The location of SW1 is shown in Figure 2-1, in the lower-left corner of the board.

Note: Do not change the factory settings of any other switches on SW1. Only Switches 1, 2, 7 and 8 are supported for configuration of the UP1100.

2.3.1 Firmware Image Selection

Configuration of alternate firmware is managed through setting of switches 1 and 2 on SW1, as shown in Table 2-3. Switches 1 and 2 are On by default, which boots the UP1100 under SRM Console.

Table 2-3 Firmware Configuration Settings (SW1, Switches 1 and 2)

Function	Switch 1 Position	Switch 2 Position
SRM Console (default)	On	On
Fail Safe Booter (FSB)	Off	Off

2.3.2 Cache Size Selection

Cache size is configured using Switches 7 and 8 of SW1, as shown in Table 2-4.

Table 2-4 Cache Size Configuration Settings (SW1, Switches 7 and 8)

Function	Switch 7 Position	Switch 8 Position
Cache Disable	On	On
2 MB	On	Off
Reserved	Off	On
Reserved	Off	Off

Chapter 3 Electrical, Environmental and Physical Data

In this chapter, a description is provided of the UP1100 power requirements, environmental and enclosure specifications, and physical parameters.

3.1 Power Specifications

3.1.1 Power Consumption

The UP1100 has a typical total power consumption of 90W. Table 3-1 lists the current requirement for each direct current supply voltage (Vdc) for the UP1100. All requirements are for fully populated products, with maximum usage applied.

Note: *This table does not include requirements for peripheral slots or disk drives. Be sure to allow for adequate additional current when selecting a power supply for the UP1100.*

Table 3-1 UP1100 Typical Power Consumption

Supply Voltage	Current	Power	Remarks
3.3V	5.1A	17W	
5.0V	13A	65W	
5.0V standby	0.8A	4.0W	Excluded in total power
-5.0V	0.1A	0.5W	
12V	0.1A	1.2W	
-12V	0.1A	1.2W	Fans
Total Power Consumption:		90W	

3.1.2 Power Supply

The UP1100 requires the use of a 300 Watt ATX power supply. Alpha

Processor, Inc. recommends the power supply described in Table 3-2, or any comparable power supply which can provide the same level of support.

Table 3-2 Recommended Power Supply

Feature	Specification
Vendor and Model:	EMACS AP2-5300F
Output:	• 30A @ +5V
	• 10A @ +12V
	• 1.0A @ -5V
	• 1.0A @ -12V
	• 28A @ +3.3V
	• 0.85A @ 5 Vsb Typical
Qualifications:	• Maximum allowable 3.3V + 5V total draw = 175W
	• Maximum total continuous power = 300W
	• Maximum total peak power = 300W

3.1.3 Power Connectors

The power connector on the UP1100 is an ATX Standard 10 x 2 (20-pin) connector.

3.2 Environmental Specifications

The Alpha 21264A Processor is cooled by one 80 mm fan blowing air directly into the chip's heat sink. The UP1100 is designed to run efficiently using only this fan. Additional fans may be necessary depending upon cabinets and requirements of plug-in cards.

The UP1100 is specified to run within the environment listed in Table 3-3.

Table 3-3 Environmental Requirements

Parameter	Specification
Operating temperature	+5°C to +35°C (+41°F to +95°F)
Storage temperature	-35°C to +85°C (-31°F to +185°F)
Relative Humidity	10% to 90%, with maximum wet bulb temperature of 35°C (95°F) and minimum dew point of 2°C (36°F)
Rate of (dry bulb) temperature change	11°C/hr. ±2°C/hr. (20°F/hr. ±4°F/hr.)

3.2.1 Safety

The UP1100 meets registered product-safety certification for the U.S. and Canadian Underwriters Laboratories (UL and cUL). It also meets the European Conforming (CE) standard EN 60950:1992 "Safety of Information Technology Equipment Including Electrical Business Equipment Incorporating Amendment Nos 1, 2, 3, 4." European Norm (EN) standards are published in the Official Journal of the European Community.

3.2.2 EMI

The UP1100 meets electro-magnetic interference (EMI) emission certification for the following:

- EN 55022:1994/A1:1958/A2:1997 Class A ITE emissions requirements
- Federal Communications Commission (FCC) 47 CFR Part 15 Class A

It also meets the EMI immunity certification EN 50082-1:1992 "EMC Residential, Commercial and Light Industrial Generic Immunity Standard."

3.2.3 Thermal

Figure 3-1 shows the location of thermally-sensitive components on the UP1100. A list of maximum allowable case temperatures for these components is provided in Table 3-4.

Case temperatures are a vital factor in determining airflow on a Printed

Circuit Board (PCB). Variables which may affect a component's case temperature include the following:

- Operating temperature
- Operating frequency
- Current load




Figure 3-1 Thermally-sensitive Components

Table 3-4 Maximum Component Case Temperatures

Component	Maximum Temperature
Alpha 21264A Processor	<77.8°C (172°F)
AMD-751 System Controller	<70°C (158°F)

3.3 Enclosure Requirements

This product has been approved for use in the Axxion Group ATX Case, DL-17. Refer to section 3.5, “Rear Panel I/O Shield,” on page 3-6 for additional details on enclosure requirements.

3.4 Physical Parameters

3.4.1 UP1100 Parameters

The UP1100 is a PCB with the dimensions specified in Table 3-5.

Table 3-5 UP1100 Physical Parameters

Dimension	Value
Length	304.8 mm (12 in)
Width	243.8 mm (9.6 in)
Height	65 mm (2.6 in)

3.4.2 UP1100 Mounting Hole Specification

The UP1100 mounting hole specification is depicted in Figure 3-2. This mounting hold specification is an standard ATX implementation, which allows the UP1100 to fit into standard ATX chassis.




Figure 3-2 UP1100 Mounting Hole Specification

3.5 Rear Panel I/O Shield

The UP1100 rear panel connectors must be fitted with a suitable ATX Core Design #6 I/O shield, as shown in Figure 3-3. Individual rear panel I/O connectors are designated with letters. Each connector type and its description are listed in Table 3-6.




Figure 3-3 Rear Panel Connectors

Table 3-6 Rear Panel Connectors

Letter	Connector Description
A	PS/2 Stacked Mouse (top)/Keyboard (bottom) [DIN]
C	Stacked Parallel (25 Pin D-Sub)
D, E	Serial (9 Pin D-Sub)
I	Dual USB
O	LAN (RJ-45 Ethernet)
P	Audio In (top)/Audio Out (bottom) [Phono jack]
Q	Microphone In (Phono jack)

Chapter 4 Software Support

4.1 Software Overview

UP1100 systems support three major software components:

- Fail Safe Booter (FSB)
- Reset PALcode (Privileged Architecture Library)
- Alpha SRM Console
- Operating System (OS)

4.1.1 FSB

FSB firmware is used for firmware recovery procedures. The UP1100 supports FSB release 1.0 or higher.

4.1.2 Reset PALcode

When the UP1100 is turned on or reset, Reset PALcode firmware automatically loads and performs system initialization activities. Once Reset PALcode firmware is loaded, it automatically loads the next level of firmware and passes control to that code.

The UP1100 supports Reset PALcode version X17.9 or higher.

4.1.3 Alpha SRM Console

The SRM Console is special firmware that initializes the UP1100 system and enables you to install and boot the operating systems. Alpha SRM Console firmware resides in the flash ROM on the UP1100.

For further information about the Alpha SRM Console, visit our website at:

<http://www.alpha-processor.com/support/srm.html>

or

Navigate from the Alpha Processor, Inc. website:

<http://www.alpha-processor.com/>

through the following steps:

1. Click on Support in the upper right of your browser.
2. Click on FAQs (Frequently Asked Questions) in the center left of your browser.
3. Scroll through the FAQ questions until you reach the one on the SRM Console.
4. Click on the word, "here." This takes you to the SRM web pages.

or go to the Alpha Linux home page:

<http://www.alphalinux.org/>

4.1.4 Operating System

The UP1100 works with the Linux kernel 2.2.14 or higher in order to boot from SRM A5.6-3 or higher.

Note: *Consult the Alpha Processor, Inc. website for a list of OS vendors and versions currently supported.*

4.2 Alpha SRM Console

The Alpha SRM Console is the command line interface that supports the Linux operating systems. The SRM Console is used to bootstrap the operating system, configure and test the system hardware, examine system options for errors, and set or change environment variables.

The following sections describe the SRM Console commands and environment variables:

- Invoking the SRM Console
- Command summary
- Displaying the system configuration
- Booting the Operating System
- Updating firmware
- Using environment variables
- Environment variable summary
- Finding Help

4.2.1 Invoking the SRM Console

When a system is powered up, the SRM Console runs and either remains running or passes control to an operating system. If the system is already running, you can invoke the SRM Console by:

- Shutting down the operating system
- Pressing the **Reset** button

Both of these actions return you to the SRM Console prompt, >>>.

For example, in a running system, in which control has passed to the Linux operating system, do one of the following steps to invoke SRM Console mode:

- Shut down the operating system according to the procedure described in your operating system documentation. The SRM Console prompt, >>>, appears.
- Or:
 1. Press the **Reset** button. The SRM Console prompt, >>>, appears. You may now perform tasks in SRM Console mode.
 2. At the >>> prompt, type **boot** to return to the operating system.

Note: See "Using Environment Variables," section 4.2.7 on page 4-15 for more details.

4.2.2 Command Summary

The SRM Console is a command line interface. SRM Console commands enable you to examine and modify the system state. Table 4-1 gives the most commonly used SRM Console commands. Table 4-2 gives the syntax for the SRM Console commands. Table 4-3 gives special characters you can use in SRM Console mode.

Table 4-1 Summary of SRM Console Commands

Command	Function
boot	Loads and starts the operating system.
<code>clear envar</code>	Resets an environment variable to its default value.
clear password	Sets the password to zero.
<code>continue</code>	Resumes program execution.
date	Sets or displays the system time and date.
<code>edit</code>	Invokes the SRM Console line editor on a RAM file or on the nvram file (power-up script).
halt	Halts the processor. (Same as the stop command.)
<code>help</code>	Displays information about the specified SRM Console command.
initialize	Resets the system to a known state.

Table 4-1 Summary of SRM Console Commands (Continued)

Command	Function
<code>isacfg</code>	Displays or modifies parameters for ISA devices.
<code>lfu</code>	Runs the Loadable Firmware Update Utility.
<code>login</code>	Turns off secure mode, enabling access to all SRM Console commands during the current session.
<code>more</code>	Displays a file one screen at a time.
<code>set envar</code>	Sets or modifies the value of an environment variable.
<code>set password</code>	Sets the SRM Console password for the first time or changes an existing password.
<code>set secure</code>	Enables secure mode without requiring a restart of the SRM Console.
<code>show envar</code>	Displays the state of the specified environment variable.
<code>show config</code>	Displays the configuration at the last system initialization.
<code>show cpu</code>	Displays the state of the processor.
<code>show device</code>	Displays a list of controllers and their devices in the system.
<code>show memory</code>	Displays memory module information.
<code>show pal</code>	Displays the version of the privileged architecture library code (PALcode).
<code>show version</code>	Displays the version of the SRM Console program.
<code>stop</code>	Halts the processor. (Same as <code>halt</code> .)

Table 4-2 Syntax for SRM Console Commands

Option	Attribute or Action
Length	Up to 255 characters, not including the terminating carriage return or any characters deleted as the command is entered. A command longer than 80 characters and without the backslash character (see Table 4-3) causes display of an error message.
Case	Upper- or lowercase characters can be used for input. Characters are displayed in the case in which they are entered.
Abbreviation	Only by dropping characters from the end of words. You must enter the minimum number of characters to identify the keyword unambiguously. Abbreviation of environment variables is allowed with the show command.
Options	You can use command options, to modify the environment, after the command keyword or after any symbol or number in the command. See individual command descriptions for examples.
Numbers	Most numbers in SRM Console commands are in decimal notation. Two exceptions, both of which use hexadecimal notation, are addresses and numbers used in the deposit command. The default radic can be overridden by inserting %d before the numbers you want to express in decimal, %o before octal, or %x before hexadecimal. Register names (for example, R0) are not considered numbers and use decimal notation.
No characters	A command line with no characters is a null command. The SRM Console program takes no action and does not issue an error message; it returns the SRM Console prompt. The SRM Console supports command line recall and editing.
Spaces or Tabs	Multiple adjacent spaces and tabs are compressed and treated as a single space. The SRM Console program ignores leading and trailing spaces.

Table 4-3 Special Characters for SRM Console

Character	Function
Return or Enter	Terminates a command line. No action is taken on a command until it is terminated. If no characters are entered and this key is pressed, the SRM Console just redisplay the prompt.
Backslash (\)	Continues a command on the next line. Must be the last character on the line to be continued.
Delete	Deletes the previous character.
Help	By itself, displays first-level help. When the Help key is pressed after part of a command, the system displays available options.
Ctrl/A or F14	Toggles between insert and overstrike modes. The default is overstrike.
Ctrl/B or up-arrow	Recalls previous command or commands. The last 16 commands are stored in the recall buffer.
Ctrl/C or Ctrl/P	Terminates the process that is running. Clears Ctrl/S; resumes output suspended by Ctrl/O. When entered as part of a command line, deletes the current line. Ctrl/C has no effect as part of a binary data stream.
Ctrl/D or left-arrow	Moves the cursor left one position.
Ctrl/E	Moves the cursor to the end of the line.
Ctrl/F or right-arrow	Moves the cursor right one position.
Ctrl/H or Backspace or F12	Moves the cursor to the beginning of the line.
Ctrl/J	Deletes the previous word.
Ctrl/O	Stops output to the SRM Console terminal for the current command. Toggles between enable and disable. The output can be reenabled by other means as well: when the SRM Console prompts for a command, issues an error message, or enters program mode, or when Ctrl/P is entered.
Ctrl/Q	Resumes output to the SRM Console terminal that was suspended by Ctrl/S.
Ctrl/R	Redisplay the current line. Deleted characters are omitted. This command is useful for hardcopy terminals.
Ctrl/S	Suspends output to the SRM Console terminal until Ctrl/Q is entered. Cleared by Ctrl/C.
Ctrl/U	Deletes the current line.

Table 4-3 Special Characters for SRM Console (Continued)

Character	Function
*	Wildcarding for commands such as <code>show</code> .
" "	Double quotes enable you to denote a string for environment variable assignment.
#	Specifies that all text between it and the end of the line is a comment. Control characters are not considered part of a comment.

4.2.3 Displaying the System Configurations

Several commands are used to display the system configuration:

- `show config`
- `show cpu`
- `show device`
- `show memory`
- `show pal`
- `show version`

`show config`

The `show config` command displays a list of devices found on the system interconnect and I/O buses. This is the configuration at the most recent initialization. The syntax is:

show config

Example 4-1 Show Config Command

```
>>>show config
                               SEC UP1100 598 MHz

SRM Console:A5.6-7
PALcode:OpenVMS PALcode V1.69-54, Tru64 UNIX PALcode V1.62-1

Processors
CPU 0 Alpha 21264A-9 598 MHz      SROM Revision: X17.9
      Bcache size: 2 MB

Core Logic
System Controller   AMD-751 Revision C Step 6

MEMORY

Array #      Size      Base Addr
-----      -
      1      128 MB      000000000
```

Total Bad Pages = 0
 Total Good Memory = 128 MBytes

```

PCI Hose 00
  Bus 00 Slot 01/0: 70071022
                                     Bridge to Bus 2, PCI
  Bus 00 Slot 03: Acer Labs M1535D Modem

  Bus 00 Slot 06: Acer Labs M1535D Audio

  Bus 00 Slot 07: Acer Labs M1535D
                                     Bridge to Bus 1, ISA
  Bus 00 Slot 11: DE500-BA Network Controller
                   ewa0.0.0.11.0 00-00-F0-51-00-2D
  Bus 00 Slot 16: Acer Labs M1535D IDE
                   dqa.0.0.16.0
                   dqa0.0.0.16.0 QUANTUM FIREBALLlct1
                   dqb0.0.1.16.0 ATAPI CD -ROM DRIVE
  Bus 02 Slot 05: 0525102B/217D102B
    
```

ISA Slot	Device Name	Type	Enabled	BaseAddr	IRQ	DMA
0	MOUSE	Embedded	Yes	60	12	
1	KBD	Embedded	Yes	60	1	
2	COM1	Embedded	Yes	3f8	4	
3	COM2	Embedded	Yes	2f8	3	
4	LPT1	Embedded	Yes	3bc	7	
5	FLOPPY	Embedded	Yes	3f0	6	2
6	EIDE	Embedded	Yes	1f0 3f6 170 376	14 15	
7	PWR_MANAGEMENT	Embedded	Yes			
8	USB	Embedded	No			

show cpu

The show cpu command displays the status of the CPU. The syntax is:

show cpu

Example 4-2 Show CPU Command

```
>>>show cpu

Primary CPU:      00
Active CPUs:     00
Configured CPUs: 00
SROM Revision:   X17.9
```

show device

The `show device` command displays status for devices and controllers in the system: SCSI and MSCP devices, the internal floppy drive, and the network. The syntax is:

```
show device [controller_name]
```

controller_name The controller name or abbreviation. When abbreviations or wildcards are used, all controllers that match the type are displayed. If no name is given, the display is a list of all devices and controllers in the system.

Example 4-3 Show Device Command

```
>>>show device
dka600.6.0.8.0            DKA600            QUANTUM ATLAS IV 36 WLS    0A0A
dkb600.6.0.108.0        DKB600            QUANTUM ATLAS 10K 9WLS    UCH0
dqa0.0.0.16.0            DQA0             CD-ROM C DU4011    UY0A
dva0.0.0.0.0            DVA0
pka0.7.0.8.0            PKA0             SCSI Bus ID 7
pkb0.7.0.108.0         PKB0             SCSI Bus ID 7
```

An example of a device name is `dka200.2.0.7.1`. Table 4-4 shows the interpretation of this device name.

Table 4-4 Device Naming Convention

Category		Description
Two-letter designator of port or class driver:		
dk	Driver ID	dk SCSI device fw FDDI device
		dq IDE Device mk SCSI tape
		dr RAID set device mu DSSI tape
		du DSSI disk pk SCSI port
		dv Diskette drive pu DSSI port
		ew Ethernet port
a	Storage adapter ID	One-letter designator of storage adapter (a, b, c...).
200	Device unit number	Unique number (MSCP unit number). SCSI unit numbers are forced to 100 X node ID.
2	Bus node number	Bus node ID.
0	Channel number	Used for multi-channel devices.
7	Logical slot number	Corresponds to PCI slot number.
1	Hose number	0 — PCI 0

Table 4-5 PCI Address Assignments

Bus	Device #	Description
Bus 0	0	AMD-751 System Controller
	1	AMD-751 System Controller, AGP Controller
	7	M1535D PCI-ISA Bridge
	8	PCI Slot 0
	9	PCI Slot 1
	10	PCI Slot 2
	16	M1535D PCI-ISA Bridge, IDE
	17	M1535D PCI-ISA Bridge, USB
	18	M1535D PCI-ISA Bridge, Power Management Unit (PMU)
Bus 1		AGP Slot

`show memory` The `show memory` command displays information about each memory bank: slot number, size in megabytes, and the starting address. The syntax is:

show memory

Example 4-4 Show Memory Command

```
>>>show memory
```

Array #	Size	Base Addr
0	128 MB	000000000
1	128 MB	008000000
2	128 MB	010000000

```
Total Bad Pages = 0
Total Good Memory = 384 MBytes
```

`show pal` The `show pal` command displays the versions of PALcode. PALcode is written to support Alpha processors. It implements architecturally defined processor behavior. The syntax is:

show pal

Example 4-5 Show PAL Command

```
>>>show pal
```

```
pal                               OpenVMS PALcode V1.69-54, Tru64 UNIX PALcode
V1.62-1
```

`show version` The `show version` command displays the version of the SRM Console program that is installed on the system. The syntax is:

show version

Example 4-6 Show Version Command

```
>>>show version
```

```
version                             A5.6-7 May 21 2000 22:26:51
```

4.2.4 Setting the System Date

The `date` command is used to either display or set the system time and date.

The syntax is:

```
date [<yyyymmddhhmm.ss>]
```

Example 4-7 Date Command

```
>>>date
 2:51:27 June 6, 2002
>>>date 200006060342.00
>>>date
 3:42:02 June 6, 2000
```

4.2.5 Booting the Operating System

The `boot` command is used to boot the operating system.

Example 4-8 Boot Command

```
>>> b dka200

(boot dka200.2.0.7.1 -flags 0,0)
block 0 of dka200.2.0.7.1 is a valid boot block
reading 893 blocks from dka200.2.0.7.1
bootstrap code read in
base = 1fa000, image_start = 0, image_bytes = 6fa00
initializing HWRPB at 2000
initializing page table at 1fff0000
initializing machine state
setting affinity to the primary CPU
jumping to bootstrap code
```

The `boot` command initializes the processor, loads a program image from the specified boot device, and transfers control to that image. The syntax is:

```
boot [-file filename] [-flags [value]] [-halt]
[-protocols enet_protocol] [boot_dev]
```

Table 4-6 Boot Command Options

Option	Description
-file filename	The boot file.
-flags [value]	Specifies additional information to the loaded image or operating system. This qualifier overrides the setting of the <code>boot_osflags</code> environment variable. See the <code>boot_osflags</code> environment variable on page 4-18 for a list of settings and their meanings.
-halt	Forces the bootstrap operation to halt and invokes the SRM Console program once the bootstrap image is loaded and page tables and other data structures are set up. Operator console* device drivers are not shut down. Transfer control to the image by entering the continue command.
-protocols enet_protocol	Either <code>mop</code> or <code>bootp</code> (default). This qualifier overrides the setting of the <code>ew*0_protocols</code> environment variable (see Table 4-12).
boot_dev	A device path or list of devices from which the SRM Console program attempts to boot, or a saved boot specification in the form of an environment variable. This qualifier overrides the setting of the <code>bootdef_dev</code> environment variable (see page 4-18). Use the <code>bootdef_dev</code> environment variable to define the default boot device string.

*Notes: *The operator console is the monitor, keyboard, and mouse. This hardware is used to enter SRM Console commands into the system.*

4.2.6 Updating Firmware

The `lfu` command is used to update firmware from the SRM Console prompt. The `lfu` command starts the Loadable Firmware Update (LFU) Utility. The syntax is:

`lfu`

Note: *If the system is shut down from a booted program (most commonly, the operating system) or in some other way halted back to the SRM Console, you must reset the system before running LFU.*

To run LFU, set the `auto_action` variable to `halt`, then reset the system. Remember to reset `auto_action` to the original value after you run LFU.

Example 4-9 Lfu Command

```
>>>lfu
```

```
Checking dqa0.0.0.16.0 for the option firmware files. . .
dqa0.0.0.16.0 has no media present or is disabled via the
RUN/STOP
switch
```

```
Checking dva0 for the option firmware files. . .
```

```
Option firmware files were not found on CD or floppy.
If you want to load the options firmware,
please enter the device on which the files are located(ewa0),
or just hit <return> to proceed with a standard console update:
dva0
```

```
Please enter the name of the options firmware files list, or
Hit <return> to use the default filename (upl100fw.txt) :
```

```
Copying upl100fw.txt from dva0. . .
```

```
Copying Gtsrm.rom from dva0. . .
```

```
***** Loadable Firmware Update Utility *****
```

```
-----
Function      Description
-----
Display      Displays the system's configuration table.
Exit         Done exit LFU (reset).
List         Lists the device, revision, firmware name, and update
            revision.
Readme       Lists important release information.
Update       Replaces current firmware with loadable data image.
Verify       Compares loadable and hardware images.
? or Help    Scrolls this function table.
-----
```

```
UPD> list
```

Device	Current Revision	Filename	Update Revision
srm	5.6-7	srm_fw	5.6-7

```
UPD> update
```

```
Confirm update on:
```

```
srm
```

```
[Y/(N)]y
```

```
WARNING: updates may take several minutes to complete for each
device.
```

```
DO NOT ABORT!
```

```
srm          Updating to 5.6-4...  Verifying 5.6-4...  PASSED.
```

```
UPD>
```

Note: Refer to section 4.3, “FSB,” on page 4-26 for information on updating SRM Console firmware using the FSB.

4.2.7 Using Environment Variables

Environment variables pass configuration information between the SRM Console and the operating system. Their settings determine how the system powers up, boots the operating system, and operates. You issue an `init` command (see page 4-25 for more details) to activate a new environment variable.

Example 4-10 Set `envar` and Show `envar` Commands

```
>>> show console
console                               graphics
>>> set console serial
>>> show console
console                               serial
>>> init
```

Environment variables are set or changed with the `set envar` command and set to default values with the `set -default envar` command. Their values are viewed with the `show envar` command. User-defined nonvolatile environment variables are created with the `edit` (see section 4.2.9 on page 4-25 for further information) command.

`set envar`

The `set` command sets or modifies the value of an environment variable. It can also be used to create a new environment variable if the name used is unique. Environment variables are used to pass configuration information between the SRM Console and the operating system. The setting of these variables determines how the system powers up, boots the operating system, and operates. The syntax is:

```
set [-default] envar value
```

Table 4-7 Set Envar Options

Option	Description
<code>-default</code>	Restores an environment variable to its default setting.
<code>envar</code>	The name of the environment variable to be modified.
<code>value</code>	The new value of the environment variable.

Whenever you modify the value of any of the following environment

variables, the new value takes effect only after you reset the system by pressing the **Reset** button or issuing the `initialize` command:

Note: All other environment variables take effect immediately after you set the value.

- `console`
- `kbd_hardware_type`
- `language`
- `os_type`

`show envar`

The `show envar` command displays the current value (or setting) of an environment variable. The syntax is:

show envar

`envar` The name of the environment variable to be displayed.
The wildcard * displays all environment variables.

Example 4-11 Using show envar

```
>>>show os_type
>>>unix
```

4.2.8 Environment Variable Summary

Environment variables pass configuration information between the SRM Console and the operating system. Their settings determine how the system powers up, boots the operating system, and operates. Environment variables are set or changed with the `set envar` command and returned to their default values with the `clear envar` command. Their values are viewed with the `show envar` command.

Table 4-8 lists the environment variables. Detailed descriptions follow. The environment variables are specific to the SRM Console.

Table 4-8 Environment Variable Summary

Environment Variable	Function
<code>auto_action</code>	Specifies the SRM Console's action at power-up, a failure, or a reset.
<code>bootdef_dev</code>	Specifies the default boot device string.
<code>boot_osflags</code>	Specifies the default operating system boot flags.
<code>com*_baud</code>	Changes the default baud rate of the COM1 or COM2 serial port.

Table 4-8 Environment Variable Summary (Continued)

Environment Variable	Function
<code>console</code>	Specifies the device on which power-up output is displayed (serial terminal or graphics monitor).
<code>ei_mode</code>	Specifies the connection type of the default Ethernet controller. In this case, the controller is an Intel controller.
<code>ew*0_mode</code>	Specifies the connection type of the default Ethernet controller. In this case, the controller is a Digital Equipment Corporation controller.
<code>ew*0_protocols</code>	Specifies network protocols for booting over the Ethernet controller.
<code>kbd_hardware_type</code>	Specifies the default operator console keyboard type.
<code>language</code>	Specifies the operator console keyboard layout.
<code>os_type</code>	Specifies the operating system. Valid entry is: Linux.
<code>password</code>	A password stored in the NVRAM used to secure the operator console.
<code>pci_parity</code>	Disables or enables parity checking on the PCI bus.
<code>pk*0_fast</code>	Enables fast SCSI mode.
<code>pk*0_host_id</code>	Specifies the default value for a controller host bus node ID.
<code>pk*0_soft_term</code>	Enables or disables SCSI terminators on systems that use the QLogic ISP1040 SCSI controller.
<code>tt_allow_login</code>	Enables or disables login to the SRM Console firmware on other operator console ports.

`auto_action`

Specifies the action the SRM Console takes any time the system powers up, fails, or resets. When the setting involves autoboot, the system boots from the default boot device specified by the value of the `bootdef_dev` environment variable. The syntax is:

```
set auto_action value
```

The options for *value* are show in Table 4-9.

Table 4-9 Auto_Action Values

Option	Description
halt	The system remains in SRM Console mode after power-up or a system crash.
boot	The system boots automatically when it is turned on and halts after a system failure.
restart	The system boots automatically when it is turned on or after it fails.

Note: *If a halt assertion exists, the SRM Console ignores the auto_action setting and halts at the SRM Console.*

bootdef_dev

The `bootdef_dev` environment variable specifies one or more devices for booting the operating system. When more than one device is listed, the system searches in the order listed and boots from the first device with operating system software. The syntax is:

```
set bootdef_dev boot_device
```

boot_device The name of the device on which the system software has been loaded. To specify more than one device, separate the names with commas. Enter the command `show bootdef_dev` to display the current default boot device. Enter the command `show device` for a list of all devices in the system.

boot_osflags

The `boot_osflags` environment variable passes information to the `boot` command. That information is dependent on the operating system to be booted. The syntax is:

```
set boot_osflags flags_value
```

The options for *flags_value* are shown in Table 4-10.

Table 4-10 Boot_Osflags Options

Option	Description
<code>root=/dev/sda5</code>	Set the root filesystem to the 5 th partition of the first SCSI disk.
<code>root=/dev/hda2</code>	Set the root filesystem to the 2 nd partition of the first IDE disk.
<code>1</code>	Use config number 1 from the <code>/etc/about.conf</code> file

`com*_baud`

The default baud rate for the system is 9600. With the `com*_baud` environment variable, you can set the baud rate to match that of the device connected to the port.

The syntax is:

```
set com*_baud baud_value
```

baud_value The new baud rate. A list of possible values is displayed by attempting to set this environment variable to an unacceptable value (for example, `set com2_baud xxx`).

You will be asked to confirm the change, as shown in the following example:

Example 4-12 Using `com*_baud`

```
>>> set com1_baud 19200
Embedded Remote Console only supports 9600 baud. Continue?
(Y/[N]) n
bad value - com1_baud not modified
>>>
```

`console`

The operator console terminal can be either a graphics monitor or a serial terminal. The `console` environment variable specifies which is used. The syntax is:

```
set console output_device
```

The options for `output_device` are:

`graphics` (default) The operator console terminal is a graphics monitor or a device connected to the VGA or TGA module.

`serial` The operator console terminal is the device connected to the COM2 port.

Whenever you change the value of `console`, you must reset the system by pressing the **Reset** button or issuing the `initialize` command.

`ew*0_mode` Sets an Ethernet controller to run an Ethernet network. The default value is `auto-sense`. For the fast setting, the device defaults to `fast`.

The syntax is:

```
set ew*0_mode value
```

The options for `value` are shown in Table 4-11.

Table 4-11 ew*0_mode Options

Option	Description
au i	Device type is AUI.
<code>auto-sense</code>	Device type is sensed by the SRM Console.
twisted-pair	Device type is 10BaseT (twisted pair).
<code>fast duplex, twisted-pair</code>	Device type is duplex 10BaseT
fast	Device type is fast 100Base TX
<code>fastFD</code>	Device type is fast full duplex 100Base TX
BNC	Device type is BNC
<code>auto-negotiate</code>	DE500-BA provides auto-sensing capabilities

`ew*0_protocols` Enables network protocols for booting and other functions. The syntax is:

```
set ew*0_protocols protocol_value
```

The options for `protocol_value` are show in Table 4-11.

Table 4-12 ew*0_protocols Options

Option	Description
<code>mop</code>	Sets the network protocol to mop (Maintenance Operations Protocol), the setting typically used with the Linux operating system.
<code>bootp (default)</code>	Sets the network protocol to bootp, the setting typically used with the Linux operating system.
<code>bootp, mop</code>	When both are listed, the system attempts to use the mop protocol first, regardless of which is listed first. If not successful, it then attempts the bootp protocol.

`kbd_hardware_type`

Used only on systems with the language variant 3C (Français), this environment variable sets the keyboard hardware type as either PCXAL or LK411 and enables the system to interpret the terminal keyboard layout correctly.

Whenever you change the value of `kbd_hardware_type`, you must reset the system by pressing the **Reset** button or issuing the `initialize` command.

The syntax is:

```
set kbd_hardware_type keyboard_type
```

The options for `keyboard_type` are:

- `pcxal (default)` Selects the default keyboard hardware type.
- `lk411` Selects the LK411 keyboard layout for use with language variant 3C (Français).

`language`

Specifies the keyboard layout, which is language dependent. The setting of the `language` environment variable must match the language of the keyboard variant.

Whenever you change the value of `language`, you must reset the system by pressing the **Reset** button or issuing the `initialize` command.

The syntax is:

```
set language language_code
```

The options for `language_code` are show in Table 4-13.

Table 4-13 Language Options

Option	Description
0	No language (cryptic)
30	Dansk (Danish)
32	Deutsch (German)
34	Deutsch (Schweiz) (Swiss)
36	English (American)
38	English (British/Irish)
3A	Español (Spanish)
3C	Français (French)
3E	Français (Canadian)
40	Français (Suisse Romande)
42	Italiano (Italian)
44	Nederlands (Netherlands)
46	Norsk (Norwegian)
48	Portuguese (Portuguese)
4A	Suomi (Finnish)
4C	Svenska (Swedish)
4E	Belgisch-Nederlands (Dutch)

os_type

The `os_type` environment variable specifies the default operating system. This variable is set at the factory to the setting for the operating system purchased. Use this command to change the factory default setting.

Whenever you change the value of `os_type`, you must reset the system by pressing the **Reset** button or issuing the `initialize` command.

The syntax is:

```
set os_type os_type
```

The options for `os_type` are:

`unix` Linux is the default operating system, and the SRM firmware is started during power-up or reset.

password

Sets or clears the SRM Console password stored in Non-Volatile RAM (NVRAM).

The syntax is:

```
set password
```

The password is not an argument to the `set password` command; the SRM Console prompts the user for the string, which must be between 15 and 30 characters.

`pci_parity`

Disables or enables parity checking on the PCI bus.

Some PCI devices do not implement PCI parity checking, and some have a parity-generating scheme in which the parity is sometimes incorrect or is not fully compliant with the PCI specification. A side effect of this aberrant behavior is that superfluous PCI parity errors are reported by the host PCI bridge. In such cases, the device can be used as long as parity is not checked; disabling PCI parity checking prevents false parity errors that can cause system problems.

The syntax is:

```
set pci_parity value
```

The options for *value* are:

- | | |
|---------------------------|-------------------------------|
| <code>on</code> (default) | Enables PCI parity checking. |
| <code>off</code> | Disables PCI parity checking. |

`pk*0_fast`

Enables fast SCSI to perform in either standard or fast mode. If the system has at least one fast SCSI device, set the default controller speed to fast SCSI (1). Devices on a controller that connects to both standard and fast SCSI devices will perform at the appropriate rate for the device. If the system has no fast SCSI devices, set the default controller speed to standard SCSI (0). If a fast SCSI device is on a controller set to standard, it will perform in standard mode.

The syntax is:

```
set pk*0_fast scsi_speed
```

The options for *scsi_speed* are:

- | | |
|--------------------------|--|
| <code>0</code> | The controller is in standard SCSI mode. |
| <code>1</code> (default) | The controller is in fast SCSI mode. |

`pk*0_host_id`

Sets the controller host bus node ID to a value between 0 and 7.

Each SCSI bus in the system requires a controller. Buses can theoretically

support up to eight devices; however, the eighth device must always be a controller. Each device on the bus, including the controller, must have a unique ID, which is a number between 0 and 7. This is the bus node ID number.

On each bus, the default bus node ID for the controller is set to 7. You do not need to change the controller bus node ID unless you place two or more controllers on the same bus.

To list the controllers on your system, enter the command `show device` (see page 4-9). SCSI devices begin with the letters “pk” (for example, pka0). The third letter is the adapter ID for the controller. When entering the command `set pk*0_host_id`, replace the asterisk with the adapter ID letter.

The syntax is:

```
set pk*_host_id scsi_node_id
```

The value for `scsi_node_id` is the bus node ID, a number from 0 to 7.

pk*0_soft_term

Enables or disables SCSI terminators. This command applies to systems that use the QLogic ISP1040 SCSI controller.

The QLogic ISP1040 SCSI controller implements the 16-bit wide SCSI bus. The QLogic module has two terminators, one for the low eight bits and one for the high eight bits.

The syntax is:

```
set pk*0_soft_term value
```

The options for `value` are shown in Table 4-14.

Table 4-14 pk*0_soft_term Options

Option	Description
<code>off</code>	Disables termination of all 16 bits.
<code>low (default)</code>	Enables low eight bits and disables high eight bits.
<code>high</code>	Enables high eight bits and disables low eight bits.
<code>on</code>	Enables all 16 bits.
<code>diff</code>	Places the bus in differential mode.

`tt_allow_login` Enables or disables login to the SRM Console firmware on alternate operator console ports. If the environment variable `console` (see page 4-19) is set to `serial`, the primary operator console device is the terminal connected through the COM1 port. The command `set tt_allow_login 1` enables logins through either the COM2 port or a graphics monitor.

The syntax is:

```
set tt_allow_login value
```

The options for *value* are:

0	Disables login through the COM2 port or a graphics monitor.
1 (default)	Enables login through the COM2 port or a graphics monitor.

4.2.9 Finding Help

The `help` command displays basic information about SRM Console commands. The syntax is:

```
help [command . . . ]
```

command . . . Command or topic for which help is requested. The options are:

<code>none</code>	Displays the complete list of commands for which you can receive help.
<code>command_name</code>	Displays information about the SRM Console command.
<code>argument_string</code> (such as "sh")	Displays information about all commands that begin with that string.

Example 4-13 Help Command

```
>>> help set
NAME
    set
FUNCTION
    Set an option or modify the value of an environment
    variable.
SYNOPSIS
    set <option> <value> or <envar> [-] <value>
```

```

where
<option>={host,mode}
where
<envar>={auto_action,bootdef_dev,boot_osflags,...}
[-default]

```

4.3 FSB

The FSB provides an emergency recovery mechanism when the primary firmware image contained in flash memory is corrupted.

You can start the FSB in one of the two following ways:

- If the primary firmware image is unavailable when the system is powered on or reset, the FSB runs automatically. When the FSB runs, the system emits a series of beeps through the speaker as beep code 1–2–3; that is, one beep and a pause, followed by two beeps and a pause, followed by three beeps. After the hard disk drive light flashes, insert the UP1100 firmware disk. The FSB loads and runs SRM Console from this disk.
- You can start the FSB manually. To manually start the FSB, perform the following procedures:
 1. Power Off system.
 2. Set switchpack to FSB configuration as shown in section 2.3.1, “Firmware Image Selection.”
 3. Power On system.
 4. Insert UP1100 installation disk into the floppy disk drive.
 5. Upgrade SRM Console.

4.4 Installing the Linux Operating System

The firmware initializes the UP1100 system and, via the Alpha SRM Console, enables you to install and boot the Linux operating system.

As noted at the beginning of the chapter, this system supports many OS distributions and vendors. Consult our website for a complete current list at:

<http://www.alpha-processor.com/>

1. With your browser pointed at the Alpha Processor, Inc. website, click on API Partner Program.
2. Scroll down in this page to the link, Linux Solutions Datasheet. Click on this link. This takes you to a datasheet on supported operating systems and applications.

3. Or, click on Software Vendors at the left center of the browser.

Examples of installing commercially available Linux distributions are given in this section. Typical requirements and procedures for Red Hat Linux Versions 6.2 or SuSE Version 6.3 follow.

4.4.1 Requirements

The following hardware components and settings are necessary for a Linux installation:

- Hard disk connected to the primary IDE port as a master, i.e.,
/dev/hda
- CD-ROM drive connected to the secondary IDE port as a master, i.e.,
/dev/hdc

Device names are different if you are using SCSI adapters or IDE disks. To the Linux kernel:

- SCSI CD-ROM names are "/dev/scdx", where **x** is the device number
- IDE CD-ROM names are "/dev/hdx", where **x** is the drive position
- SCSI hard disk names are "/dev/sdx", where **x** is the drive position
- IDE hard disk names are "/dev/hdx", where **x** is the drive position
- Floppy disk names are "/dev/fdx", where **x** is the device number

The following disks are required:

- The appropriate Linux operating system distribution CD-ROM disk, either the Red Hat Version 6.2 or SuSE Version 6.3 CD-ROM disk.
- If you are installing SuSE Version 6.3, you will need a ramdisk floppy. See the SuSE Version 6.3 documentation for instructions about creating this disk.
- The UP1100 installation diskette is also required.

Note: *For all Linux distributions, be careful when configuring the X server. Do not test the X server configuration.*

4.4.2 Before Installing Linux

Before installing the Linux operating system, follow these instructions:

1. Use the `date` command to set the system time and date. Refer to section 4.2.4, "Setting the System Date," on page 4-11 for details.
2. Make a backup copy of the UP1100 installation diskette.

4.4.3 Setting Environmental Variables

From the SRM Console prompt, >>>, check the device numbers for disk, diskette and CD-ROM drives:

Type `show device`

The SRM Console environmental variables identified in Table 4-15 are set.

Table 4-15 SRM Console Variables

Variable	Setting
<code>bootdef_dev</code>	Sets default boot device Example: <code>DQA0</code> (IDE disk) or <code>DKA0</code> (SCSI disk)
<code>boot_osflags</code>	Information passed to Linux kernel via boot Example: <code>"root=/dev/hda2"</code>
<code>boot_file</code>	Sets file to use as the kernel on the default boot device Example for Red Hat 6.2: <code>kernels/generic.gz</code>

From the SRM Console prompt, >>>, perform the procedures as described in the following paragraphs.

- To set the default boot device:
 - For SuSE Version 6.3, to boot from a floppy drive:
Type `set bootdef_dev dva0`
 - For Red Hat 6.2, to boot from an IDE CD-ROM drive:
Type `set bootdef_dev dqb0`

Note: *If your drive is a different device type, set this variable appropriately.*
- To set the default boot file to the kernel on the CD, choose the command that corresponds to your version of Linux:
 - For SuSE Version 6.3:
Type `set boot_file vmlinux.gz`
 - For Red Hat 6.2:
Type `set boot_file kernels/generic.gz`
- To set the default flags to point to the (currently non-existent) root partition:
 - On a SCSI hard drive:
Type `set boot_osflags "root=/dev/sda2"`
 - On an IDE drive:
Type `set boot_osflags "root=/dev/hda2"`

Note: *Setting the flags to point to sda1 (Linux terminology for SCSI Disk A Partition 2) assumes that you will create and set the first partition during the installation to be the “root” partition. If you plan to use another name for your root partition, set this variable to that name.*

- To check the environmental setting parameters you have chosen:
Type `show boot*`

Chapter 5 Troubleshooting

This chapter discusses troubleshooting aspects for both hardware and software components during the UP1100 system startup.

Topics covered include:

- Video review checklist
- Status LEDs
- Beep codes
- Error recovery procedures

5.1 Hardware Startup

5.1.1 No Video Present

Use the following steps to diagnose and fix video problems:

1. Check the AC power cord connection to the AC outlet.
2. Ensure that the monitor is connected and switched on.
3. Check the voltage setting on the chassis power supply (115 Vac in the U.S.).



WARNING: *Always take appropriate electrostatic discharge safety measures when handling boards or modules.*

4. Check that the Alpha 21264A Processor fan is connected and spinning.
5. Turn the system power OFF.
6. Reseat the video card and ensure that it is connected to the monitor.
7. Reseat the DIMMs.
8. Replace the DIMMs.

5.1.2 LED Status Indicators

Two LED indicators, D24 and D25, provide diagnostic information about the UP1100, including the status of some Alpha 21264A Processor functions.

The LEDs are mounted on the lower edge of the UP1100 board below the M1535D PCI-ISA Bridge and to the right of the internal I/O connector area. Their orientation is shown in Figure 5-1.




Figure 5-1 LED Status Indicators

Use Table 5-1 to interpret the LED status information.

Table 5-1 LED Status Indicators

LED	Function	Comment
D24	PowerGOOD	Green LED ON when power to Alpha 21264A Processor is good.
D25	Reset PALcode	Red LED ON when Reset PALcode is loading.

5.1.3 Beep Code

In FSB mode, the UP1100 delivers an audible troubleshooting message during startup, referred to as a beep code. This message consists of one audible beep, followed by two audible beeps, followed by three audible beeps. It is called the 1-2-3 beep code.

If the 1-2-3 beep code is delivered, the FSB code has loaded correctly and the UP1100 is retrieving the SRM Console firmware image.

If the 1-2-3 beep code is not delivered, the FSB code did not load correctly.

5.2 Error Recovery Procedures

On the UP1100 switchpack SW1, two configuration switches with selectable settings are firmware-related. They are identified by the shaded box in Figure 5-2. You can change the configuration settings to recover from several error conditions.




Figure 5-2 Firmware Configuration Switches

5.2.1 Error Conditions

In addition to the factory default setting, there are two other configuration settings which you select based on certain error categories.

Restore Factory Defaults

Some error conditions of this type include:

- Choosing incorrect selections when configuring the SRM Console. These selections prevent the system from booting.
- Forgetting your system password.

Reload Firmware

An error condition of this type may occur during the upgrading of the SRM Console (see section 4.2.6 on page 4-13) by an improper system action. An example would be: accidentally powering off the system during this procedure.

For more information, see the FAQs on the Alpha Processor, Inc. website:

<http://www.alpha-processor.com>

5.2.2 Error Recovery Switch Settings

For these error recoveries, select the appropriate settings from Table 5-2.

Table 5-2 Switch Settings for Various Error Conditions

Error	Function	SW1 Switch:							
		1	2	3	4	5	6	7	8
Factory Default	Boot under SRM Console	On	On	Off	Off	Off	Off	On	Off
Reload Firmware	Reload SRM Console from FSB	Off	Off	Off	Off	Off	Off	On	On

5.2.3 Error Recovery Procedure

To clear the errors noted in section 5.2.1, take the following steps:

1. Power Off the system.
2. Change the SW1 switch settings according to the Reload Firmware configuration.
3. Insert the SRM firmware disk into the floppy drive.
4. Power On the system.

Wait while FSB firmware loads image into memory.

5. Run LFU. Refer to section 4.2.6 “Updating Firmware” on page 4-13 for information on running LFU.
6. Power Off the system after LFU completes.
7. Restore the SW1 switch settings to their default positions.
8. Power On the system.

Appendix A

Connectors and Pinouts

This appendix describes the connectors and pinouts used on the UP1100. Refer to Figure 2-1 in Chapter 2 for connector locations.

A.1 Power Connector Pinouts

Pinouts for J18, the ATX power connector, are shown in Table A-1. J18 is a standard Molex 39-29-9202 connector.

Table A-1 ATX Power Connector Pinouts (J18)

Pin	Signal	Pin	Signal
1	+3.3 VDC	11	+3.3 VDC
2	+3.3 VDC	12	-12 VDC
3	GND	13	GND
4	+5 VDC	14	PS_ON
5	GND	15	GND
6	+5 VDC	16	GND
7	GND	17	GND
8	P_DCOK	18	-5 VDC
9	5V SB	19	+5 VDC
10	+12 VDC	20	+5 VDC

A.2 Nonstandard Connections

Pinouts for J19, the Power LED, are shown in Table A-2. J19 is an AMP 103239-3 connector.

Table A-2 Power LED Connector Pinouts (J19)

Pin	Signal	Pin	Signal
1	GND	3	+5 VDC
2	GND		

Pinouts for J21, the VID port, are shown in Table A-3. J21 is an AMP 103240-5 connector.

Table A-3 VID Port Pinouts (J21)

Pin	Signal	Pin	Signal
1	GND	6	VID[2]
2	VID[4]	7	GND
3	GND	8	VID[1]
4	VID[3]	9	GND
5	GND	10	VID[0]

Pinouts for J22, the SM bus extender port, are shown in Table A-4. J22 is a Molex 6373-03 connector.

Table A-4 SM Bus Extender Port Connector Pinouts (J22)

Pin	Signal	Pin	Signal
1	SMbus_clock	3	SMbus_data
2	GND		

Pinouts for J23, the Power button connector, are shown in Table A-5. J23 is an AMP 103239-2 connector.

Table A-5 Power Button Connector Pinouts (J23)

Pin	Signal	Pin	Signal
1	Power_On	2	GND

Pinouts for J25, the Speaker cable, are shown in Table A-6. J25 is an AMP 103239-4 connector.

Table A-6 Speaker Cable Connector Pinouts (J25)

Pin	Signal	Pin	Signal
1	+5 VDC	3	GND
2	GND	4	PC_Speaker_Signal

Pinouts for J26, the HDD Activity LED, are shown in Table A-7. J26 is an AMP 103239-2 connector.

Table A-7 HDD Activity LED Connector Pinouts (J26)

Pin	Signal	Pin	Signal
1	HDD_Act_N	2	+5 VDC

Pinouts for J27, the Reset button connector, are shown in Table A-8. J27 is an AMP 103239-2 connector.

Table A-8 Reset Button Connector Pinouts (J27)

Pin	Signal	Pin	Signal
1	GND	2	Reset

Pinouts for J28, the Keyboard Lock Cable connector, are shown in Table A-9. J28 is an AMP 103239-2 connector.

Table A-9 Keyboard Lock Cable Connector Pinouts (J28)

Pin	Signal	Pin	Signal
1	GND	2	Key_Lock

Pinouts for J29, the System Fan connector, are shown in Table A-10. J29 is a Molex 6373-03 connector.

Table A-10 System Fan Connector Pinouts (J29)

Pin	Signal	Pin	Signal
1	GND	3	+12 VDC
2	GND		

Pinouts for J30 and J33, the CPU Fan connectors, are shown in Table A-11. J30 and J33 are Molex 6373-03 connectors.

Table A-11 CPU Fan Connectors Pinouts (J30, J33)

Pin	Signal	Pin	Signal
1	GND	3	+12 VDC
2	PFan_Sense		

Pinouts for J31, the Debug port, are shown in Table A-12. J31 is an AMP 103240-3 connector.

Table A-12 Debug Port Connector Pinouts (J31)

Pin	Signal	Pin	Signal
1	NC	4	NC
2	TxD	5	RxD
3	GND	6	NC

Pinouts for J32, the EPLD program port, are shown in Table A-13. J13 is an AMP 103240-5 connector.

Note: For specific information on the EPLD device used in the UP1100, refer to Altera Corporation's EPM7064 Programmable Logic Device Family Data Sheet.

Table A-13 EPLD Program Port Pinouts (J32)

Pin	Signal	Pin	Signal
1	TCK	6	No Connect (NC)
2	GND	7	NC
3	TDO	8	NC
4	VCC	9	TDI
5	TMS	10	GND

A.3 Standard Connectors

Industry standard parts are used for most of the connections in the UP1100. Refer to Table A-14 for a list of the connectors used and their functions.

Table A-14 UP1100 Standard Connectors

Connector	Function	Part Number
J1	AGP	Molex 71796-0008 or AMP 145263-1
J2-J4	SDRAM DIMMs	Molex 71251-0012
J5-J7	32-bit PCI bus	AMP 145154-4
J8	10/100 Mbps, RJ-45 LAN (Ethernet)	AMP 555141-1
J9	MIC In	Foxconn JA1333L-102
J10, J11	IDE drive bus	Molex 87256-4011 or AMP 103308-8
J12	FDD	Molex 87256-3411 or AMP 103308-7
J13	Parallel bus and COM1/COM2 serial line	Foxconn DM11351-Z5
J14	USB	AMP 787617-1
J15	Keyboard and mouse	Foxconn MH11067-D2 or AMP 84405-1 or 84376-1
J16	Audio In/Out	SMK LGA6507-0200
J17	CD Audio In	Molex 53014-0310

Appendix B

Support,

Products and

Documentation

B.1 Customer Support

Alpha Processor, Inc. provides assistance for their products on their web page at www.alpha-processor.com.

Alpha Original Equipment Manufacturers (OEMs) provide the following web page resources for customer support:

URL	Description
http://www.compaq.com	Contains links for the Alpha 21264A Processor CPU.
http://www.amd.com	Contains links for the AMD-751 System Controller.
http://www.acerlabs.com	Contains links for the M1535D PCI-ISA Bridge.
http://www.intel.com	Contains links for the 21143 LAN (Ethernet) controller

B.2 Supporting Products

Alpha Processor, Inc. maintains a Hardware Compatibility List on their website for components and accessories that are not included with the UP1100. Compatibility for items such as memory, power supplies, and enclosure are listed.

Point your browser to www.alpha-processor.com and check the Product Information list for Peripherals.

B.3 Alpha Products

Alpha Processor, Inc. maintains information about other Alpha products on their website. Point your browser to www.alpha-processor.com and check the Product Information list for Alpha products.

B.4 Documentation

B.4.1 Alpha Documentation

Title	Vendor
Alpha Architecture Reference Manual	Digital Press order# EQ-W938E-DP.
<i>Alpha Architecture Handbook</i>	Compaq Computer Corporation order# EC-QD2KC-TE, October, 1998.
Alpha 21264 Microprocessor Hardware Specification	Digital Press
<i>UP1100 Quick Start Installation Guide (51-0047)</i>	Alpha Processor, Inc.
UP1100 Technical Reference Manual (51-0049)	Alpha Processor, Inc.

B.4.2 Related Documentation

You can order the following associated documentation directly from the vendor.

Title	Vendor
21143 PCI/CardBus 10/100 Mb/s Ethernet LAN Controller Datasheet	Intel Corporation 2200 Mission College Blvd. Santa Clara, CA 95052-8119
<i>Accelerated Graphics Port Interface Specification Revision 2.0</i>	Intel Corporation 2200 Mission College Blvd. Santa Clara, CA 95052-8119 May, 1998
AlphaPC 264DP Technical Reference Manual	Compaq Computer Corporation order# EC-RBODA-TE.
<i>AMD-751TM System Controller Data Sheet, Revision E</i>	AMD Publication # 21910, March, 2000
Computer Architecture	John L. Hennessy and David A. Patterson, Morgan Kaufman Publishers, San Mateo, CA, 1990.
<i>EPM7064 Programmable Logic Device Family Data Sheet</i>	Altera Corporation, 101 Innovation Drive San Jose, CA 95134

Title	Vendor
ISA & EISA Theory and Operations	Edward Solari, Annabooks Bookstore (http://www.annabooks.com/index.htm), ISBN 0-929392-15-9
<i>M1535D: PCI-to-ISA Bus Bridge with Super I/O & Fast IR Data Sheet, Ver. 1.20</i>	ALI
<ul style="list-style-type: none"> • PCI Local Bus Specification, Revision 2.1 • PCI Multimedia Design Guide, Revision 1.0 • PCI System Design Guide • PCI-to-PCI Bridge Architecture Specification, Revision 0 	PCI Special Interest Group U.S. 1-800-433-5177 International 1-503-797-4207 FAX 1-503-234-6762
<ul style="list-style-type: none"> • <i>PC SDRAM Specification, Revision 1.63</i> (October, 1998) • <i>PC SDRAM Unbuffered DIMM Specification, Revision 1.0</i> (February, 1998) • <i>PC SDRAM Serial Presence Detect (SPD) Specification, Revision 1.2A</i> (December, 1997) 	Intel Corporation
<i>The Indispensable PC Hardware Book 3E</i>	Hans-Peter Messamer, Addison-Wesley Pub. Co., ISBN 0-201-87697-3
<i>Universal Serial Bus Specification, Revision 1.1</i>	USB Implementers Forum http://www.usb.org/developers/docs.html September, 1998

Index

Numerics

21143 PCI/CardBus 10/100 Mb/s Ethernet LAN
Controller Datasheet, B-3

A

Accelerated Graphics Port Interface Specification
Revision 2.0, B-3

AGP

connector, 2-2

Alpha 21264 Microprocessor Hardware
Specification, B-3

Alpha 21264A Processor
environment, 3-2

Alpha Architecture Handbook, B-3

Alpha Architecture Reference Manual, B-3

Alpha publications, B-3

Alpha System Reference Manual Console, *See*
SRM Console

AlphaPC 264DP Technical Reference Manual, B-3

AMD-751 System Controller

system controller, 1-1

AMD-751 System Controller Data Sheet,
Revision D, B-3

audio

connector, in/out, 2-3

B

Bcache, 1-1

beep codes, 5-2

troubleshooting, 5-2

board

UP1100 board layout, 2-2

boot command, SRM Console, 4-12

C

cache

configuration, size selection, 2-6

chipsets, 1-1

commands, SRM Console, 4-3

compact disk drive

connector, 2-3

component list, 2-2

UP1100, 2-2

Computer Architecture, B-3

configuration

board settings, 2-5, 5-3

cache size selection, 2-6

displaying system, 4-3, 4-7

firmware selection, 2-5

connectors

component list, 2-2

nonstandard connections

CPU fan, A-5

debug port, A-5

EPLD program port, A-5

HDD activity LED, A-4

keyboard lock, A-4

power button, A-3

power LED, A-2

reset button, A-4

SM bus extender port, A-3

speaker cable, A-3

system fan, A-4

VID port, A-2

power

ATX connector, A-2

standard connectors, A-6

system support, 3-6

console, *See* SRM Console

conventions, xi

CPU, 1-1

CPU fan

connections, A-5

customer support, B-2

Alpha products, B-2

hardware compatibility list, B-2

D

date

command, 4-11

debug port
 connections, A-5
 definitions, conventions, and references, xi
 device naming conventions, SRM Console, 4-10
 diagnostic information, 5-1
 DIMM
 connectors
 slot 0, 2-2
 slot 1, 2-2
 slot 2, 2-2
 displaying system configuration, 4-3, 4-7

E

EMI certification, 3-3
 enclosure
 requirements, 3-5
 environment
 EMI, 3-3
 requirements, 3-3
 operating temperature, 3-3
 storage temperature, 3-3
 safety, 3-3
 UP1100 specification, 3-2
 environment variable
 auto_action, 4-17
 boot_osflags, 4-18
 bootdef_dev, 4-18
 com*_baud, 4-19
 console, 4-19
 ew*0_mode, 4-20
 ew*0_protocols, 4-20
 kbd_hardware_type, 4-21
 language, 4-21
 os_type, 4-22
 password, 4-22
 pci_parity, 4-23
 pk*0_fast, 4-23
 pk*0_host_id, 4-23
 pk*0_soft_term, 4-24
 set envvar, 4-15
 show config, 4-7
 show cpu, 4-8
 show envvar, 4-16
 show memory, 4-11
 show pal, 4-11
 show version, 4-11

summary, SRM Console, 4-16
 tt_allow_login, 4-25
 using SRM Console, 4-15
 EPLD program port
 connections, A-5
EPM7064 Programmable Logic Device Family Data Sheet, B-3
 error recovery procedures, 5-3

F

fan
 connector
 CPU, 2-3
 system, 2-3
 FDD
 connector, 2-3
 features
 cache, 1-1
 chipsets, 1-1
 CPU, 1-1
 firmware, 1-2
 I/O slots, 1-2
 main memory, 1-1
 on-board I/O, 1-2
 physical form factor, 1-1
 power, 1-2
 system bus, 1-2
 UP1100, 1-1
 firmware, 1-2
 configuration, 2-5
 FSB
 description, 4-1
 details, 4-26
 functional block diagram, 1-3

G

guidelines, memory, 2-4

H

hardware compatibility
 customer support, B-2
 memory, 2-4
 HDD activity LED
 connections, A-4

help, SRM Console command, 4-25

I

I/O slots, 1-2

IDE

connectors

primary, 2-3

secondary, 2-3

installing Linux, 4-26

ISA & EISA Theory and Operations, B-4

K

keyboard

connector, 2-3

keyboard lock

connections, A-4

L

LED Status indicators, 5-2

troubleshooting, 5-1

lfu, SRM Console command, 4-13

Linux, 4-2

boot options, 4-27

environmental variables, 4-28, 4-31

installing, 4-26

Prerequisites, 4-27

prerequisites, 4-30

Setting OS Type, 4-27

setting OS type, 4-30

starting, 4-29

system requirements, 4-27

Loadable Firmware Update (LFU) Utility

See lfu

M

*M1535D PCI-to-ISA Bus Bridge with Super I/O
& Fast IR Data Sheet*, B-4

main memory, 1-1

memory

configuration, 2-5

description, 2-3

typical, 2-5

guidelines, 2-4

microphone

connector, in, 2-3

mouse

connector, 2-3

N

network

connector, 2-2

no video present, troubleshooting, 5-1

O

on-board

connectors, 2-1

I/O, 1-2

P

parallel port

connector, 2-3

*PC SDRAM Serial Presence Detect (SPD)
Specification, Revision 1.2A*, B-4

PC SDRAM Specification, Revision 1.63, B-4

*PC SDRAM Unbuffered DIMM Specification,
Revision 1.0*, B-4

PCI

connectors

slot 0, 2-2

slot 1, 2-2

slot 2, 2-2

PCI Local Bus Specification, B-4

PCI Multimedia Design Guide, B-4

PCI System Design Guide, B-4

PCI-to-PCI Bridge Architecture Specification, B-4

physical form factor, 1-1

physical parameters

UP1100 board, 3-5

power

button, connections, A-3

connector, 1-2, 3-2

ATX, 2-3

ATX connector pinout, A-2

consumption, 1-2

UP1100, 3-1

estimated maximum power

UP1100, 3-1

- LED
 - connections, A-2
 - power button connector, 2-3
- product safety
 - compliance, 3-3
- R
- related publications, B-3
- reset
 - button, connections, A-4
 - button, connector, 2-3
- Reset PALcode
 - description, 4-1
- S
- set envar, 4-15
- show config, 4-7
- show cpu, 4-8
- show device, 4-9
- show envar, 4-16
- show memory, 4-11
- show pal, 4-11
- show version, 4-11
- SM bus extender port
 - connections, A-3
- speaker
 - connector, 2-3
- speaker cable
 - connections, A-3
- SRM Console, 4-2
 - booting, 4-12
 - command examples, 4-3, 4-7
 - command summary, 4-3
 - device naming conventions, 4-10
 - environment variable
 - summary, 4-16
 - using, 4-15
 - invoking, 4-2
 - special characters, 4-6
 - updating firmware, 4-13
- SRM Console commands
 - boot, 4-12
 - date, 4-11
 - environment variable
 - auto_action, 4-17
 - boot_osflags, 4-18
 - bootdef_dev, 4-18
 - com*_baud, 4-19
 - console, 4-19
 - ew*0_mode, 4-20
 - ew*0_protocols, 4-20
 - kbd_hardware_type, 4-21
 - language, 4-21
 - os_type, 4-22
 - password, 4-22
 - pci_parity, 4-23
 - pk*0_fast, 4-23
 - pk*0_host_id, 4-23
 - pk*0_soft_term, 4-24
 - set envar, 4-15
 - show config, 4-7
 - show cpu, 4-8
 - show device, 4-9
 - show envar, 4-16
 - show memory, 4-11
 - show pal, 4-11
 - show version, 4-11
 - tt_allow_login, 4-25
 - environment variable summary, 4-16
 - help, 4-25
 - lfu, 4-13
 - syntax, 4-5
- starting Linux operating system, 4-29
- syntax, SRM Console command, 4-5
- system
 - bus, 1-2
 - system configuration
 - commands to display, 4-3, 4-7
 - system controller
 - AMD-751 System Controller, 1-1
 - chipsets, 1-1
 - system date
 - command, 4-11
 - setting and displaying, 4-11
 - system fan
 - connections, A-4
 - system management bus
 - extender port, 2-3
 - system requirements, Linux, 4-27
 - system time
 - command, 4-11

T

The Indispensable PC Hardware Book 3E, B-4

thermal

maximum case temperatures, 3-5

sensitive components, 3-3

time

command, *See* date

troubleshooting, 5-1

beep codes, 5-2

LED Status indicators, 5-1

no video present, 5-1

U

Universal Serial Bus Specification,

Revision 1.1, B-4

Unix, *See* Linux

UP1100

board

layout, 2-2

physical parameters, 3-5

component list, 2-2

components, 1-1

enclosure requirements, 3-5

estimated maximum power use, 3-1

functional block diagram, 1-3

maximum case temperatures, 3-5

memory configurations, supported, 2-5

on-board connectors, 2-1

power

connector, 3-2

power consumption, 3-1

product features, 1-1

system components, 1-2

thermal considerations, 3-3

UP1100 Quick Start Installation Guide, B-3

UP1100 Technical Reference Manual, B-3

updating SRM Console firmware, 4-13

USB ports

connector, 2-3

using SRM Console environment variables, 4-15

V

VID port

connections, A-2



Publication Evaluation Form

Please help us develop better manuals by sending us your comments on our publications. You can submit your comments on-line, send us E-mail, or print this evaluation form, complete it, and return it to:

Alpha Processor, Inc.
130C Baker Street Extension
Concord, MA 01742
Phone: 978.318.1100 FAX: 978.371.3177
E-mail: customer.support@alpha-processor.com

Contents and Organization

Publication Name: I Agree Disagree that the information I need is in this publication.

I Agree Disagree that it is easy to locate information in this publication.

I Agree Disagree that I am confident of the accuracy of this publication.

What I liked least about this publication is:

What I like most about this publication is:

Information not provided in this publication that I would find useful is:

This publication would be easier to use if:

Other comments:

User Information (Optional)

Name:	<input type="text"/>	Company:	<input type="text"/>
Street Address:	<input type="text"/>	Phone:	<input type="text"/>
City, State, Zip:	<input type="text"/>	E-mail:	<input type="text"/>