

INSTALLATION INSTRUCTIONS

MSD Billet Crank Trigger Distributors **Ford V8 Engines 289/302, PN 8379** **351W, PN 8378** **351C, 460, PN 8377** **Sheet Metal Intakes 351C, 460W, PN 8569** **460 Bob Glidden Block, PN 85691**

ONLINE PRODUCT REGISTRATION: Register your MSD product online. Registering your product will help if there is ever a warranty issue with your product and helps the MSD R&D team create new products that you ask for! Go to www.msperformance.com/registration.

Note: Read these instructions completely before attempting the installation.

Parts Included:

1 - MSD Distributor Assembly	1 - Gasket
2 - O-Rings	1 - Rotor Phasing Tech Brief
1 - Tube of Gear Lubricant	2 - 1.5" Self Tapping Screws
1 - Wire Retainer	

Replacement Parts:

Rotor and Base, PN 8457
Cap, PN 8408

WARNING: During installation, disconnect the battery cables. When disconnecting the cables, always remove the Negative cable first and install it last.

Note: A Crank Trigger must be used with this distributor.
An MSD Billet Hold-Down Clamp, PN 8010, is recommended.

INSTALLING THE DISTRIBUTOR

1. Position the number one cylinder at the desired timing.
2. Apply a liberal amount of the supplied lubricant to the distributor gear.
3. Install the distributor making sure that it seats fully. If the distributor will not fully seat, you may need to rotate the oil pump shaft.
4. Rotate the distributor until the rotor aligns with the number one terminal of the distributor cap.
5. Position and tighten the hold-down clamp onto the distributor.
6. Install the distributor cap and clamp it in place.
7. Install the spark plug wires.
8. It is recommended to check and confirm correct rotor phasing. The supplied tech brief explains rotor phasing in detail.
9. An optional wire retainer is supplied to secure the wires in place. Align the mounting bosses and use the two self-tapping screws to hold the retainer in place.

