Features

- Audio Processor
 - Proprietary Digital Signal Processor
 - MP3 and WMA Decoders
 - WAV PCM and ADPCM Decoder/Coder with AGC
 - JPEG decoder
 - Video Animation (MTV up to 16fps)
- Audio Codec
 - 16-bit Stereo D/A Converters⁽³⁾
 - Headphone Amplifier with Analog Volume Control⁽³⁾
 - Microphone Pre-Amplifier with Bias Control
 - 16-bit Mono A/D Converter: Microphone or Line Inputs Recording
 - Stereo Lines Input for FM Playback or Mono Recording
 - 3-band EQ and Bass Boost and 3D Sound Effects
 - Graphical EQ
- Digital Audio DAC Interface
 - PCM / I²S Format Compatible
- USB Rev 2.0 Controller
 - 7 Endpoints, Multiple Enumeration
 - High Speed Mode (480 Mbps)
 - Full Speed Mode (12 Mbps)
 - On The Go Full Speed Mode
- File Management
 - Fat 12, 16, 32 Management
 - Multiple Drive Management: Nand Flash, Card, U-Disk...
 - Multiple Folders and Sub-Folders (user defined)
 - Multiple File Read and Write
 - Playlist and Lyrics Support
- Data Flow Controller
 - 16-bit Multimedia Bus with 2 DMA Channels for high speed transfer with USB
- Nand Flash Controller
 - Multiple Nand as 1 Drive, Support All Page Size
 - Read up to 10MB/s, Write up to 8MB/s
 - Built-in ECC and Hardware Write Protection
- MultiMediaCard[®] Controller
 - MultiMediaCard 1-bit / 4-bits Modes (V4 compatible)
 - Secure Digital Card 1-bit / 4-bit Modes
- Man Machine Interface
 - Glueless Generic LCD Interface
 - Keyboard Interface
 - FM Tuner Input and Control including RDS
 - PSI I80 Slave Interface (EBI Compatible) up to 6Mbytes/s
 - SPI Master and Slave Modes
 - Full Duplex UART with Baud Rate Generator up to 6 Mbit/s (Rx, Tx, RTS, CTS)
- Control Processor
 - Enhanced 8-bit MCU C51 Core (F_{MAX} = 24 MHz)
 - 64K Bytes of Internal RAM for application code and data
 - Boot ROM Memory: Secured Nand Flash Boot Strap (standard), USB Boot Loader
 - Two 16-bit Timers/Counters: Hardware Watchdog Timer
 - In-System and In-Application Programming
- Power Management
 - 1.8V 40 mA Single AAA or AA Battery Powered⁽⁴⁾
 - Direct USB V_{BUS} Supply
 - 3V or 1.8V 50 mA Regulator Output
 - Battery Voltage Monitoring
 - Power-on Reset, Idle, Power-Down, Power-Off Modes
 - Software Programmable MCU Clock
- Operating Conditions
 - Supply 1.8V to 5V for all Product range, plus 0.9V to 1.8V⁽⁴⁾





Single-Chip Digital Audio Decoder -Encoder with USB 2.0 Interface

AT85C51SND3B

Preliminary

7632D-MP3-01/07



- 25 mA Typical Operating at 25 °C (estimation to be confirmed)
- Temperature Range: -40 ℃ to +85 ℃

Packages

- LQFP100, BGA100, Dice

- Notes: 1. See Ordering Information
 - 2. AT85C51SND3B1 & AT85C51SND3B2 only
 - 3. AT85C51SND3B2 only

Description

Digital Music Players, Mobile Phones need ready to use low-cost solutions for very fast time to market. The AT85C51SND3B with associated firmware embeds in a single chip all features, hardware and software, for Digital Music Players, Mobile Phones and Industrial or Toys applications: MP3 decoder, WMA decoder, Display interface, serial interface, parallel interface, USB high speed and USB host.

Close to a plug and play solution for most applications, the AT85C51SND3B drastically reduces system development for the best time to market. The AT85C51SND3B handles full file system management with Nand Flash and Flash Cards, including full detection and operation of a thumb drive. The AT85C51SND3Bx is used either as a master controller, or as a slave controller interfacing easily with most of the base-band or host processors available on the market.

The AT85C51SND3B includes Power Management with: 5V USB V_{BUS} direct supply, 2.7V to 3.6V supply, 1.8V supply or alkaline battery supply (0.9V to 1.8V). External Nand Flash or Flash Card can be supplied by the AT85C51SND3B at 1.8V or 3V.

The AT85C51SND3B supports many applications including: mobile phones, music players, portable navigation, car audio, music in shopping centers, applications including MMC/SD Flash Cards in Industrial applications.

To facilitate custom applications with the AT85C51SND3B, a development kit AT85DVK-07 and a reference design AT85RFD-07 are available with hardware and firmware database.

Key Features

- Firmware to support
 - MP3
 - WMA
 - ADPCM/WAV voice or line recording
 - JPEG Decoder
- Audio Codec
 - Internal DAC
 - FM inputs
- Memory Support
 - Up to 4x Nand-Flash
 - SD/MMC cards
- USB
 - High Speed, Full Speed
 - OTG (reduced Host)





Block Diagram





Notes: 1. AT85C51SND3B2 only

2. AT85C51SND3B1 & AT85C51SND3B2 only

Application Information

٠

The AT85C51SND3B derivatives allow design of 2 typical applications which differentiate by the power supply voltage:

- The Very Low Voltage System The player operates at 1.8V and allows very low power consumption.
- The Low Voltage System The player operates at 3V and allows low power consumption.

Figure 2. Typical Low Voltage 3V Application







Pin Description

Pinouts

Figure 3. AT85C51SND3B 100-pin QFP Package



Notes: 1. Leave these pins unconnected for AT85C51SND3B0 & AT85C51SND3B1 products



Figure 4. AT85C51SND3B 100-pin BGA Package (no ADC)





Signals Description

System

Table 1. System Signal Description

Signal Name	Туре	Description	Alternate Function
RST	I/O	Reset Input Holding this pin low for 64 oscillator periods while the oscillator is running resets the device. The Port pins are driven to their reset conditions when a voltage lower than V_{IL} is applied, whether or not the oscillator is running. This pin has an internal pull-up resistor (R_{RST}) which allows the device to be reset by connecting a capacitor between this pin and V_{SS} . Asserting RST when the chip is in Idle mode or Power-Down mode returns the chip to normal operation. In order to reset external components connected to the \overline{RST} line a low level 96-clock period pulse is generated when the watchdog timer reaches its time-out period.	-
ISP	I	In System Programming Assert this pin during reset phase to enter the in system programming mode.	OCDT

Table 2. Ports Signal Description

Signal Name	Туре	Description	Alternate Function
P0.7:0	I/O	Port 0 P0 is an 8-bit bidirectional I/O port with internal pull-ups.	LD7:0
P1.7:0	I/O	Port 1 P1 is an 8-bit bidirectional I/O port with internal pull-ups.	KIN3:0
P2.7:0	I/O	Port 2 P2 is an 8-bit bidirectional I/O port with internal pull-ups.	SDINS SDLCK SDCMD SDCLK SDDAT3:0
P3.4:0 P3.7:6	I/O	Port 3 P3 is a 7-bit bidirectional I/O port with internal pull-ups.	RXD MISO TXD MOSI INT0 RTS SCK INT1 CTS SS T0 UVCON UID

Signal Name	Туре	Description	Alternate Function
P4.6:0	I/O	Port 4 P4 is a 7-bit bidirectional I/O port with internal pull-ups.	OCLK DCLK DDAT DSEL NFCE1/SMLCK NFCE2/SMINS NFCE3/SMCE
P5.3:0	I/O	Port 5 P5 is a 4-bit bidirectional I/O port with internal pull-ups.	LRD/LDE SDR LCS SCS LA0/LRS SA0 LWR/LRW SWR

Table 3. Timer 0 and Timer 1 Signal Description

Signal Name	Туре	Description	Alternate Function
ĪNT0	I	Timer 0 Gate Input INT0 serves as external run control for timer 0, when selected by GATE0 bit in TCON register. External Interrupt 0 INT0 input sets IE0 in the TCON register. If bit IT0 in this register is set.	P3.2 RTS SCK
		bit IE0 is set by a falling edge on INTO. If bit IT0 is cleared, bit IE0 is set by a low level on INTO.	UOIX
INT1	I	Timer 1 Gate InputINT1 serves as external run control for timer 1, when selected byGATE1 bit in TCON register.External Interrupt 1INT1 input sets IE1 in the TCON register. If bit IT1 in this register is set,bit IE1 is set by a falling edge on INT1. If bit IT1 is cleared, bit IE1 is setby a low level on INT1.	P3.3 CTS SS
то	I	Timer 0 External Clock Input When timer 0 operates as a counter, a falling edge on the T0 pin increments the count.	P3.4





Clock Controller

Table 4. Clock Signal Description

Signal Name	Туре	Description	Alternate Function
X1	I	Input of the on-chip inverting oscillator amplifier To use the internal oscillator, a crystal/resonator circuit is connected to this pin. If an external oscillator is used, its output is connected to this pin. X1 is the clock source for internal timing.	-
X2	0	Output of the on-chip inverting oscillator amplifier To use the internal oscillator, a crystal/resonator circuit is connected to this pin. If an external oscillator is used, leave X2 unconnected.	-
UPVDD	PWR	USB PLL Supply voltage Connect this pin to LVDD pin.	-
UPVSS	GND	USB PLL Circuit Ground Connect this pin to LVSS pin.	-
APVDD	PWR	Audio PLL / Oscillator Supply voltage Connect this pin to LVDD pin.	-
APVSS	GND	Audio PLL / Oscillator Circuit Ground Connect this pin to LVSS pin.	-

Memory Controllers

Table 5. Secure Digital Card / MutiMediaCard Controller Signal Description

Signal Name	Туре	Description	Alternate Function
SDCLK	0	SD/MMC Clock Data or command clock transfer.	P2.3
SDCMD	I/O	SD/MMC Command Line Bidirectional command line used for commands and responses transfer.	P2.2
SDDAT3:0	I/O	SD/MMC Data Lines Bidirectional data lines. In 1-bit mode configuration SDDAT0 is the DAT signal and SDDAT3:1 are not used and can be reused as I/O ports.	P2.7:4
SDINS	I	SD/MMC Card Insertion SignalSDINSSDINSis the card presence signal. A low level on this input indicatesthe card is present in its slot.Note:This signal is generated by the SD/MMC card connector.	P2.0
SDLCK	I	SD Card Write Lock Signal SDLCK is the SD Card write protected input. A low level on this pin indicates the card is write protected. Note: This signal is generated by the SD/MMC card connector.	P2.1

Table 6. Nand Flash / SmartMedia Card Controller Signal Description

Signal Name	Туре	Description	Alternate Function
NFD7:0	I/O	Memory Data Bus 8-bit bidirectional data bus.	-
NFALE	0	Address Latch Enable Signal Asserted high during address write cycle.	-

Signal Name	Туре	Description	Alternate Function
NFCLE	0	Command Latch Enable Signal Asserted high during command write cycle.	-
NFRE	0	Read Enable Signal Read signal asserted low during NF/SMC read operation.	-
NFWE	0	Write Enable Signal Write signal asserted low during NF/SMC write operation.	-
NFCE0	0	Nand Flash 0 Chip Enable NFCE0 is active low and is asserted by the nand flash controller each time it makes access to the device 0.	-
NFCE1	0	Nand Flash 1 Chip Enable NFCE1 is active low and is asserted by the nand flash controller each time it makes access to the selected device.	
SMLCK	I	SmartMediaCard/xD-Picture Card Write Lock Signal SMLCK is the card write protected input. A low level on this pin indicates the card is write protected. Note: When used as SMLCK input, pad has internal pull-up.	P4.4
NFCE2	0	Nand Flash 2 Chip Enable NFCE2 is active low and is asserted by the nand flash controller each time it makes access to the selected device.	
SMINS	Ι	SmartMediaCard/xD-Picture Card Insertion Signal SMINS is the card presence signal. A low level on this input indicates the card is present in its slot. Note: When used as SMINS input, pad has internal pull-up.	P4.5
NFCE3	0	Nand Flash 3 Chip EnableNFCE3 is active low and is asserted by the nand flash controller each time it makes access to the selected device.SmartMediaCard/xD-Picture Card Chip EnableSMCE is active low and is asserted by the nand flash controller each time it makes access to the card.	P4.6
NFWP	0	Write Protect Signal NFWP is the Nand Flash / SmartMediaCard/xD-Picture Card write protect signal. This signal is active low and is set to low during reset in order to protect the memory against parasitic writes.	-

USB Controller

Table 7. USB Controller Signal Description

Signal Name	Туре	Description	Alternate Function
DPF	I/O	USB Full Speed Positive Data Upstream Port	-
DMF	I/O	USB Full Speed Minus Data Upstream Port	-
DPH	I/O	USB High Speed Plus Data Upstream Port	-
DMH	I/O	USB High Speed Minus Data Upstream Port	-
UVCON	0	USB VBUS Control line UVCON is used to control the external VBUS power supply ON or OFF. Note: This output is requested for OTG mode.	P3.6





Signal Name	Туре	Description	Alternate Function
UID	I	USB OTG Identifier Input This pin monitors the function of the OTG device. Note: This input is requested for OTG mode.	P3.7
UVCC	PWR	USB Supply Voltage Connect this pin to USB V _{BUS} power line.	-
ULVDD	PWR	USB Pad Low Voltage Connect this pin to LVDD pin.	-
UHVDD	PWR	USB Pad High Voltage Connect this pin to HVDD pin.	-
UVSS	GND	USB Ground	-
UBIAS	0	USB Bias Connect this pin to external resistor and capacitor.	

Audio Processor

Table 8. I2S Output Description

Signal Name	Туре	Description	Alternate Function
OCLK	0	Over-sampling Clock Line	P4.0
DCLK	0	Data Clock Line	P4.1
DDAT	0	Data Lines	P4.2
DSEL	0	Data Channel Selection Line	P4.3

Table 9. Audio Codec Description

Signal Name	Туре	Description	Alternate Function
LINR	I	Right Channel Analog Input	-
LINL	I	Left Channel Analog Input	-
MICIN	I	Electret Microphone Analog Input	-
MICBIAS	0	Electret Microphone Bias Output	-
OUTR	0	Right Channel Output Do not connect on AT85C51SND3B0 product	-
OUTL	0	Left Channel Output Do not connect on AT85C51SND3B0 product	-
AVCM	I	Analog Common Mode Voltage Connect this pin to external decoupling capacitor.	-
AREF	0	Analog Reference Voltage Connect this pin to external decoupling capacitor.	-
AVDD1	PWR	Analog Power Supply 1 Connect this pin to LVDD pin.	-
AVSS1	GND	Analog Ground 1 Connect this pin to LVSS pin.	-

Signal Name	Туре	Description	Alternate Function
AVDD2	PWR	Analog Power Supply 2 Low Voltage system: connect this pin to LVDD pin. High voltage system: connect this pin to external +3V power supply.	-
AVSS2	GND	Analog Ground 2 Low Voltage system: connect this pin to LVSS pin. High voltage system: connect this pin to external +3V ground.	-

Parallel Slave Interface

Table 10. PSI Signal Description

Signal Name	Туре	Description	Alternate Function
SD7:0	I/O	Slave Data Bus 8-bit bidirectional data bus.	P0.7:0 LD7:0
SRD	I	Slave Read Signal Read signal asserted low during external host read operation.	P5.0 LRD/LDE
SWR	I	Slave Write Signal Write signal asserted low during external host write operation.	P5.3 LWR/LRW
SCS	I	Slave Chip Select Select signal asserted low during external host read or write operation.	P5.1 LCS
SA0	I	Slave Address Bit 0 Address signal asserted during external host read or write operation.	P5.2 LA0/LRS

Serial Interfaces

Table 11. SPI Controller Signal Description

Signal Name	Туре	Description	Alternate Function
MISO	I/O	SPI Master Input Slave Output Data Line When in master mode, MISO receives data from the slave peripheral. When in slave mode, MISO outputs data to the master controller.	P3.0 RXD
MOSI	I/O	SPI Master Output Slave Input Data Line When in master mode, MOSI outputs data to the slave peripheral. When in slave mode, MOSI receives data from the master controller.	P3.1 TXD
SCK	I/O	SPI Clock Line When in master mode, SCK outputs clock to the slave peripheral. When in slave mode, SCK receives clock from the master controller.	P3.2 INTO RTS
SS	I	SPI Slave Select Line When in controlled slave mode, \overline{SS} enables the slave mode.	P3.3 INT1 CTS

Table 12. SIO Signal Description

Signal Name	Туре	Description	Alternate Function
RXD	I/O	Receive Serial Data RXD sends and receives data in serial I/O mode 0 and receives data in serial I/O modes 1, 2 and 3.	P3.0 MISO





Signal Name	Туре	Description	Alternate Function
TXD	0	Transmit Serial Data TXD outputs the shift clock in serial I/O mode 0 and transmits data in serial I/O modes 1, 2 and 3.	P3.1 MOSI
RTS	0	Request To Send Hardware Handshake Line Asserted low by hardware when SIO is ready to receive data.	P3.2 INT0 SCK
CTS	I	Clear To Send Hardware Handshake Line Asserted low by external hardware when SIO is allowed to send data.	P3.3 INT1 SS

MMI Interface

Table 13. Keypad Controller Signal Description

Signal Name	Туре	Description	Alternate Function
KIN3:0	I	Keypad Input lines Holding one of these pins high or low for 24 oscillator periods triggers a keypad interrupt.	P1.3:0

Table 14. LCD Interface Signal Description

Signal Name	Туре	Description	Alternate Function
LD7:0	I/O	Display Data Bus 8-bit bidirectional data bus.	P0.7:0 SD7:0
LRD/LDE	0	Read Signal/Enable Signal8080:Read signal asserted low during display read access.6800:Enable signal asserted high during display access.	P5.0 SRD
LWR/LRW	0	Write Signal/Read Write Signal8080:Write signal asserted low during display write access.6800:Read/Write signal asserted low/high during display read/write access	P5.3 SWR
LCS	0	Display Chip Select Select signal asserted low during display access.	P5.1 SCS
LA0/LRS	0	Display Address Bit 0/Register Select Address signal asserted during display access.	P5.2 SA0

Power Management

Table 15. Power Signal Description

Signal Name	Туре	Description	Alternate Function
DCPWR	I	DC-DC Power ON Input Connect $\overline{\text{DCPWR}}$ to V _{SS} to start the DC-DC converter.	-
DCLI	PWR	C-DC Inductance Input onnect low ESR inductance to DCLI and BVDD.	
BVDD	PWR	Battery Supply Voltage Connect this pin to the positive pin of the battery.	-

Signal Name	Туре	Description	Alternate Function
BVSS	GND	Battery Ground Connect this pin to the negative pin of the battery.	-
LVDD	PWR	Low Voltage DC-DC Power Supply output This pin outputs +1.8V typ. from internal DC-DC (battery powered).	-
RLVDD	PWR	Low Voltage Regulator Power Supply Output This pin outputs +1.8V typ. from internal regulator (USB powered or +3V external power supply). Connect this pin to LVDD incase of internal DC-DC usage.	-
HVDD	PWR	High Voltage Power Supply This pin outputs +3V typ. from internal regulator (USB powered). Connect this pin to +3V external power supply.	-
VSS	GND	Power Ground Connect this pin to the system ground.	-
CVSS	GND	Core Ground Connect this pin to VSS pin.	-
IOVDD	PWR	Input/Output Supply voltage Connect this pin to LVDD or HVDD pin.	-
IOVSS	GND	Input/Output Circuit Ground Connect this pin to VSS pin.	-

OCD Interface

Table 16. OCD Signal Description

Signal Name	Туре	Description	Alternate Function
OCDR	I	On Chip Debug Receive Input OCDR receives data.	-
OCDT	I/O	On Chip Debug Transmit Output OCDT transmits data.	ISP





Internal Pin Structure

 Table 17.
 Detailed Internal Pin Structure



Circuit ⁽¹⁾	Туре	Pins
	Output	SDCLK SCK NFCE3:0 NFCLE NFWE NFWE NFWE SMCE DSEL DDAT DCLK OCLK LWR/LE LA0/LRS LRD/LRW LCS UVCON TXD
	Input/Output	DPF DMF
	Input/Output	DPH DMH
	Input	DCPWR ⁽²⁾
	-	DCLI ⁽²⁾







- Notes: 1. For information on resistor value, input/output levels, and drive capability, refer to Section "DC Characteristics", page 242.
 - 2. AT85C51SND3B2 only
 - 3. AT85C51SND3B1 & AT85C51SND3B2 only

Power Management

The Power Management of AT85C51SND3B dervatives implements all the internal power circuitry (regulators, links...) as well as power failure detector and reset circuitry.

Power Supply The AT85C51SND3B2 embeds the regulators and a DC to DC step-up convertor to be able to operate from either USB power supply (5V nominal) or from a single cell battery such as AAA battery.

The AT85C51SND3B0 and AT85C51SND3B1 embed the regulators to be able to operate from either USB power supply (5V nominal) or from an external 3 volts supply.





Note: 1. External connection mandatory when 1.8V DC-DC is used.

Regulators

The high voltage regulator supplies power to the external devices through HVDD power pin. Its nominal voltage output is 3V.

The low voltage regulator supplies power to the internal device and external devices through RLVDD power pin. Its nominal voltage output is 1.8V.

Figure 6 shows how to connect external components, capacitors value along with power characteristics are specified in the section "DC characteristics".





Schematic

Figure 6. Regulator Connection



Note: Depending on power supply scheme, C_{LV} may replace C_{DC} capacitor (see Figure 8).

Low Voltage DC-DC in
AT85C51SND3B2The low voltage output DC-DC converter supplies power to the internal device and
external devices through LVDD power pin. It operates from a single AAA battery. Its
nominal voltage output is 1.8V.

 DC-DC Start-Up
 DC-DC start-up is done by asserting the DCPWR input until the voltage reaches its nominal value (see Section "Power Fail Detector") and firmware starts execution and sets the DCEN bit in PCON to maintain the DC-DC enabled. DCPWR input can then be released. As shown in Figure 8 DCPWR input is asserted by pressing a key connected to BVSS.

Figure 7. DC-DC Start-Up Phase



DC-DC Shut-Down

DC-DC shut-down is done by two different ways:

- Clearing the DCEN bit while DCPWR pin is de-asserted
- Detecting the presence of an internal or external 3V supply, e.g. when the device is connected to USB, DC-DC is disabled to save battery power⁽¹⁾.
- Note: 1. If DCEN bit is left set, the DC-DC will restart as soon as the USB power supply disappears.

DC-DC Connection Figure 8 shows how to connect external components, inductance and components value along with power characteristics are specified in the section "DC characteristics".





Note:

Depending on power supply scheme, C_{DC1} may replace C_{LV} capacitor (see Figure 6).

20 AT85C51SND3B

Battery Voltage Monitor

The battery voltage monitor is a 5-bit / 50 mV resolution A to D converter with fixed conversion range as detailed in Table 18.

Table 18. Battery Voltage Value

VB4:0	Battery Voltage (V)
00000	[0.9 - 0.95[
00001	[0.95 - 1.0[
00010	[1.0 - 1.05[
01110	[1.6 - 1.65]
01111	[1.65 - 1.7[
10000	[1.7 - 1.75[

Conversion Management The battery voltage monitor is turned on by setting the VBPEN and VBCEN bits in PCON (see Table 20). VBPEN bit is set first and VBCEN bit is set 1 ms later. An additional delay of 16 cycles is required before lauching any conversion. Launching a conversion is done by setting VBEN bit in VBAT (see Table 22). VBEN is automatically cleared at the end of the conversion which takes 34 clock periods. At this step two cases occur:

- Voltage is valid (inside conversion range) VBERR is cleared and conversion value is set in VB4:0 according to Table 18.
- Voltage is invalid (out of conversion range) VBERR is set and value reported by VB4:0 is indeterminate.

Power Reduction Mode Two power reduction modes are implemented in the AT85C51SND3B: the Idle mode and the Power-down mode. These modes are detailed in the following sections. In addition to these power reduction modes, the clocks of the core and peripherals can be dynamically divided by 2 using the X2 mode as detailed in Section "X2 Feature", page 31.

Lock Mode

In order to allow firmware to efficiently enter in idle mode and not to lose any events that should come from one or more interrupts, power reduction modes entry are conditioned to an hardware bit: PMLCK in PCON.

PMLCK is set by software in each ISR that needs to report an event to the system and thus disables entry in power reduction mode and allows immediate processing of this event. It is cleared by software after exiting power reduction mode.

As shown in Figure 9, when power reduction modes are disabled by setting PMLCK, IDL and PD bits in PCON can not be set and idle or power down modes are not entered.

Figure 9. Power Reduction Controller Block Diagram





AMEL

Idle Mode	Idle mo progran the per page 3 counter The cor	de is a power reduction mode that reduces the power consumption. In this mode, n execution halts. Idle mode freezes the clock to the CPU at known states while ipherals continue to be clocked (refer to Section "System Clock Generator", 0). The CPU status before entering Idle mode is preserved, i.e., the program and program status word register retain their data for the duration of Idle mode. ntents of the SFRs and RAM are also retained.
Entering Idle Mode	To ente cleared sets ID	er Idle mode, the user must set the IDL bit in PCON register while PMLCK is . The AT85C51SND3B enters Idle mode upon execution of the instruction that L bit. The instruction that sets IDL bit is the last instruction executed.
	Note:	If IDL bit and PD bit are set simultaneously, the AT85C51SND3B enter Power-down mode. Then it does not go in Idle mode when exiting Power-down mode.
Exiting Idle Mode	There a	are 2 ways to exit Idle mode:
	1. Ge	nerate an enabled interrupt.
	_	Hardware clears IDL bit in PCON register which restores the clock to the CPU. Execution resumes with the interrupt service routine. Upon completion of the interrupt service routine, program execution resumes with the instruction immediately following the instruction that activated Idle mode. The general-purpose flags (GF1 and GF0 in PCON register) may be used to indicate whether an interrupt occurred during normal operation or during Idle mode. When Idle mode is exited by an interrupt, the interrupt service routine may examine GF1 and GF0.
	2. Ge	nerate a reset.
	-	A logic high on the RST pin clears IDL bit in PCON register directly and asynchronously. This restores the clock to the CPU. Program execution momentarily resumes with the instruction immediately following the instruction that activated the Idle mode and may continue for a number of clock cycles before the internal reset algorithm takes control. Reset initializes the AT85C51SND3B and vectors the CPU to address 0000h.
	Note:	During the time that execution resumes, the internal RAM cannot be accessed; however, it is possible for the Port pins to be accessed. To avoid unexpected outputs at the Port pins, the instruction immediately following the instruction that activated Idle mode should not write to a Port pin or to the external RAM.
Power-down Mode	The Po down n Section preserv the dur preserv	wer-down mode places the AT85C51SND3B in a very low power state. Power- node stops the oscillator and freezes all clocks at known states (refer to the "Oscillator", page 28). The CPU status prior to entering Power-down mode is red, i.e., the program counter, program status word register retain their data for ration of Power-down mode. In addition, the SFRs and RAM contents are red.
Entering Power-down Mode	To ente AT85C sets PE	er Power-down mode, set PD bit in PCON register while PMLCK is cleared. The 51SND3B enters the Power-down mode upon execution of the instruction that bit. The instruction that sets PD bit is the last instruction executed.
Exiting Power-down Mode	There a	are 2 ways to exit the Power-down mode:
	1. Ge	nerate an enabled external interrupt.
	_	The AT85C51SND3B provides capability to exit from Power-down using INT0, INT1, and KIN3:0 inputs. In addition, using KIN input provides high or low level exit capability (see Section "Keyboard Interface", page 240). Hardware clears PD bit in PCON register which starts the oscillator and restores

the clocks to the CPU and peripherals. Using INTn input, execution resumes when the input is released (see Figure 10) while using KINx input, execution resumes after counting 1024 clock ensuring the oscillator is restarted properly (see Figure 11). This behavior is necessary for decoding the key while it is still pressed. In both cases, execution resumes with the interrupt service routine. Upon completion of the interrupt service routine, program execution resumes with the instruction immediately following the instruction that activated Powerdown mode.

- Note: 1. The external interrupt used to exit Power-down mode must be configured as level sensitive (INT0 and INT1) and must be assigned the highest priority. In addition, the duration of the interrupt must be long enough to allow the oscillator to stabilize. The execution will only resume when the interrupt is de-asserted.
 - 2. Exit from power-down by external interrupt does not affect the SFRs nor the internal RAM content.



Figure 10. Power-down Exit Waveform Using INT1:0





Note: 1. KIN3:0 can be high or low-level triggered.

- 2. Generate a reset.
 - A logic high on the RST pin clears PD bit in PCON register directly and asynchronously. This starts the oscillator and restores the clock to the CPU and peripherals. Program execution momentarily resumes with the instruction immediately following the instruction that activated Power-down mode and may continue for a number of clock cycles before the internal reset algorithm takes control. Reset initializes the AT85C51SND3B and vectors the CPU to address 0000h.
- Notes: 1. During the time that execution resumes, the internal RAM cannot be accessed; however, it is possible for the Port pins to be accessed. To avoid unexpected outputs at the Port pins, the instruction immediately following the instruction that activated the Power-down mode should not write to a Port pin or to the external RAM.
 - 2. Exit from power-down by reset redefines all the SFRs, but does not affect the internal RAM content.





Reset

In order to secure the product functionality while in power-up or power-down phase or while in running phase, a number of internal mechanisms have been implemented. These mechanisms are listed below and detailed in the following paragraphs.

- External RST input
- Power Fail Detector (brown-out)
- Watchdog timer
- Pads control

Figure 12 details the internal reset circuitry.

Reset Source Reporting In order for the firmware to take specific actions depending on the source which has currently reset the device, activated reset source is reported to the CPU by EXTRST, WDTRST, and PFDRST flags in PSTA register.





Pads Level Control

As soon as one reset source is asserted, the pads go to their reset value. This ensures that pads level is steady during reset (e.g. NFWP set to low level and then protecting Nand Flash against spurious writing).

The status of the Port pins during reset is detailed in Table 19.

Table 19. Pin State Under Reset Condition.

Port 0	Port 1	Port 2	Port 3	Port 4	Port 5	NFD7:0	NFWP	NFCE0
Float	Н	Н	Н	Н	Н	Float	L	Н

External RST Input

In order to start-up (cold reset) or to restart (warm reset) properly the microcontroller, a low level has to be applied on the RST pin. A bad level leads to a wrong initialization of the internal registers like SFRs, Program Counter... and to unpredictable behavior of the microcontroller. A proper device reset initializes the AT85C51SND3B and vectors the CPU to address 0000h. RST input has a pull-up resistor allowing power-on reset by simply connecting an external capacitor to V_{SS} as shown in Figure 13. A warm reset can be applied either directly on the RST pin or indirectly by an internal reset source such as the watchdog timer. Resistor value and input characteristics are discussed in the Section "DC Characteristics", page 242.





Power Fail Detector

The Power Fail Detector (PFD) ensures that whole product is in reset when internal voltage is out of its limits specification. PFD limits are detailed in the Section "DC Characteristics", page 242.





Registers

Table 20. PCON Register

PCON (0.87h) - Power Control Register

7	6	5	4	3	2	1	0	
VBCEN	VBPEN	DCPBST	GF0	DCEN	PMLCK	PD	IDL	
Bit Number	Bit Mnemonic	Description						
7	VBCEN	Battery Mon Set to enable Clear to disa	itor Clock Ei the clock of ble the clock	nable Bit the battery mo of the battery i	nitoring. nonitoring.			
6	VBPEN	Battery Mon Set to power Clear to unpo	itor Power E the battery m ower the batte	nable Bit nonitoring. ery monitoring.				
5	DCPBST	DC-DC Conv Set to disable Clear to enal	DC-DC Converter Power Boost Bit Set to disable DC-DC high power boost mode. Clear to enable DC-DC high power boost mode.					
4	GF0	General-pur One use is to during Idle m	pose flag 0 o indicate who ode.	ether an interr	upt occurred	during normal	operation or	
3	DCEN	DC-DC Conv Set to start asserted. Clear to stop external pow	DC-DC Converter Enable Bit Set to start the DC-DC converter or maintain its activity while DCPWR pin is asserted. Clear to stop the DC-DC converter and shut off the device if not powered by an external power supply.					
2	PMLCK	Power Mode Lock Bit Set to lock power-down or Idle mode entry by preventing PD or IDL bits from being set by software. Clear to unlock power-down or Idle mode entry.						
1	PD	Power-down Mode bit Cleared by hardware when an interrupt or reset occurs. Set to activate the Power-down mode when PMLCK is cleared. If IDL and PD are both set, PD takes precedence.						
0	IDL	Idle Mode bi Cleared by h Set to activat If IDL and PE	t ardware whe the Idle mo are both set	n an interrupt de when PML , PD takes pre	or reset occur CK is cleared cedence.	S.		

Reset Value = 00011 0000b

Table 21. PSTA Register

PSTA (0.86h) - Power Status Register

7	6	5	4	3	2	1	0
UVDET	HVDET	-	-	-	WDTRST	EXTRST	PFDRST
Bit Number	Bit Mnemonic	Description					
		_					

Bit Number	Bit Mnemonic	Description
6	HVDET	High Voltage Detect Flag Set by hardware when 3V is detected on HVDD pin. Cleared by hardware when 3V is not detected on HVDD pin.
5-3	-	Reserved The value of these bits is always 0. Do not set these bits.
2	WDTRST	Watchdog Timer Reset Flag Set by hardware when the watchdog timer has overflowed triggering and internal reset. Must be cleared by software at power-up.
1	EXTRST	External Reset Flag Set by hardware when the external \overrightarrow{RST} pin is asserted (warm reset). Must be cleared by software at power-up.
0	PFDRST	Power Failure Detector Reset Flag Set by hardware when the power voltage has been triggered outside its specified value (cold reset). Must be cleared by software at power-up.

Reset Value = XX00 0XXXb⁽¹⁾

Note: 1. Reset value depends on the power supply presence and on the internal reset source.

Table 22. VBAT Register

VBAT	(0.85h) –	Battery	Voltage	Monitor	Register
------	-----------	---------	---------	---------	----------

7	6	5	4	3	2	1	0		
VBEN	VBERR	-	VB4	VB3	VB2	VB1	VB0		
Bit Number	Bit Mnemonic	Description	Description						
7	VBEN	Battery Mon Set to enable Cleared by h	Battery Monitor Enable Bit Set to enable the battery monitoring. Cleared by hardware at the end of conversion						
6	VBERR	Battery Mon Set by hardw	Battery Monitor Error Flag Set by hardware when conversion is out of min/max values.						
5	-	Reserved The value read from this bit is always 0. Do not set this bit.							
4-0	VB4:0	Battery Valu Refer to Tab	e le 18 for volta	ge value corre	espondence.				





Clock Controller	The clock controller implemented in AT85C51SND3B derivatives is based on an on-chip oscillator feeding two on-chip Phase Lock Loop (PLL) dedicated for the USB controller (see Section "USB Controller", page 85) and the Audio Controller (see Section "Audio Controller", page 149). All internal clocks to the peripherals and CPU core are generated by this controller.
Oscillator	X1 and X2 pins are the input and the output of a frequency power-optimized single- stage on-chip inverter (see Figure 15) that can be configured with off-chip components such as a Pierce oscillator (see Figure 16). Value of capacitors and crystal characteris- tics are detailed in the Section "DC Characteristics", page 242.
Authorized frequency	In order to be able to be able to properly detect the oscillating frequency when in In Sys- tem Programming mode and then generate the 480MHz requested for USB connection, only the following frequencies are authorized: 12MHz, 13MHz, 16MHz, 19.2MHz, 19.5MHz, 20MHz, 24MHz and 26MHz.
Power Optimization	In order to optimize the power consumption, oscillator gain can be adjusted by software depending on the crystal frequency. Such optimization is done after reset using OSCF1:0 bits in CKCON register (see Table 31) according to Table 23. Moreover if external frequency signal is input (X1 driven by a remote host) it is possible to switch off the internal amplifier by setting the OSCAMP bit in CKCON register as shown in Figure 15.
	Table 23 Oscillator Frequency Configuration

Table 23. Oscillator Frequency Configuration
--

OSCF1:0	Crystal Clock Frequency Range (F _{osc})			
00	22 - 26 MHz (default)			
01	18 - 22 MHz			
10	14 - 18 MHz.			
11	10 - 14 MHz			

The oscillator outputs a clock: the oscillator clock used to feed the clock generator and the system clock generator.

The oscillator clock can be disabled by entering the power-down reduction mode as detailed in the Section "Power Management", page 19.

Figure 15. Oscillator Block Diagram and Symbol



Figure 16. Crystal Connection



Clock Generator

The clock generator provides the oscillator and higher frequency clocks to the System, the DFC, the memory controllers: Nand Flash and MMC controllers, the USB and the high speed Serial I/O port. It is based on a 480 MHz PLL namely the PLL clock followed by a frequency divider giving a broad range of available clock frequency: the CLOCK GEN clocks.

The clock generation is enabled by setting CKGENE bit in CKEN (see Table 32).

The PLL is enabled by setting PLLEN bit in CKEN and reports a filtered lock status by the PLOCK Flag in CKEN.

As soon as the PLL is locked, the generated clocks can be used by the peripherals as detailed in the following sections.

Figure 17. Clock Generator Block Diagram and Symbol



480 MHz PLL

The PLL is based on a Phase Frequency Comparator and Lock Detector block (PFLD) which makes the comparison between the reference clock coming from the 4-bit N divider (PLLN3:0 + 1 in PLLCLK) and the reverse clock coming from either fixed frequencies or the 4-bit R divider (PLLR3:0 + 1 in PLLCLK) and generates some pulses on the Up or Down signal depending on the edge position of the reverse clock. These pulses feed the Charge Pump block (CHP) that generates a voltage reference to the 480 MHz Voltage Controlled Oscillator (VCO) by injecting or extracting charges from an internal filter. The reverse clock selection mechanism is implemented in order to support many oscillator frequencies and to minimize the PLL output jitter.









Table 24. PLL Reverse Clock Selection

PLLCKS1:0	Clock Selection (F _{REV})
00	12 MHz (default)
01	16 MHz
10	20 MHz
11	12 MHz ÷ (PLLR + 1)

PLL Programming

The PLL is programmed depending on the oscillator clock frequency. In order to minimize the output jitter, F_{REV} must be as higher as possible. Table 26 shows the PLL programming values and reverse frequency depending on some oscillator frequency.

F _{OSC} (MHz)	PLLCKS1:0	PLLN3:0 / N	PLLR3:0 / R	F _{REV} (MHz)
12	00	0000	XXXX	12
13	11	1100 / 13	1011 / 12	1
16	01	0000	XXXX	16
19.2	11	0111 / 8	0100 / 5	2.4
19.5	11	1100 / 13	0111 / 8	1.5
20	10	0000	XXXX	20
24	00	0001 / 2	XXXX	12
26	11	1100 / 13	0101 / 6	2

Table 25. PLL Programming Values versus Input Frequency

System Clock Generator

In order to increase the system computation throughput, it is possible to switch the system clock to higher value when PLL is enabled. System clock generator block diagram is shown in Figure 19 and is based on a frequency selector controlled by SYSCKS1:0 bits in CKSEL (see Table 34) according to Table 26.

The CPU clock can be disabled by entering the idle reduction mode as detailed in the Section "Power Management", page 19.

Note: In order to prevent any incorrect operation while dynamically switching the system frequency, user must be aware that all peripherals using the peripheral clock as time reference (timers, etc...) will have their time reference modified by this frequency change.



Figure 19. System Clock Generator Block Diagram and Symbols

Table 26. System Clock Selection

SYSCKS1:0	Clock Selection (F _{SYS})
00	F _{OSC} (default)
01	24 MHz
10	30 MHz
11	40 MHz

X2 Feature

Unlike standard C51 products that require 12 clock periods per machine cycle, the AT85C51SND3B needs only 6 clock periods per machine cycle. This feature called the "X2 feature" can be enabled using the X2 bit⁽¹⁾ in CKCON and allows the AT85C51SND3B to operate in 6 or 12 clock periods per machine cycle. As shown in Figure 19, both CPU and peripheral clocks are affected by this feature. Figure 20 shows the X2 mode switching waveforms. After reset the standard mode is activated. In standard mode the CPU and peripheral clock frequency is the oscillator frequency divided by 2 while in X2 mode, it is the oscillator frequency.

Figure 20. Mode Switching Waveforms



DFC/NFC Clock Generator

In order to optimize the data transfer throughput between the DFC and the NFC, both peripherals share the same clock frequency. The DFC and NFC clock generator block diagram is shown in Figure 21 and is based on a frequency selector.

Frequency selection is done using DNFCKS2:0 bits in CKSEL (see Table 33) according to Table 27.

Frequency is enabled by setting DNFCKEN bit in CKEN.









Table 27. DFC/NFC Clock Se

DNFCKS2:0	Clock Selection (F _S)
000	F _{OSC} (default)
001	60 MHz
010	48 MHz
011	40 MHz
100	30 MHz
101	24 MHz
110	20 MHz
111	16 MHz

MMC Clock Generator

The MMC clock generator block diagram is shown in Figure 22 and is based on a frequency selector followed by a frequency divider.

Frequency selection is done using MMCCKS2:0 bits in MMCCLK (see Table 35) according to Table 28⁽¹⁾.

Frequency division is done using MMCDIV4:0 bits in MMCCLK according to Table 29.

Frequency configuration (selection and division) must be done prior to enable the MMC clock generation by setting MMCKEN bit in CKEN.

Note: 1. To allow low frequency as low as 400 KHz (frequency needed in MMC identification phase), F_{OSC} selection can be divided by 2.





TADIE 20. IVIIVIC CIUCK SEIECLIU	Table 28.	MMC	Clock	Selection
----------------------------------	-----------	-----	-------	-----------

MMCCKS2:0	Clock Selection (F _S)
000	F _{OSC} (default)
001	60 MHz
010	48 MHz
011	30 MHz
100	24 MHz
101	20 MHz
110	16 MHz
111	F _{OSC} ÷ 2

Table 29. MMC Clock Divider

MMCDIV4:0	Clock Division
00000	Disabled (no clock out)
≥ 00001	$F_{MMC} = F_{S} \div MMCDIV$

SIO Clock Generator

As detailed in Figure 23, the SIO clock which feeds the internal SIO baud rate generator can be programmed using SIOCKS bit in CKSEL register according to Table 30 to generate either the oscillator frequency or a very high frequency allowing very high baud rate when PLL is enabled. SIO clock is enabled by SIOCKEN bit in CKEN register.

Figure 23. SIO Clock Generator Block Diagram and Symbol



Table 30.	SIO	Clock	Selection
-----------	-----	-------	-----------

SIOCKS	Clock Selection (F _S)
0	F _{OSC}
1	120 MHz





Registers

Table 31. CKCON Register

CKCON (0.8Fh) – Clock Control Register

7	6	5	4	3	2	1	0				
-	WDX2	OSCAMP	OSCF1	OSCF0	T1X2	T0X2	X2				
Bit Number	Bit Mnemonic	Description	Description								
7	-	Reserved The value re	Reserved The value read from this bit is always 0. Do not set this bit.								
6	WDX2	Watchdog C Set to select independent Clear to select	Natchdog Clock Control Bit Set to select the oscillator clock divided by 2 as watchdog clock input (X2 ndependent). Clear to select the peripheral clock as watchdog clock input (X2 dependent).								
5	OSCAMP	Oscillator Amplifier Control Bit Set to optimize power consumption by disabling the oscillator amplifier when an external clock is used. Clear to enable the oscillator amplifier in case of crystal usage (default).									
4-3	OSCF1:0	Oscillator F Set this bits a	Oscillator Frequency Range Bits Set this bits according to Table 23 to optimize power consumption.								
2	T1X2	Timer 1 Clock Control Bit Set to select the oscillator clock divided by 2 as timer 1 clock input (X2 independent). Clear to select the peripheral clock as timer 1 clock input (X2 dependent).									
1	T0X2	Timer 0 Clock Control Bit Set to select the oscillator clock divided by 2 as timer 0 clock input (X2 independent). Clear to select the peripheral clock as timer 0 clock input (X2 dependent).									
0	X2	System Close Clear to sele F _{OSC} /2). Set to select	ck Control Bi ect 12 clock p 6 clock period	it periods per ma ds per machin	ichine cycle (e cycle (X2 m	STD mode, F ode, F _{CPU} = F	_{CPU} = F _{PER} = _{PER} = F _{OSC}).				

Table 32. CKEN Register

CKEN (0.B9h) - Clock Enable Register

7	6	5	4	3	2	1	0			
CKGENE	PLLEN	-	PLOCK	MMCKEN	-	SIOCKEN	DNFCKEN			
Bit Number	Bit Mnemonic	Description	Description							
7	CKGENE	Clock General Set to enable Clear to disa	rator Enable e the clock ge ble the clock	Bit nerator. generators.						
6	PLLEN	PLL Enable Set to enable Clear to disa	PLL Enable Bit Set to enable the 480 MHz PLL. Clear to disable the 480 MHz PLL.							
5	-	Reserved The value rea	Reserved The value read from this bit is always 0. Do not set this bit.							
4	PLOCK	PLL Lock FI Set by hardw Cleared by h	PLL Lock Flag Set by hardware when the PLL is locked. Cleared by hardware when the PLL is not locked.							
3	MMCKEN	MMC Controller Clock Enable Bit Set to enable the MMC controller Clock. Clear to disable the MMC controller Clock.								
2	-	Reserved The value read from this bit is always 0. Do not set this bit.								
1	SIOCKEN	SIO Controller Clock Enable Bit Set to enable the SIO Clock. Clear to disable the SIO Clock.								
0	DNFCKEN	DF Controlle Set to enable Clear to disa	DF Controller / NF Controller Clock Enable Bit Set to enable the DFC/NFC Clock. Clear to disable the DFC/NFC Clock.							





Table 33. CKSEL Register

CKSEL (0.BAh) – Clock Selection Register

7	6	5	4	3	2	1	0	
DNFCKS2	DNFCKS1	DFCCKS0	PLLCKS1	PLLCKS0	SIOCKS	SYSCKS1	SYSCKS0	
Bit Number	Bit Mnemonic	Description						
7-5	DNFCKS2:0	DFC/NFC CI Refer to Tabl	DFC/NFC Clock Select Bits Refer to Table 27 for information on selected clock value.					
4-3	PLLCKS1:0	PLL Reverse Refer to Tabl	PLL Reverse Clock Select Bits Refer to Table 24 for information on selected clock value.					
2	SIOCKS	SIO Clock S Refer to Tabl	SIO Clock Select Bit Refer to Table 30 for information on divided clock value.					
1-0	SYSCKS1:0	System Cloc Refer to Tabl	ck Select Bits le 26 for inform	s mation on divid	led clock valu	le.		

Reset Value = 0000 0000b

Table 34. PLLCLK Register

PLLCLK (0.BCh) - PLL Clock Control Register

7	6	5	4	3	2	1	0
PLLR3	PLLR2	PLLR1	PLLR0	PLLN3	PLLN2	PLLN1	PLLN0
Bit Number	Bit Mnemonic	Description					
7-4	PLLR3:0	PLL R Divide 4-bit R divide	e r Bits er, R from 1 (P	LLR3:0 = 000	0) to 16 (PLLF	R3:0 = 1111).	
3-0	PLLN3:0	PLL N Divide 4-bit N divide	er Bits er, N from 1 (P	LLN3:0 = 000	0) to 16 (PLLN	N3:0 = 1111).	

Reset Value = 0000 0000b

Table 35. MMCCLK Register

MMCCLK (0.BDh) - MMC Clock Control Register

7	6	5	4	3	2	1	0
MMCCKS2	MMCCKS1	MMCCKS0	MMCDIV4	MMCDIV3	MMCDIV2	MMCDIV1	MMCDIV0
Bit Number	Bit Mnemonic	Description					
7-5	MMCCKS2:0	MMC Clock Select Bits Refer to Table 28 for information on selected clock value.					
4-0	MMCDIV4:0	MMC Clock Divider Bits Refer to Table 29 for information on divided clock value.					
Special Function Registers

SFR Pagination

The AT85C51SND3B derivatives implement a SFR pagination mechanism which allows mapping of high number of peripherals in the SFR space. As shown in Figure 24, four pages are accessible through the PPCON (Peripheral Pagination Control) register (see Table 37). The four bits of PPCON: PPS0 to PPS3 are used to select one page as detailed in Table 36. Setting one bit of PPCON using the *setb* instruction automatically clears the 7 others: e.g. if page 0 is selected, selecting page 3 is done by the instruction *setb* PPS3 which clears PPS0.

By default, after reset selected page is page 0.

The PPCON content is automatically saved in a specific stack at each interrupt service routine entry during vectorization and restored at exit during *reti* execution.





Table 36. Page Selection Truth Table

PPS3	PPS2	PPS1	PPS0	Selected Page
0	0	0	0	Page 0
х	Х	Х	1	Page 0
х	х	1	0	Page 1
х	1	0	0	Page 2
1	0	0	0	Page 3

Table 37. PPCON Register

PPCON (Y.C0h) - Peripheral Page Control Register

7	6	5	4	3	2	1	0						
-	-	-	PPS1	PPS0									
Bit Number	Bit Mnemonic	Description	Description										
7-4	-	Reserved The value re	ad from these	bits is always	0. Do not set	these bits.							
3-0	PPS3:0	Peripheral F Refer to Tab	e 36 for page	i its decoding info	ormation.								





SFR Registers

The Special Function Registers (SFRs) of the AT85C51SND3B fall into the categories detailed in Table 39 to Table 58. Address is identified as "P.XXh" where P can take the values detailed in Table 38 and XXh is the hexadecimal address from 80h to FFh

Table 38. Page Address Notation

Р	Comment
Y	Register mapped in all pages
3-0	Register mapped in the corresponding page

The SFRs mapping within pages is provided together with SFR reset value in Table 58 to Table 58. In these tables, the bit-addressable registers are identified by Note 1.

Table 39. C51 Core SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
ACC	Y.E0h	Accumulator								
В	Y.F0h	B Register								
PSW	Y.D0h	Program Status Word	CY	AC	F0	RS1	RS0	OV	F1	Р
SP	Y.81h	Stack Pointer								
DPL	Y.82h	Data Pointer Low Byte								
DPH	Y.83h	Data Pointer High Byte								
PPCON	Y.C0h	Peripheral Pagination	-	-	-	-	PPS3:0			

Table 40. Power and System Management

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
PCON	0.87h	Power Control	VBCEN	VBPEN	DCPBST	GF0	DCEN*	PMLCK	PD	IDL
PSTA	0.86h	Power Status	UVDET	HVDET	-	-	-	WDTRST	EXTRST	PFDRST
AUXR1	0.A2h	Auxiliary Register 1	-	-	-	-	GF3	0	-	DPS
VBAT	0.85h	Battery Voltage Monitoring	VBEN	VBERR	-	VB4:0				
SVERS	3.97h	Silicon Version				SV7:0				

Note: Available in AT85C51SND3B2 only.

Table 41. Clock Management Unit SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
CKCON	0.8Fh	Clock Control	-	WDX2	-	OSC	CF1:0	T1X2	T0X2	X2
CKEN	0.B9h	Clock Enable	CKGENE	PLLEN	-	PLOCK	MMCKEN	-	SIOCKEN	DFCKEN
CKSEL	0.BAh	Clock Selection		DNFCKS2:0		PLLC	KS1:0	SIOCKS SYSCKS1:0		
PLLCLK	0.BCh	PLL Clock	PLLR3:0				PLLN3:0			
MMCCLK	0.BDh	MMC Clock	I	MMCCKS2:0)	MMCDIV4:0				

Table 42. Interrupt SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
IEN0	0.A8h	Interrupt Enable Control 0	EA	EAUP	EDFC	ES	ET1	EX1	ET0	EX0
IEN1	0.B1h	Interrupt Enable Control 1	-	-	EMMC	ENFC	ESPI	EPSI	EKB	EUSB
IPH0	0.B7h	Interrupt Priority Control High 0	-	IPHAUP	IPHDFC	IPHS	IPHT1	IPHX1	IPHT0	IPHX0
IPL0	0.B8h	Interrupt Priority Control Low 0	-	IPLAUP	IPLDFC	IPLS	IPLT1	IPLX1	IPLT0	IPLX0
IPH1	0.B3h	Interrupt Priority Control High 1	-	-	IPHMMC	IPHNFC	IPHSPI	IPHPSI	IPHKB	IPHUSB
IPL1	0.B2h	Interrupt Priority Control Low 1	-	-	IPLMMC	IPLNFC	IPLSPI	IPLPSI	IPLKB	IPLUSB

Table 43. I/O Port SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
P0	Y.80h	8-bit Port 0								
P1	Y.90h	8-bit Port 1								
P2	Y.A0h	8-bit Port 2								
P3	Y.B0h	8-bit Port 3								
P4	0.98h	8-bit Port 4								
P5	0.C8h	4-bit Port 5								

Table 44. Timer SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
TCON	0.88h	Timer/Counter 0 and 1 Control	TF1	TR1	TF0	TR0	IE1	IT1	IE0	IT0
TMOD	0.89h	Timer/Counter 0 and 1 Modes	GATE1	C/T1#	M11	M01	GATE0	C/T0#	M10	M00
TL0	0.8Ah	Timer/Counter 0 Low Byte								
TH0	0.8Ch	Timer/Counter 0 High Byte								
TL1	0.8Bh	Timer/Counter 1 Low Byte								
TH1	0.8Dh	Timer/Counter 1 High Byte								
WDTRST	0.A6h	Watchdog Timer Reset								
WDTPRG	0.A7h	Watchdog Timer Program	-	-	-	-	-		WTO2:0	

Table 45. RAM Interface

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
RDFCAL	1.FDh	RAM DFC Low Address Byte	RA7	RA6	RA5	RA4	RA3	RA2	RA1	RA0
RDFCAM	1.FEh	RAM DFC Medium Address Byte	RA15	RA14	RA13	RA12	RA11	RA10	RA9	RA8
RDFCAH	1.FFh	RAM DFC Higher Address Byte	-	-	-	-	-	-	-	RA16





Table 46. Memory Management SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0	
MEMCBAX	0.F2h	Memory CODE Base Address				CBA	X16:9				
MEMDBAX	0.F3h	Memory DATA Base Address	DBAX16:9								
MEMXBAX	0.F4h	Memory XDATA Base Address		XBAX16:9							
MEMCSX	0.F5h	Memory CODE Size				CS	(7:0				
MEMXSX	0.F6h	Memory XDATA Size		XSX7:0							

Table 47. Scheduler SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0	
SCHCLK	0.FEh	Scheduler Clocks	-	T0ETB2:0		-	-	-	-		
SCHGPR3	Y.F9h	32-bit General Purpose Register	GPR31:24								
SCHGPR2	Y.FAh	32-bit General Purpose Register		GPR23:16							
SCHGPR1	Y.FBh	32-bit General Purpose Register				GPF	15:8				
SCHGPR0	Y.FCh	32-bit General Purpose Register				GPI	R7:0				

Table 48. Data Flow Controller SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
DFCON	1.89h	DFC Control		DFRES	-	DFCRCEN	DFPF	RIO1:0	DFABTM	DFEN
DFCSTA	1.88h	DFC Channel Status	DRDY1	SRDY1	EOFI1	DFBSY1	DRDY0	SRDY0	EOFI0	DFBSY0
DFCCON	1.85h	DFC Channel Control	DFABT1	EOFE1	EOFIA1	-	DFABT0	EOFE0	EOFIA0	-
DFD0	1.8Ah	DFC Channel 0 Descriptor				DFD)D7:0			
DFD1	1.8Bh	DFC Channel 1 Descriptor	DFD1D7:0							
DFCRC	1.8Ch	DFC CRC16 Data	CRCD7:0							

Table 49. USB Controller SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
USB Genera	al Regi	sters								
USBCON	1.E1h	USB General Control	USBE	HOST	FRZCLK	OTGPADE	-	-	IDTE	VBUSTE
USBSTA	1.E2h	USB General Status	-	-	-	-	-	SPEED	ID	VBUS
USBINT	1.E3h	USB General Interrupt	-	-	-	-	-	-	IDTI	VBUSTI
UDPADDH	1.E4h	USB DPRAM Direct Access High	DPACC	-	-	-	-		DPADD10:8	
UDPADDL	1.E5h	USB DPRAM Direct Access Low				DPA	D7:0			
OTGCON	1.E6h	USB OTG Control	-	-	HNPREQ	SRPREQ	SRPSEL	VBUSHWC	VBUSREQ	VBUSRQC
OTGIEN	1.E7h	USB OTG Interrupt Enable	-	-	STOE	HNPERRE	ROLEEXE	BCERRE	VBERRE	SRPE
OTGINT	1.D1h	USB OTG Interrupt	_	_	STOI	HNPERRI	ROLEEXI	BCERRI	VBERRI	SRPI

Table 49. USB Controller SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
USB Device	Regis	ters (HOST cleared)	-		-		~	_		
UDCON	1.D9h	Device Global Control	-	-	-	-	-	-	RMWKUP	DETACH
UDINT	1.D8h	Device Global Interrupt (bit addressable)	-	UPRSMI	EORSMI	WAKEUPI	EORSTI	SOFI	MSOFI	SUSPI
UDIEN	1.DAh	Device Global Interrupt Enable	_	UPRSME	EORSME	WAKEUPE	EORSTE	SOFE	MSOFE	SUSPE
UDADDR	1.DBh	Device Address	ADDEN				UADD6:0	<u> </u>		<u>. </u>
UDFNUMH	1.DCh	Device Frame Number High	-	-	-	-	-		FNUM10:8	
UDFNUML	1.DDh	Device Frame Number Low				FNU	M7:0			
UDMFN	1.DEh	Device Micro Frame Number	-	-	-	FNCERR	-		MFNUM2:0	
UDTST	1.DFh	Device Test	-	-	OPMODE2	TSTPCKT	TSTK	TSTJ	SPDC	ONF
USB Host R	egister	rs (HOST set)	<u> </u>			1		L		
UHCON	1.D9h	USB Host General Control	-	-	-	-	-	RESUME	RESET	SOFE
UHINT	1.D8h	USB Host General Interrupt (bit addressable)	-	HWUPI	HSOFI	RXRSMI	RSMEDI	RSTI	DDISCI	DCONNI
UHIEN	1.DAh	USB Host General Interrupt En	-	HWUPE	HSOFE	RXRSME	RSMEDE	RSTE	DDISCE	DCONNE
UHADDR	1.DBh	USB Host Address	-				HADDR6:0			
UHFNUMH	1.DCh	USB Host Frame Number High	-	-	-	-	-		FNUM10:8	
UHFNUML	1.DDh	USB Host Frame Number Low			1	FNU	M7:0			
UHFLEN	1.DEh	USB Host Frame Length				FLE	N7:0			
USB Device	Endpo	bint Registers (HOST cleared)								
UENUM	1.C9h	Endpoint Number Selection	-	-	-	-	-		EPNUM2:0	
UERST	1.CAh	Endpoint Reset	-			·	EPRST6:0			
UECONX	1.CBh	Endpoint Control			STALLRQ	STALLRQC	RSTDT	EPNUMS	DFCRDY	EPEN
UECFG0X	1.CCh	Endpoint Configuration 1	EPTY	PE1:0	-	-	ISOSW	AUTOSW	NYETDIS	EPDIR
UECFG1X	1.CDh	Endpoint Configuration 0	-		EPSIZE2:0		EPB	K1:0	ALLOC	-
UESTA0X	1.CEh	Endpoint Status 0	CFGOK	OVERFI	UNDERFI	ZLPSEEN	DTSE	EQ1:0	NBUSY	/BK1:0
UESTA1X	1.CFh	Endpoint Status 1	-	-	-	-	-	CTRLDIR	CURR	BK1:0
UEINTX	1.C8h	Endpoint Interrupt (bit addressable)	FIFOCON	NAKINI	RWAL	NAKOUTI	RXSTPI	RXOUTI	STALLI	TXINI
UEIENX	1.D2h	Endpoint Interrupt Enable	FLERRE	NAKINE	-	NAKOUTE	RXSTPE	RXOUTE	STALLE	TXINE
UEDATX	1.D3h	Endpoint Data			1	DAT	7:0			
UEBCHX	1.D4h	Endpoint Byte Counter High	-	-	-	-	-		BYCT10:8	
UEBCLX	1.D5h	Endpoint Byte Counter Low			·	BYC	T7:0			
UEINT	1.D6h	Endpoint Interrupt	-				EPINT6:0			





Table 49. USB Controller SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
USB Pipe R	egister	s (HOST set)								
UPNUM	1.C9h	USB Host Pipe Number	-	-	-	-	-		PNUM2:0	
UPRST	1.CAh	USB Host Pipe Reset	-				PRST6:0			
UPCONX	1.CBh	USB Pipe Control	-	PFREEZE	INMODE	AUTOSW	RSTDT	PNUMS	DFCRDY	PEN
UPCFG0X	1.CCh	USB Pipe Configuration 0	PTYF	PE1:0	PTOK	EN1:0		PEPN	UM3:0	
UPCFG1X	1.CDh	USB Pipe Configuration 1	-		PSIZE2:0		PBł	<1:0	ALLOC	-
UPCFG2X	1.CFh	USB Pipe Configuration 2				INTE	RQ7:0			
UPSTAX	1.CEh	USB Pipe Status	CFGOK	OVERFI	UNDERFI	-	DTSE	EQ1:0	NBUSY	YBK1:0
UPINRQX	1.DFh	USB Pipe IN Request				INR	Q7:0			
UPERRX	1.D7h	USB Pipe Error	-	COUN	TER1:0	CRC16	TIMEOUT	PID	DATAPID	DATATGL
UPINTX	1.C8h	USB Pipe Interrupt (bit addressable)	FIFOCON	NAKEDI	RWAL	PERRI	TXSTPI	TXOUTI	RXSTALLI	RXINI
UPIENX	1.D2h	USB Pipe Interrupt Enable	FLERRE	NAKEDE	-	PERRE	TXSTPE	TXOUTE	RXSTALLE	RXINE
UPDATX	1.D3h	USB Pipe Data				PDA	T7:0		•	
UPBCHX	1.D4h	USB Pipe Byte Counter (high)	-	-	-	-	-		PBYCT10:8	
UPBCLX	1.D5h	USB Pipe Byte Counter (low)				PBY	CT7:0			
UPINT	1.D6h	USB Pipe General Interrupt				PIN	T7:0			

Table 50. NFC SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
NFCFG	1.99h	NF Configuration (FIFO 8 B)				CFC	G7:0			
NFLOG	1.9Ah	NF Logical Value (2 B)				LOC	G7:0			
NFCON	1.9Bh	NF Control	-	-	TRS	RESET	WP	SPZEN	ECCEN	EN
NFERR	1.9Ch	NF Error Information (FIFO 4 B)				ERF	R7:0			
NFADR	1.9Dh	NF Row Address				ADF	R7:0			
NFADC	1.9Eh	NF Column Address				ADO	07:0			
NFCMD	1.9Fh	NF Command	CMD7:0							
NFACT	1.A1h	NF Action	-	-	-	EXT	Г1:0		ACT2:0	
NFDAT	1.A2h	NF Data				DA	Г7:0			
NFDATF	1.A3h	NF Data and Fetch Next				DAT	F7:0			
NFSTA	1.98h	NF Controller Status	SMCD	SMLCK	-	EOP		NECC2:0		RUN
NFECC	1.A4h	NF ECC 1 and 2 (FIFO 6 B)				ECO	07:0			
NFINT	1.A5h	NF Interrupt	-	-	-	SMCTI	ILGLI	ECCRDYI	ECCERRI	STOPI
NFIEN	1.A6h	NF Interrupt Enable	-	-	-	SMCTE	ILGLE	ECCRDYE	ECCERRE	STOPE
NFUDAT	1.A7h	NF User Data				UDA	FA7:0			

Table 50. NFC SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
NFBPH	1.94h	NF Byte Position (MSB)				BP	15:8			
NFBPL	1.95h	NF Byte Position (LSB)				BP	7:0			

Table 51. MMC Controller SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
MMCON0	1.B1h	MMC Control 0	-	DPTRR	CRPTR	CTPTR	MBLOCK	DFMT	RFMT	CRCDIS
MMCON1	1.B2h	MMC Control 1		BLEN	N11:8		DATDIR	DATEN	RXCEN	TXCEN
MMCON2	1.B3h	MMC Control 2	FCK	DCR	CCR	DBSI	ZE1:0	DAT	D1:0	MMCEN
MMBLP	1.B4h	MMC Block Length				BLE	N7:0			
MMSTA	1.B5h	MMC Status	SDWP	CDET	CBUSY	CRC16S	DATFS	CRC7S	WFRS	HFRS
MMDAT	1.B6h	MMC Data				MC	07:0			
MMCMD	1.B7h	MMC Command				МС	7:0			
MMINT	1.BEh	MMC Interrupt	CDETI	EORI	EOCI	EOFI	WFRI	HFRI	EOBI	-
MMMSK	1.BFh	MMC Interrupt Mask	CDETM	EORM	EOCM	EOFM	WFRM	HFRM	EOBM	_

Table 52. Audio Controller SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
AUCON	1.F1h	Audio Controller Control	BPEN	VSURND	BBOOST	MIXEN	EQUDIS	-	-	ACCKEN
APCON0	1.F2h	Audio Processor Control 0	0				APCMD6:0			
APCON1	1.F3h	Audio Processor Control 1	-	-	ABACC	ABWPR	ABRPR	ABSPLIT	APLOAD	DAPEN
APSTA	1.EAh	Audio Processor Status				APST	AT7:0			
APDAT	1.EBh	Audio Processor Data				APD	AT7:0			
APINT	1.F4h	Audio Processor Interrupt	APGP13	APGPI2	APGPI1	APGPI0	APEVTI	ACLIPI	APRDYI	APREQI
APIEN	1.E9h	Audio Processor Interrupt Enable	APGPE3	APGPE2	APGPE1	APGPE0	APEVTE	ACLIPE	APRDYE	APREQE
APTIM0	2.C6h	Audio Processor Timer 0				AP	Г7:0			
APTIM1	2.C7h	Audio Processor Timer 1				APT	15:8			
APTIM2	2.C9h	Audio Processor Timer 2				APT	23:16			
APRDVOL	2.F1h	Audio Processor Right Channel Digital Volume	-	-	-			DVR4:0		
APLDVOL	2.F2h	Audio Processor Left Channel Digital Volume	-	-	-			DVL4:0		
APBDVOL	2.F3h	Audio Processor Bass Band Digital Volume	-	-	-			DVB4:0		
APMDVOL	2.F4h	Audio Processor Medium Band Digital Volume	-	-	-			DVM4:0		
APTDVOL	2.F5h	Audio Processor Treble Band Digital Volume	-	-	-			DVT4:0		





Table 52. Audio Controller SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0	
APEBS	2.F6h	Audio Processor Equalizer Band Select	-	-	-	-	0		EQBS2:0		
APELEV	2.F7h	Audio Processor Equalizer Level	-	-	-		-	EQLEV4:0			
ACCON	2.EAh	Audio Codec Control	-	AMBSEL	AMBEN	AISSEL	AIEN	AODRV*	AOSSEL*	AOEN*	
ACAUX	2.E4h	Audio Codec Auxiliary	-	-	-	-	-	-	AODIS*	AOPRE*	
ACORG*	2.EBh	Audio Codec Right Output Gain	-	-	-			AORG4:0*			
ACOLG*	2.ECh	Audio Codec Left Output Gain	-	-	-			AOLG4:0*			
ACIPG	2.EDh	Audio Codec Input Preamp Gain	-	-	-	-	AILPG		AIPG2:0		
ADICON0	2.EEh	Audio DAC Interface Control 0	-	-	-	CSPOL	DSIZE	E OVERS1:0 ADIEN			
ADICON1	2.EFh	Audio DAC Interface Control 1	-	-	-			JUST4:0			
Note: Av	ailable	e in AT85C51SND3B1 & AT85C	51SND3B2	2 only.							

Table 53. Audio Stream Codec SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
ASCON	2.E1h	Audio Stream Control								
ASSTA0	2.E2h	Audio Stream Status 0			Denen	da an tha ai				
ASSTA1	2.E3h	Audio Stream Status 1			Depen	us on the at	iaio codec ili	mware		
ASSTA2	2.E9h	Audio Stream Status 2								

Table 54. PSI Controller SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
PSISTH	1.ACh	PSI Status Host	PSHBSY				PSSTH6:0			
PSICON	1.ADh	PSI Control	PSEN	PSBSYE PSRUNE PSWS2:0						
PSISTA	1.AEh	PSI Status	PSEMPTY	PSBSY	PSRUN	PSRDY	-	-	-	-
PSIDAT	1.AFh	PSI Data				PSE	07:0			

Table 55. SPI Controller SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
SPCON	1.91h	SPI Control	SPR2	SPEN	SSDIS	MSTR	CPOL	CPHA	SPR1	SPR0
SPSCR	1.92h	SPI Status and Control	SPIF	-	OVR	MODF	SPTE	UARTM	SPTEIE	MODFIE
SPDAT	1.93h	SPI Data				SPE	07:0			

Table 56. Serial I/O Port SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
SCON	0.91h	SIO Control	SIOEN	PMC	D1:0	PBEN	STOP	DLEN	GBI	T1:0
SFCON	0.95h	SIO Flow Control	OVSF3:0			CTSEN	RTSEN	RTST	「H1:0	

Table 56. Serial I/O Port SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
SINT	1.A8h	SIO Interrupt	-	-	EOTI	OEI	PEI	FEI	ТІ	RI
SIEN	1.A9h	SIO Interrupt Enable	-	-	EOTIE	OEIE	PEIE	FEIE	TIE	RIE
SBUF	1.AAh	SIO Data Buffer	SIOD7:0							
SBRG0	0.92h	SIO Baud Rate Generator 0	CDIV7:0							
SBRG1	0.93h	SIO Baud Rate Generator 1	BDIV7:0							
SBRG2	0.94h	SIO Baud Rate Generator 2	ADIV7:0							

Table 57. LCD Interface SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
LCDCON0	1.96h	LCD Control 0	BUINV	LCIFS	ADSUH1	ADSUH0	ACCW3	ACCW2	ACCW1	ACCW0
LCDCON1	1.8Eh	LCD Control 1	SLW1:0		RSCMD	LCYCW	LCYCT	LCEN	LCRD	LCRS
LCDSTA	1.8Fh	LCD Status	-	-	-	-	-	-	-	LCBUSY
LCDDAT	1.97h	LCD Data	LD7:0							
LCDBUM	1.8Dh	LCD Busy Mask	BUM7:0							

Table 58. Keyboard Interface SFRs

Mnemonic	Add	Name	7	6	5	4	3	2	1	0
KBCON	0.A3h	Keyboard Control	KINL3:0			KINM3:0				
KBSTA	0.A4h	Keyboard Status	KPDE KDCPE KDCPL -				KIN	=3:0		



R

	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F	
F8h		SCHGPR3 0000 0000	SCHGPR2 0000 0000	SCHGPR1 0000 0000	SCHGPR0 0000 0000		SCHCLK 0000 0000		FFh
F0h	B ⁽¹⁾ 0000 0000	MEMCON 0000 0001	MEMCBAX 0 0000 000	MEMDBAX 0 1111 111	MEMXBAX 0 1111 000	MEMCSX 1110 1111	MEMXSX 0000 1110		F7h
E8h									EFh
E0h	ACC ⁽¹⁾ 0000 0000								E7h
D8h									DFh
D0h	PSW ⁽¹⁾ 0000 0000								D7h
C8h	P5 ⁽¹⁾ 1111 1111								CFh
C0h	PPCON ⁽¹⁾ 0000 0001								C7h
B8h	IPL0 ⁽¹⁾ X000 0000	CKEN 0000 0000	DFCCLK 0000 0000		NFCCLK 0000 0000	MMCCLK 0000 0000			BFh
B0h	P3 ⁽¹⁾ 1111 1111	IEN1 0000 0000	IPL1 0000 0000	IPH1 0000 0000				IPH0 X000 0000	B7h
A8h	IEN0 ⁽¹⁾ 0000 0000								AFh
A0h	P2 ⁽¹⁾ 1111 1111		AUXR1 XXXX 00X0	KBCON 0000 1111	KBSTA 0010 0000		WDTRST XXXX XXXX	WDTPRG XXXX X000	A7h
98h	P4 ⁽¹⁾ 1111 1111								9Fh
90h	P1 ⁽¹⁾ 1111 1111	SCON 0000 0000	SBRG0 0000 0000	SBRG1 0000 0000	SBRG2 0000 0000	SFCON 0000 0000			97h
88h	TCON ⁽¹⁾ 0000 0000	TMOD 0000 0000	TL0 0000 0000	TL1 0000 0000	TH0 0000 0000	TH1 0000 0000		CKCON 0000 0000	8Fh
80h	P0 ⁽¹⁾ 1111 1111	SP 0000 0111	DPL 0000 0000	DPH 0000 0000		VBAT 0000 0000	PSTA XX00 0XXX	PCON 0011 0000	87h
	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F	-

Table 59. SFR Page 0: Addresses and Reset Values

Notes: 1. SFR registers with least significant nibble address equal to 0 or 8 are bit-addressable.

	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F	
F8h		SCHGPR3 0000 0000	SCHGPR2 0000 0000	SCHGPR1 0000 0000	SCHGPR0 0000 0000	RDFCAL 0000 0000	RDFCAM 0000 0000	RDFCAH 0000 0000	FFh
F0h	B ⁽¹⁾ 0000 0000	AUCON 0000 0000	APCON0 0000 0000	APCON1 0000 0000	APINT 0000 0000				F7h
E8h		APIEN 0000 0000	APSTA 0000 0000	APDAT 0000 0000					EFh
E0h	ACC ⁽¹⁾ 0000 0000	USBCON 0010 0000	USBSTA 0000 00XX	USBINT 0000 000X	UDPADDH 0000 0000	UDPADDL 0000 0000	OTGCON 0000 0000	OTGIEN 0000 0000	E7h
D8h	UDINT ⁽¹⁾ 0000 0000 UHINT ⁽¹⁾ 0000 0000	UDCON 0000 0001 UHCON 0000 0000	UDIEN 0000 0000 UHIEN 0000 0000	UDADDR 0000 0000 UHADDR 0000 0000	UDFNUMH 0000 0000 UHFNUMH 0000 0000	UDFNUML 0000 0000 UHFNUML 0000 0000	UDMFN 0000 0000 UHFLEN 0000 0000	UDTST 0000 0000 UPINRQX 0000 0000	DFh
D0h	PSW ⁽¹⁾ 0000 0000	OTGINT 0000 0000	UEIENX 0000 0000 UPIENX 0000 0000	UEDATX 0000 0000 UPDATX 0000 0000	UEBCHX 0000 0000 UPBCHX 0000 0000	UEBCLX 0000 0000 UPBCLX 0000 0000	UEINT 0000 0000 UPINT 0000 0000	UPERRX 0000 0000	D7h
C8h	UEINTX ⁽¹⁾ 0000 0000 UPINTX ⁽¹⁾ 0000 0000	UENUM 0000 0000 UPNUM 0000 0000	UERST 0000 0000 UPRST 0000 0000	UECONX 0000 0000 UPCONX 0000 0000	UECFG0X 0000 0000 UPCFG0X 0000 0000	UECFG1X 0000 0000 UPCFG1X 0000 0000	UESTA0X 0000 0000 UPSTAX 0000 0100	UESTA1X 0000 0000 UPCFG2X 0000 0000	CFh
C0h	PPCON ⁽¹⁾ 0000 0001								C7h
B8h							MMINT 0000 0000	MMMSK 1111 1110	BFh
B0h	P3 ⁽¹⁾ 1111 1111	MMCON0 0000 0010	MMCON1 0000 0000	MMCON2 0000 0000	MMBLP 0000 0000	MMSTA XX00 0000	MMDAT 1111 1111	MMCMD 1111 1111	B7h
A8h	SINT ⁽¹⁾ 0X10 0010	SIEN 0000 0000	SBUF XXXX XXXX		PSITH 0000 0000	PSICON 0000 0000	PSISTA 1000 0000	PSIDAT 0000 0000	AFh
A0h	P2 ⁽¹⁾ 1111 1111	NFACT 0000 0000	NFDAT 0000 0000	NFDATF 0000 0000	NFECC 0000 0000	NFINT 0000 0000	NFIEN 0000 0000	NFUDAT XXXX XXXX	A7h
98h	NFSTA ⁽¹⁾ 0000 0000	NFCFG 0000 0000	NFLOG 0000 0000	NFCON 0000 0000	NFERR 0000 0000	NFADR 0000 0000	NFADC 0000 0000	NFCMD 0000 0000	9Fh
90h	P1 ⁽¹⁾ 1111 1111	SPCON 0001 0100	SPSCR 0000 1000	SPDAT XXXX XXXX	NFBPH 0000 0000	NFBPL 0000 0000	LCDCON0 0000 0000	LCDDAT 0000 0000	97h
88h	DFCSTA ⁽¹⁾ 0000 0000	DFCON 0000 0000	DFD0 0000 0000	DFD1 0000 0000	DFCRC 0000 0000	LCDBUM 0000 0000	LCDCON1 0000 0000	LCDSTA 0000 0000	8Fh
80h	P0 ⁽¹⁾ 1111 1111	SP 0000 0111	DPL 0000 0000	DPH 0000 0000		DFCCON 0000 0000			87h
	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F	

Table 60. SFR Page 1: Addresses and Reset Values

Note: 1. SFR registers with least significant nibble address equal to 0 or 8 are bit-addressable.



IIIEL
8

	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F	
F8h		SCHGPR3 0000 0000	SCHGPR2 0000 0000	SCHGPR1 0000 0000	SCHGPR0 0000 0000				FFh
F0h	B ⁽¹⁾ 0000 0000	APRDVOL 0000 0011	APLDVOL 0000 0011	APBDVOL 0001 1111	APMDVOL 0001 1111	APTDVOL 0001 1111			F7h
E8h		ASSTA2 0000 0000	ACCON 0000 0000	ACORG ⁽¹⁾ 0000 0000	ACOLG ⁽¹⁾ 0000 0000	ACIPG 0000 0000	ADICON0 0000 0000	ADICON1 0000 0000	EFh
E0h	ACC ⁽¹⁾ 0000 0000	ASCON 0000 0000	ASSTA0 0000 0000	ASSTA1 0000 0000	ACAUX 0000 0000				E7h
D8h									DFh
D0h	PSW ⁽¹⁾ 0000 0000								D7h
C8h		APTIM2 0000 0000							CFh
C0h	PPCON ⁽¹⁾ 0000 0001						APTIM0 0000 0000	APTIM1 0000 0000	C7h
B8h									BFh
B0h	P3 ⁽¹⁾ 1111 1111								B7h
A8h									AFh
A0h	P2 ⁽¹⁾ 1111 1111								A7h
98h									9Fh
90h	P1 ⁽¹⁾ 1111 1111								97h
88h									8Fh
80h	P0 ⁽¹⁾ 1111 1111	SP 0000 0111	DPL 0000 0000	DPH 0000 0000					87h
	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F	-

Table 61. SFR Page 2: Addresses and Reset Values

Notes: 1. SFR registers with least significant nibble address equal to 0 or 8 are bit-addressable.

2. Available in AT85C51SND3B1 & AT85C51SND3B2 only.

	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F	
F8h		SCHGPR3 0000 0000	SCHGPR2 0000 0000	SCHGPR1 0000 0000	SCHGPR0 0000 0000				FFh
F0h	B ⁽¹⁾ 0000 0000								F7h
E8h									EFh
E0h	ACC ⁽¹⁾ 0000 0000								E7h
D8h									DFh
D0h	PSW ⁽¹⁾ 0000 0000								D7h
C8h									CFh
C0h	PPCON ⁽¹⁾ 0000 0001								C7h
B8h									BFh
B0h	P3 ⁽¹⁾ 1111 1111								B7h
A8h									AFh
A0h	P2 ⁽¹⁾ 1111 1111								A7h
98h									9Fh
90h	P1 ⁽¹⁾ 1111 1111							SVERS ⁽²⁾ XXXX XXXX	97h
88h									8Fh
80h	P0 ⁽¹⁾ 1111 1111	SP 0000 0111	DPL 0000 0000	DPH 0000 0000					87h
	0/8	1/9	2/A	3/B	4/C	5/D	6/E	7/F	J

Table 62. SFR Page 3: Addresses and Reset Values

Notes: 1. SFR registers with least significant nibble address equal to 0 or 8 are bit-addressable.

2. SVERS reset value depends on the silicon version 1111 1011 for AT85C51SND3B product.





Memory Space

The AT85C51SND3B derivatives implement an "all in one" 64K bytes of RAM split between the three standard C51 memory segments:

- CODE
- DATA
- XDATA

To satisfy application needs in term of CODE and XDATA sizes, size and base address of XDATA and CODE segments and base address of DATA segment can be dynamically configured.

Figure 25 shows the memory space organization.

Figure 25. Memory Organization



Memory Segments	
CODE Segment	The AT85C51SND3B executes up to 64K Bytes of program/code memory.
	The AT85C51SND3B implements an additional 4K Bytes of on-chip boot ROM memory. This boot memory is delivered programmed with a boot strap software allowing loading of the application code from the Nand Flash Memory to the internal RAM. It also con- tains a boot loader software allowing In-System Programming (ISP).
DATA Segment	The DATA segment is mapped in two separate segments: – The lower 128 Bytes RAM segment – The upper 128 Bytes RAM segment
Lower 128 Bytes	The lower 128 Bytes of RAM (see Figure 26) are accessible from address 00h to 7Fh using direct or indirect addressing modes. The lowest 32 Bytes are grouped into 4 banks of 8 registers (R0 to R7). 2 bits RS0 and RS1 in PSW register (see Table 64) select which bank is in use according to Table 63. This allows more efficient use of code space, since register instructions are shorter than instructions that use direct addressing, and can be used for context switching in interrupt service routines.

Table 63.	Register	Bank	Selection
-----------	----------	------	-----------

RS1	RS0	Description
0	0	Register bank 0 from 00h to 07h
0	1	Register bank 1 from 08h to 0Fh
1	0	Register bank 2 from 10h to 17h
1	1	Register bank 3 from 18h to 1Fh

The next 16 Bytes above the register banks form a block of bit-addressable memory space. The C51 instruction set includes a wide selection of single-bit instructions, and the 128 bits in this area can be directly addressed by these instructions. The bit addresses in this area are 00h to 7Fh.

Figure 26. Lower 128 Bytes Internal RAM Organization



Upper 128 Bytes	The upper 128 Bytes of RAM are accessible from address 80h to FFh using only indirect addressing mode. Using direct addressing mode within this address range selects the Special Function Registers, SFRs. For information on this segment, refer to the Section "Special Function Registers", page 37.
XDATA Segment	The on-chip expanded RAM (XRAM) are accessible using indirect addressing mode through MOVX instructions.
Memory Configuration	As shown in Figure 25, the 64KB addressing space of the C51 is artificially increased by usage of logical address over a physical one. For example, the boot memory which contains the bootstrap software is implemented at physical address 10000h but is starting at logical address code 0000h which means that the bootstrap is first executed when a system reset occurs. To achieve such logical mapping over the physical memory, some registers have been

implemented to give the base address of the memory segments and their size:

- MEMCBAX (see Table 65) for the code segment base address.
 - MEMDBAX (see Table 66) for the data segment base address.
- MEMXBAX (see Table 67) for the xdata segment base address.
- MEMCSX (see Table 68) for the code segment size.
- MEMXSX (see Table 69) for the code segment size.

The data segment is not programmable in size as it is a fixed 256-byte segment.



•



The Figure 27 shows the memory segments configuration after bootstrap execution along with an example of user memory segments configuration done during firmware start-up. In this figure italicized address are the logical address within segments.





Registers

Table 64. PSW Register

PSW (S:8Eh) – Program Status Word Register

7	6	5	4	3	2	1	0
СҮ	AC	F0	RS1	RS0	ov	F1	Р
Bit Number	Bit Mnemonic	Description					
7	CY	Carry Flag Carry out from	n bit 1 of ALL	J operands.			
6	AC	Auxiliary Ca Carry out from	Auxiliary Carry Flag Carry out from bit 1 of addition operands.				
5	F0	User Defina	ble Flag 0				
4-3	RS1:0	Register Ba	nk Select Bit e 63 for bits c	s lescription.			
2	OV	Overflow Fla Overflow set	Overflow Flag Overflow set by arithmetic operations.				
1	F1	User Defina	User Definable Flag 1				
0	Р	Parity Bit Set when AC Cleared whe	Parity Bit Set when ACC contains an odd number of 1's. Cleared when ACC contains an even number of 1's.				

Table 65. MEMCBAX Register

MEMCBAX (0.F2h) - Memory Management CODE Base Address Register

7	6	5	4	3	2	1	0
CBAX16	CBAX15	CBAX14	CBAX13	CBAX12	CBAX11	CBAX10	CBAX9
Bit Number	Bit Mnemonic	Description					
7-0	CBAX16:9	CODE Base 17-bit CODE 512-byte alig	Address Mos Base Addres nment, no off	st Significant s: X XXXX XX set.	Bits of Cont (X0 0000 000)	ext MEMPID Ob.	

Reset Value MEMCBA0 = 0 0000 000b

Table 66. MEMDBAX Register

MEMDBAX (0.F3h) - Memory Management DATA Base Address Register

7	6	5	4	3	2	1	0	
DBAX16	DBAX15	DBAX14	DBAX13	DBAX12	DBAX11	DBAX10	DBAX9	
Bit Number	Bit Mnemonic	Description						
7-0	DBAX16:9	DATA Base 17-bit DATA 512-byte alig	DATA Base Address Most Significant Bits of Context MEMPID 17-bit DATA Base Address: X XXXX XXX1 0000 0000b. 512-byte alignment with 256-byte offset.					

Reset Value MEMDBAX = 0 1111 111b

Table 67. MEMXBAX Register

MEMXBAX (0.F4h) – Memory Management XDATA Base Address Registers

7	6	5	4	3	2	1	0
XBAX16	XBAX15	XBAX14	XBAX13	XBAX12	XBAX11	XBAX10	XBAX9
Bit Number	Bit Mnemonic	Description					
7-0	XBAX16:9	XDATA Base 17-bit CODE 512-byte alig	XDATA Base Address Most Significant Bits of Context MEMPID 17-bit CODE Base Address: X XXXX XXX0 0000 0000b. 512-byte alignment, no offset.				

Reset Value MEMXBAX = 0 1111 000b

Table 68. MEMCSX Register

MEMCSX (0.F5h) – Memory Management CODE Size Register

7	6	5	4	3	2	1	0
CSX7	CSX6	CSX5	CSX4	CSX3	CSX2	CSX1	CSX0





Bit Number	Bit Mnemonic	Description
7-0	CSX7:0	CODE Size Bits of Context MEMPID Size is equals to (CSX+1) x 256 bytes. CODE sizes available: from 256 bytes to 64 Kbytes, by 256-byte steps.

Reset Value MEMCSX = 1110 1111b

Table 69. MEMXSX Register

MEMXSX (0.F6h) - Memory Management XDATA Size Register

7	6	5	4	3	2	1	0	
XSX7	XSX6	XSX5	XSX4	XSX3	XSX2	XSX1	XSX0	
Bit Number	Bit Mnemonic	Description						
7-0	XSX7:0	XDATA Size Size is equal XDATA sizes	XDATA Size Bits of Context MEMPID Size is equals to (XSX+1) x 256 bytes. XDATA sizes available: from 256 bytes to 64 Kbytes, by 256-byte steps.					

Reset Value MEMXSX = 0000 1110b

Interrupt System

The AT85C51SND3B derivatives, like other control-oriented computer architectures, employ a program interrupt method. This operation branches to a subroutine and performs some service in response to the interrupt. When the subroutine completes, execution resumes at the point where the interrupt occurred. Interrupts may occur as a result of internal AT85C51SND3B activity (e.g., timer overflow) or at the initiation of electrical signals external to the microcontroller (e.g., keyboard). In all cases, interrupt operation is programmed by the system designer, who determines priority of interrupt service relative to normal code execution and other interrupt service routines. All of the interrupt sources are enabled or disabled by the system designer and may be manipulated dynamically.

A typical interrupt event chain occurs as follows:

- An internal or external device initiates an interrupt-request signal. The AT85C51SND3B latches this event into a flag buffer.
- The priority of the flag is compared to the priority of other interrupts by the interrupt handler. A high priority causes the handler to set an interrupt flag.
- This signals the instruction execution unit to execute a context switch. This context switch breaks the current flow of instruction sequences. The execution unit completes the current instruction prior to a save of the program counter (PC) and reloads the PC with the start address of a software service routine.
- The software service routine executes assigned tasks and as a final activity performs a RETI (return from interrupt) instruction. This instruction signals completion of the interrupt, resets the interrupt-in-progress priority and reloads the program counter. Program operation then continues from the original point of interruption.

Six interrupt registers are used to control the interrupt system:

- Two 8-bit registers are used to enable separately the interrupt sources: IEN0 and IEN1 registers (see Table 72 and Table 73).
- Four 8-bit registers are used to establish the priority level of the different sources: IPH0, IPL0, IPH1 and IPL1 registers (see Table 74 to Table 77).

Interrupt System **Priorities**

Each interrupt sources of the AT85C51SND3B can be individually programmed to one of four priority levels. This is accomplished by one bit in the Interrupt Priority High registers (IPH0 and IPH1) and one bit in the Interrupt Priority Low registers (IPL0 and IPL1). This provides each interrupt source four possible priority levels according to Table 70.

IPHxx	IPLxx	Priority Level
0	0	0 Lowest
0	1	1
1	0	2
1	1	3 Highest

Table 70. Priority Levels

A low-priority interrupt is always interrupted by a higher priority interrupt but not by another interrupt of lower or equal priority. Higher priority interrupts are serviced before lower priority interrupts. The response to simultaneous occurrence of equal priority interrupts is determined by an internal hardware polling sequence detailed in Table 71. Thus, within each priority level there is a second priority structure determined by the polling sequence. The interrupt control system is shown in Interrupt Control System.





Table 71.	Priority	Within	Same	Level
		••••••	ouno	-0101

Interrupt Name	Priority Number	Interrupt Address Vectors	Interrupt Request Flag Cleared by Hardware (H) or by Software (S)
ĪNT0	0 (Highest Priority)	C:0003h	H if edge, S if level
Timer 0	1	C:000Bh	Н
INT1	2	C:0013h	H if edge, S if level
Timer 1	3	C:001Bh	Н
Serial I/O Port	4	C:0023h	S
Data Flow Controller	5	C:002Bh	S
Audio Processor	6	C:0033h	S
USB Controller	7	C:003Bh	S
Keyboard	8	C:0043h	S
Parallel Slave Interface	9	C:004Bh	S
Serial Peripheral Interface	10	C:0053h	S
Nand Flash Controller	11	C:005Bh	S
MMC Controller	12	C:0063h	S
Reserved	13	C:006Bh	-
Reserved	14 (Lowest Priority)	C:0073h	-



Figure 28. Interrupt Control System





External Interrupts

INT1:0 Inputs

External interrupts $\overline{INT0}$ and $\overline{INT1}$ (\overline{INTn} , n = 0 or 1) pins may each be programmed to be level-triggered or edge-triggered, dependent upon bits IT0 and IT1 (ITn, n = 0 or 1) in TCON register as shown in INT1:0 Input Circuitry. If ITn = 0, INTn is triggered by a low level at the pin. If ITn = 1, INTn is negative-edge triggered. External interrupts are enabled with bits EX0 and EX1 (EXn, n = 0 or 1) in IEN0. Events on INTn set the interrupt request flag IEn in TCON register. If the interrupt is edge-triggered, the request flag is cleared by hardware when vectoring to the interrupt service routine. If the interrupt is level-triggered, the interrupt service routine must clear the request flag and the interrupt must be de-asserted before the end of the interrupt service routine.

INTO and INT1 inputs provide both the capability to exit from Power-down mode on low level signals as detailed in Section "Exiting Power-down Mode", page 22.

Figure 29. INT1:0 Input Circuitry



KIN3:0 Inputs External interrupts KIN0 to KIN3 provide the capability to connect a matrix keyboard. For detailed information on these inputs, refer to Section "Keyboard Interface", page 240.

Input Sampling

External interrupt pins (INT1:0 and KIN3:0) are sampled once per peripheral cycle (6 peripheral clock periods) (see Minimum Pulse Timings). A level-triggered interrupt pin held low or high for more than 6 peripheral clock periods (12 oscillator in standard mode or 6 oscillator clock periods in X2 mode) guarantees detection. Edge-triggered external interrupts must hold the request pin low for at least 6 peripheral clock periods.

Figure 30. Minimum Pulse Timings



Registers

Table 72. IEN0 Register

IEN0 (0.A8h) - Interrupt Enable Register 0

7	6	5	4	3	2	1	0		
EA	EAUP	EDFC	ES	ET1	EX1	ET0	EX0		
Bit Number	Bit Mnemonic	Description							
7	EA	Enable All II Set to enable Clear to disa If EA = 1, ea clearing its ir	Thable All Interrupt Bit Tet to enable all interrupts. Flear to disable all interrupts. EA = 1, each interrupt source is individually enabled or disabled by setting or learing its interrupt enable bit.						
6	EAUP	AUP Interru Set to enable Clear to disa	UP Interrupt Enable Bit et to enable audio processor interrupt. clear to disable audio processor interrupt.						
5	EDFC	DFC Enable Set to enable Clear to disa	DFC Enable Bit Set to enable data flow interrupt. Clear to disable data flow interrupt.						
4	ES	SIO Interrup Set to enable Clear to disa	SIO Interrupt Enable Bit Set to enable serial port interrupt. Clear to disable serial port interrupt.						
3	ET1	T1 Overflow Set to enable Clear to disa	timer 1 over ble timer 1 over	a ble Bit flow interrupt. erflow interrup	ot.				
2	EX1	EX1 Interrup Set to enable Clear to disa	ot Enable bit e external inte ble external ir	rrupt 1. nterrupt 1.					
1	ET0	T0 Overflow Set to enable Clear to disa	timer 0 over ble timer 0 over	a ble Bit flow interrupt. erflow interrup	ot.				
0	EX0	EX0 Interrup Set to enable Clear to disa	ot Enable Bit e external inte ble external ir	rrupt 0. nterrupt 0.					





Table 73. IEN1 Register

IEN1 (0.B1h) - Interrupt Enable Register 1

7	6	5	4	3	2	1	0		
-	-	EMMC	ENFC	ESPI	EPSI	EKB	EUSB		
Bit Number	Bit Mnemonic	Description							
7-6	-	Reserved The value re	Reserved The value read from these bits is always 0. Do not set these bits.						
5	EMMC	MMC/SD Int Set to enable Clear to disa	IMC/SD Interrupt Enable Bit et to enable MMC/SD interrupt. clear to disable MMC/SD interrupt.						
4	ENFC	NFC Interru Set to enable Clear to disa	NFC Interrupt Enable Bit Set to enable IDE interrupt. Clear to disable IDE interrupt.						
3	ESPI	SPI Interrup Set to enable Clear to disa	t Enable Bit SPI interrupt ble SPI interru	t. upt.					
2	EPSI	PSI Interrup Set to enable Clear to disa	PSI Interrupt Enable Bit Set to enable PSI interrupt. Clear to disable PSI interrupt.						
1	ЕКВ	KBD Interru Set to enable Clear to disa	pt Enable Bi t e Keyboard in ble Keyboard	t terrupt. interrupt.					
0	EUSB	USB Interru Set this bit to Clear this bit	pt Enable Bit enable USB to disable US	interrupt. B interrupt.					

Table 74. IPH0 Register

IPH0 (0.B7h) – Interrupt Priority High Register 0

7	6	5	4	3	2	1	0		
-	IPHAUP	IPHDFC	IPHS	IPHT1	IPHX1	IPHT0	IPHX0		
Bit Number	Bit Mnemonic	Description	Description						
7	-	Reserved The value re	eserved he value read from this bit is indeterminate. Do not set this bit.						
6	IPHAUP	AUP Interru Refer to Tabl	UP Interrupt Priority Level Msb efer to Table 70 for priority level description.						
5	IPHDFC	DFC Interru Refer to Tabl	DFC Interrupt Priority Level Msb Refer to Table 70 for priority level description.						
4	IPHS	SIO Interrup Refer to Tabl	e 70 for priority	vel Msb ty level descrij	otion.				
3	IPHT1	T1 Interrupt Refer to Tabl	Priority Leve e 70 for priori	el Msb ty level descrij	otion.				
2	IPHX1	EX1 Interrup Refer to Tabl	ot Priority Leve e 70 for priori	vel Msb ty level descrij	otion.				
1	IPHT0	T0 Interrupt Refer to Tabl	Priority Leve e 70 for priori	el Msb ty level descrij	otion.				
0	IPHX0	EX0 Interrup Refer to Tabl	ot Priority Leve e 70 for priori	vel Msb ty level descrij	otion.				





Table 75. IPH1 Register

IPH1 (0.B3h) – Interrupt Priority High Register 1

7	6	5	4	3	2	1	0		
-	-	IPHMMC	IPHNFC	IPHSPI	IPHSPI	IPHKB	IPHUSB		
Bit Number	Bit Mnemonic	Description	Description						
7-6	-	Reserved The value re	Reserved The value read from these bits is always 0. Do not set these bits.						
5	IPHMMC	MMC/SD Int Refer to Tabl	MMC/SD Interrupt Priority Level Msb Refer to Table 70 for priority level description.						
4	IPHNFC	NFC Interru Refer to Tabl	NFC Interrupt Priority Level Msb Refer to Table 70 for priority level description.						
3	IPHSPI	SPI Interrup Refer to Tabl	t Priority Lev e 70 for priori	vel Msb ty level descrij	ption.				
2	IPHPSI	PSI Interrup Refer to Tabl	t Priority Lev e 70 for priori	vel Msb ty level descri	ption.				
1	ІРНКВ	KBD Interru Refer to Tabl	pt Priority Le e 70 for priori	e vel Msb ty level descri	ption.				
0	IPHUSB	USB Interru Refer to Tabl	pt Priority Le e 70 for priori	ty level descri	ption.				

Table 76. IPL0 Register

IPL0 (0.B8h) - Interrupt Priority Low Register 0

7	6	5	4	3	2	1	0		
-	IPLAUP	IPLDFC	IPLS	IPLT1	IPLX1	IPLT0	IPLX0		
Bit Number	Bit Mnemonic	Description	Description						
7	-	Reserved The value rea	Reserved The value read from this bit is indeterminate. Do not set this bit.						
6	IPLAUP	AUP Interru Refer to Tabl	AUP Interrupt Priority Level Lsb Refer to Table 70 for priority level description.						
5	IPLDFC	DFC Interru Refer to Tabl	DFC Interrupt Priority Level Lsb Refer to Table 70 for priority level description.						
4	IPLS	SIO Interrup Refer to Tabl	e 70 for priori	vel Lsb ty level descrij	ption.				
3	IPLT1	T1 Interrupt Refer to Tabl	Priority Leve e 70 for priori	∍l Lsb ty level descrij	ption.				
2	IPLX1	EX1 Interrup Refer to Tabl	ot Priority Le e 70 for priori	vel Lsb ty level descrij	ption.				
1	IPLT0	T0 Interrupt Refer to Tabl	Priority Leve e 70 for priori	el Lsb ty level descrij	ption.				
0	IPLX0	EX0 Interrup Refer to Tabl	ot Priority Le e 70 for priori	vel Lsb ty level descrij	ption.				





Table 77. IPL1 Register

IPL1 (0.B2h) - Interrupt Priority Low Register 1

7	6	5	4	3	2	1	0			
-	-	IPLMMC	IPLNFC	IPLSPI	IPLPSI	IPLKB	IPLUSB			
Bit Number	Bit Mnemonic	Description	Description							
7-6	-	Reserved The value re	leserved The value read from these bits is always 0. Do not set these bits.							
5	IPLMMC	MMC/SD Int Refer to Tab	MMC/SD Interrupt Priority Level Lsb Refer to Table 70 for priority level description.							
4	IPLNFC	NFC Interru Refer to Tab	NFC Interrupt Priority Level Lsb Refer to Table 70 for priority level description.							
3	IPLSPI	SPI Interrup Refer to Tab	t Priority Lev e 70 for priori	vel Lsb ty level descri	otion.					
2	IPLPSI	PSI Interrup Refer to Tab	t Priority Lev e 70 for priori	vel Lsb ty level descrij	otion.					
1	IPLKB	KBD Interru Refer to Tab	pt Priority Le e 70 for priori	e vel Lsb ty level descri	otion.					
0	IPLUSB	USB Interru Refer to Tab	pt Priority Le e 70 for priori	e vel Lsb ty level descri	otion.					

Timers/Counters	The AT85C51SND3B derivatives implement 2 general-purpose, 16-bit Timers/Counters. They are identified as Timer 0 and Timer 1, and can be independently configured to operate in a variety of modes as a Timer or as an event Counter. When operating as a Timer, the Timer/Counter runs for a programmed length of time, then issues an interrupt request. When operating as a Counter, the Timer/Counter counts negative transitions on an external pin. After a preset number of counts, the Counter issues an interrupt request.
	The sector sector sector sector set and the transformed to the sector sect

The various operating modes of each Timer/Counter are described in the following sections.

Timer/CounterFor instance, a basic operation is Timer registers THx and TLx (x = 0, 1) connected in
cascade to form a 16-bit Timer. Setting the run control bit (TRx) in TCON register (see
Table 81) turns the Timer on by allowing the selected input to increment TLx. When TLx
overflows it increments THx; when THx overflows it sets the Timer overflow flag (TFx) in
TCON register. Setting the TRx does not clear the THx and TLx Timer registers. Timer
registers can be accessed to obtain the current count or to enter preset values. They
can be read at any time but TRx bit must be cleared to preset their values, otherwise,
the behavior of the Timer/Counter is unpredictable.

The C/Tx# control bit selects Timer operation or Counter operation by selecting the divided-down peripheral clock or external pin Tx as the source for the counted signal. TRx bit must be cleared when changing the mode of operation, otherwise the behavior of the Timer/Counter is unpredictable.

For Timer operation (C/Tx# = 0), the Timer register counts the divided-down peripheral clock. The Timer register is incremented once every peripheral cycle (6 peripheral clock periods). The Timer clock rate is $F_{PER}/6$, i.e., $F_{OSC}/12$ in standard mode or $F_{OSC}/6$ in X2 mode.

For Counter operation (C/Tx# = 1), the Timer register counts the negative transitions on the Tx external input pin. The external input is sampled every peripheral cycles. When the sample is high in one cycle and low in the next one, the Counter is incremented. Since it takes 2 cycles (12 peripheral clock periods) to recognize a negative transition, the maximum count rate is $F_{PER}/12$, i.e., $F_{OSC}/24$ in standard mode or $F_{OSC}/12$ in X2 mode. There are no restrictions on the duty cycle of the external input signal, but to ensure that a given level is sampled at least once before it changes, it should be held for at least one full peripheral cycle.

Timer Clock Controller As shown in Figure 31, the Timer 0 (FT0) and Timer 1 (FT1) clocks are derived from either the peripheral clock (F_{PER}) or the oscillator clock (F_{OSC}) depending on the T0X2 and T1X2 bits in CKCON register. These clocks are issued from the Clock Controller block as detailed in Section "Oscillator", page 28. When T0X2 or T1X2 bit is set, the Timer 0 or Timer 1 clock frequency is fixed and equal to the oscillator clock frequency divided by 2. When cleared, the Timer clock frequency is equal to the oscillator clock frequency divided by 2 in standard mode or to the oscillator clock frequency in X2 mode.









Timer 0

Timer 0 functions as either a Timer or event Counter in four modes of operation. Figure 32, Figure 34, Figure 36, and Figure 38 show the logical configuration of each mode.

Timer 0 is controlled by the four lower bits of TMOD register (see Table 82) and bits 0, 1, 4 and 5 of TCON register (see Table 81). TMOD register selects the method of Timer gating (GATE0), Timer or Counter operation (C/T0#) and mode of operation (M10 and M00) according to Table 78. TCON register provides Timer 0 control functions: overflow flag (TF0), run control bit (TR0), interrupt flag (IE0) and interrupt type control bit (IT0).

For normal Timer operation (GATE0 = 0), setting TR0 allows TL0 to be incremented by the selected input. Setting GATE0 and TR0 allows external pin $\overline{INT0}$ to control Timer operation.

Timer 0 overflow (count rolls over from all 1s to all 0s) sets TF0 flag generating an interrupt request.

It is important to stop Timer/Counter before changing mode.

M10	M00	Mode	Operation
0	0	0	8-bit Timer/Counter (TH0) with 5-bit prescaler (TL0).
0	1	1	16-bit Timer/Counter.
1	0	2	8-bit auto-reload Timer/Counter (TL0).
1	1	3	TL0 is an 8-bit Timer/Counter. TH0 is an 8-bit Timer using Timer 1's TR0 and TF0 bits.

Table 78. Timer/counter 0 Operating Modes

Mode 0 (13-bit Timer)

Mode 0 configures Timer 0 as a 13-bit Timer which is set up as an 8-bit Timer (TH0 register) with a modulo 32 prescaler implemented with the lower five bits of TL0 register (see Figure 32). The upper three bits of TL0 register are indeterminate and should be ignored. Prescaler overflow increments TH0 register. Figure 33 gives the overflow period calculation formula.





Figure 33. Mode 0 Overflow Period Formula



Mode 1 (16-bit Timer)Mode 1 configures Timer 0 as a 16-bit Timer with TH0 and TL0 registers connected in
cascade (see Figure 34). The selected input increments TL0 register. Figure 35 gives
the overflow period calculation formula when in timer mode.

Figure 34. Timer/Counter x (x = 0 or 1) in Mode 1



Figure 35. Mode 1 Overflow Period Formula



Mode 2 (8-bit Timer with Auto-Reload)

Mode 2 configures Timer 0 as an 8-bit Timer (TL0 register) that automatically reloads from TH0 register (see Figure 36). TL0 overflow sets TF0 flag in TCON register and reloads TL0 with the contents of TH0, which is preset by software. When the interrupt request is serviced, hardware clears TF0. The reload leaves TH0 unchanged. The next reload value may be changed at any time by writing it to TH0 register. Figure 37 gives the auto-reload period calculation formula when in timer mode.











$$TFx_{PER} = \frac{6 \cdot (256 - THx)}{F_{TIMx}}$$

Mode 3 (2 x 8-bit Timers) Mode 3 configures Timer 0 such that registers TL0 and TH0 operate as separate 8-bit Timers (see Figure 38). This mode is provided for applications requiring an additional 8-bit Timer or Counter. TL0 uses the Timer 0 control bits C/T0# and GATE0 in TMOD register, and TR0 and TF0 in TCON register in the normal manner. TH0 is locked into a Timer function (counting F_{TF1} /6) and takes over use of the Timer 1 interrupt (TF1) and run control (TR1) bits. Thus, operation of Timer 1 is restricted when Timer 0 is in mode 3. Figure 39 gives the auto-reload period calculation formulas for both TF0 and TF1 flags.







$$TF0_{PER} = \frac{6 \cdot (256 - TL0)}{F_{TIM0}} \qquad TF1_{PER} = \frac{6 \cdot (256 - TH0)}{F_{TIM0}}$$

Timer 0 Enhanced Mode

Timer 0 overflow period can be increased in all modes by enabling a divider as detailed in Figure 40. This mode is implemented to allow higher time periods as it can be used for example as a scheduler time base with auto-reload (mode 2).

Timer 0 enhanced mode is enabled by programming T0ETB2:0 bits in SCHCLK (see Table 87) to a value other than 000b and according to Table 79.

Figure 40. Timer/Counter 0 Enhanced Mode



 Table 79.
 Timer/counter 0 Enhanced Overflow Period

T0ETB2	T0ETB1	T0ETB0	New TF0 Overflow Period
0	0	0	TF0 _{PER} ÷ 1 (divider disable)
0	0	1	TF0 _{PER} ÷ 2
0	1	0	$TF0_{PER} \div 4$
0	1	1	TF0 _{PER} ÷ 8
1	0	0	TF0 _{PER} ÷ 16
1	0	1	TF0 _{PER} ÷ 32
1	1	0	TF0 _{PER} ÷ 64
1	1	1	TF0 _{PER} ÷ 128

Timer 1 is identical to Timer 0 except for Mode 3 which is a hold-count mode and for the enhanced mode which is not available. The following comments help to understand the differences:

- Timer 1 functions as either a Timer or event Counter in three modes of operation. Figure 32, Figure 34, and Figure 36 show the logical configuration for modes 0, 1, and 2. Timer 1's mode 3 is a hold-count mode.
- Timer 1 is controlled by the four high-order bits of TMOD register (see Table 82) and bits 2, 3, 6 and 7 of TCON register (see Table 81). TMOD register selects the method of Timer gating (GATE1), Timer or Counter operation (C/T1#) and mode of operation (M11 and M01) according to Table 80. TCON register provides Timer 1 control functions: overflow flag (TF1), run control bit (TR1), interrupt flag (IE1) and interrupt type control bit (IT1).
- Timer 1 can serve as the Baud Rate Generator for the Serial Port. Mode 2 is best suited for this purpose.
- For normal Timer operation (GATE1 = 0), setting TR1 allows TL1 to be incremented by the selected input. Setting GATE1 and TR1 allows external pin INT1 to control Timer operation.
- Timer 1 overflow (count rolls over from all 1s to all 0s) sets the TF1 flag generating an interrupt request.
- When Timer 0 is in mode 3, it uses Timer 1's overflow flag (TF1) and run control bit (TR1). For this situation, use Timer 1 only for applications that do not require an interrupt (such as a Baud Rate Generator for the Serial Port) and switch Timer 1 in and out of mode 3 to turn it off and on.



Timer 1



It is important to stop the Timer/Counter before changing modes.

	M11	M01	Mode	Operation				
	0	0	0	8-bit Timer/Counter (TH1) with 5-bit prescaler (TL1).				
	0	1	1	16-bit Timer/Counter.				
	1	0	2	8-bit auto-reload Timer/Counter (TL1).				
	1	1	3	Timer/Counter halted. Retains count.				
Mode 0 (13-bit Timer)	Mode 0 configures Timer 1 as a 13-bit Timer, which is set up as an 8-bit Timer (TH1 reg- ster) with a modulo-32 prescaler implemented with the lower 5 bits of the TL1 register (see Figure 32). The upper 3 bits of TL1 register are ignored. Prescaler overflow incre- ments TH1 register.							
Mode 1 (16-bit Timer)	Mode 1 configures Timer 1 as a 16-bit Timer with TH1 and TL1 registers connected in cascade (see Figure 34). The selected input increments TL1 register.							
Mode 2 (8-bit Timer with Auto- Reload)	Mode 2 cor TH1 registe and reload leaves TH1	nfigures Tim er on overflo s TL1 with unchanged	er 1 as an w (see Figu the conten I.	8-bit Timer (TL1 register) with automatic reload from ure 36). TL1 overflow sets TF1 flag in TCON register ts of TH1, which is preset by software. The reload				
Mode 3 (Halt)	Placing Tim Timer 1 whe	er 1 in mod en TR1 run	le 3 causes control bit is	it to halt and hold its count. This can be used to halt s not available i.e. when Timer 0 is in mode 3.				
Interrupt	Each Timer flag is set e interrupt ro assumes in	handles on very time ar outine. Inte terrupts are	e interrupt s n overflow c rrupts are globally en	source that is the timer overflow flag TF0 or TF1. This occurs. Flags are cleared when vectoring to the Timer enabled by setting ETx bit in IEN0 register. This abled by setting EA bit in IEN0 register.				

 Table 80.
 Timer/counter 1 Operating Modes

٠

Figure 41. Timer Interrupt System



Registers

Table 81. TCON Register

TCON (0.88h) – Timer/Counter Control Register

7	6	5	4	3	2	1	0		
TF1	TR1	TF0	TR0	IE1	IT1	IE0	IT0		
Bit Number	Bit Mnemonic	Description							
7	TF1	Timer 1 Ove Cleared by h Set by hardw	Fimer 1 Overflow Flag Cleared by hardware when processor vectors to interrupt routine. Set by hardware on Timer/Counter overflow, when Timer 1 register overflows.						
6	TR1	Timer 1 Run Clear to turn Set to turn or	Fimer 1 Run Control Bit Clear to turn off Timer/Counter 1. Set to turn on Timer/Counter 1.						
5	TF0	Timer 0 Ove Cleared by h Set by hardw	Timer 0 Overflow Flag Cleared by hardware when processor vectors to interrupt routine. Set by hardware on Timer/Counter overflow, when Timer 0 register overflows.						
4	TR0	Timer 0 Run Clear to turn Set to turn or	Timer 0 Run Control Bit Clear to turn off Timer/Counter 0. Set to turn on Timer/Counter 0.						
3	IE1	Interrupt 1 E Cleared by h Set by hardw	dge Flag ardware whe vare when ext	n interrupt is p ernal interrupt	rocessed if ec is detected o	lg <u>e-trigg</u> ered (n INT1 pin.	see IT1).		
2	IT1	Interrupt 1 T Clear to sele Set to select	ype Control ct low level ad falling edge a	Bit ctive (level trig active (edge tri	gered) for ext ggered) for ex	ernal interrupt kternal interrup	1 (INT1). pt 1.		
1	IE0	Interrupt 0 E Cleared by h Set by hardw	dge Flag ardware whe vare when ext	n interrupt is p ernal interrupt	rocessed if ec is detected o	lg <u>e-trigg</u> ered (n INT0 pin.	(see IT0).		
0	ITO	Interrupt 0 T Clear to sele Set to select	ype Control ct low level ad falling edge a	Bit ctive (level trig active (edge tri	gered) for ext ggered) for ex	ernal interrupt kternal interrup	0 (INT0). ot 0.		





Table 82. TMOD Register

TMOD (0.89h) – Timer/Counter Mode Control Register

7	6	5	4	3	2	1	0		
GATE1	C/T1#	M11	M01	GATE0	C/T0#	M10	M00		
Bit Number	Bit Mnemonic	Description							
7	GATE1	Timer 1 Gat Clear to enal Set to enable	Fimer 1 Gating Control Bit Clear to enable Timer 1 whenever TR1 bit is set. Set to enable Timer 1 only while INT1 pin is high and TR1 bit is set.						
6	C/T1#	Timer 1 Cou Clear for Tim Set for Coun	Timer 1 Counter/Timer Select Bit Clear for Timer operation: Timer 1 counts the divided-down system clock. Set for Counter operation: Timer 1 counts negative transitions on external pin T1.						
5	M11	Timer 1 Mod	le Select Bits	5					
4	M01	Refer to Tabl	e 80 for Time	r 1 operation.					
3	GATE0	Timer 0 Gat Clear to enal Set to enable	i ng Control E ole Timer 0 wl e Timer/Count	Bit henever TR0 b er 0 only while	pi <u>t is s</u> et. e INT0 pin is h	igh and TR0 t	oit is set.		
2	C/T0#	Timer 0 Cou Clear for Tim Set for Coun	nter/Timer S er operation: ter operation:	elect Bit Timer 0 count Timer 0 count	s the divided- s negative tra	down system nsitions on ex	clock. ternal pin T0.		
1	M10	Timer 0 Mod	le Select Bit						
0	M00	Refer to Tabl	e 78 for Time	r 0 operation.					

Reset Value = 0000 0000b

Table 83. TH0 Register

TH0 (0.8Ch) - Timer 0 High Byte Register

7	6	5	4	3	2	1	0
-	-	-	-	-	-	-	-
Bit Number	Bit Mnemonic	Description					
7-0		High Byte of Timer 0					
Table 84. TL0 Register

TL0 (0.8Ah) - Timer 0 Low Byte Register

7	6	5	4	3	2	1	0		
-	-	-	-	-	-	-	-		
Bit Number	Bit Mnemonic	Description	Description						
7-0		Low Byte of	Timer 0						

Reset Value = 0000 0000b

Table 85. TH1 Register

TH1 (0.8Dh) – Timer 1 High Byte Register

7	6	5	4	3	2	1	0	
-	-	-	-	-	-	-	-	
Bit Number	Bit Mnemonic	Description						
7-0		High Byte of	f Timer 1					

Reset Value = 0000 0000b

Table 86. TL1 Register

TL1 (0.8Bh) – Timer 1 Low Byte Register

7	6	5	4	3	2	1	0	
-	-	-	-	-	-	-	-	
Bit Number	Bit Mnemonic	Description						
7-0		Low Byte of	Timer 1					

Reset Value = 0000 0000b





Table 87. SCHCLK Register

SCHCLK (0.FEh) – Scheduler Clocks Register

7	6	5	4	3	2		1	0
-	T0ETB2	T0ETB1	T0ETB0	-	-		-	-
Bit Number	Bit Mnemonic	Description						
7	-	Reserved The value rea	Reserved The value read from this bit is always 0. Do not set this bit.					
6-4	T0ETB2:0	Timer 0 Enh Refer to Tabl	i mer 0 Enhanced Time Base Bits Refer to Table 79 for dividing values.					
3-0	-	Reserved The value rea	ad from these	bits is always	s 0. Do not	set these	bits.	

Reset Value = 0000 0000b

Watchdog Timer

The AT85C51SND3B derivatives implement a hardware Watchdog Timer (WDT) that automatically resets the chip if it is allowed to time out. The WDT provides a means of recovering from routines that do not complete successfully due to software or hardware malfunctions.

Description

The WDT consists of a 14-bit prescaler followed by a 7-bit programmable counter. As shown in Figure 42, the 14-bit prescaler is fed by the WDT clock detailed in Section "Clock Controller".

The Watchdog Timer Reset register (WDTRST, see Table 89) provides control access to the WDT, while the Watchdog Timer Program register (WDTPRG, see Figure 90) provides time-out period programming.

Three operations control the WDT:

- Chip reset clears and disables the WDT.
- Programming the time-out value to the WDTPRG register.
- Writing a specific 2-Byte 1Eh-E1h sequence to the WDTRST register clears and enables the WDT.

Figure 42. WDT Block Diagram



Clock Controller

As shown in Figure 43 the WDT clock (F_{WDT}) is derived from either the peripheral clock (F_{PER}) or the oscillator clock (F_{OSC}) depending on the WTX2 bit in CKCON register. These clocks are issued from the Clock Controller block as detailed in Section "Oscillator", page 28. When WTX2 bit is set, the WDT clock frequency is fixed and equal to the oscillator clock frequency divided by 2. When cleared, the WDT clock frequency is equal to the oscillator clock frequency divided by 2 in standard mode or to the oscillator clock frequency in X2 mode.









Operation

After reset, the WDT is disabled. The WDT is enabled by writing the sequence 1Eh and E1h into the WDTRST register. As soon as it is enabled, there is no way except the chip reset to disable it. If it is not cleared using the previous sequence, the WDT overflows and forces a chip reset. This overflow generates a low level 96 oscillator periods pulse on the RST pin to globally reset the application (refer to Section "Watchdog Timer Reset", page 25).

The WDT time-out period can be adjusted using WTO2:0 bits located in the WDTPRG register accordingly to the formula shown in Figure 44. In this formula, WTOval represents the decimal value of WTO2:0 bits. Table 88 reports the time-out period depending on the WDT frequency.

Figure 44. WDT Time-Out Formula

$$WDT_{TO} = \frac{6 \cdot (2^{14} \cdot 2^{WTOval})}{F_{WDT}}$$

					WD)T _{TO} (ms) / F	WDT		
WTO2	WTO1	WTO0	6 MHz ⁽¹⁾	8 MHz ⁽¹⁾	10 MHz ⁽¹⁾	12 MHz	16 MHz ⁽²⁾	20 MHz ⁽²⁾	24 MHz ⁽²⁾
0	0	0	16.38	12.28	9.83	8.19	6.14	4.92	4.1
0	0	1	32.77	24.57	19.66	16.38	12.28	9.83	8.19
0	1	0	65.54	49.14	39.32	32.77	24.57	19.66	16.36
0	1	1	131.07	98.28	78.64	65.54	49.14	39.32	32.77
1	0	0	262.14	196.56	157.29	131.07	98.28	78.64	65.54
1	0	1	524.29	393.1	314.57	262.14	196.56	157.29	131.07
1	1	0	1049	786.24	629.15	524.29	393.12	314.57	262.14
1	1	1	2097	1572	1258	1049	786.24	629.15	524.29

Table 88. WDT Time-Out Computation

Notes: 1. These frequencies are achieved in X1 mode or in X2 mode when WTX2 = 1:

- $F_{WDT} = F_{OSC} \div 2.$
- 2. These frequencies are achieved in X2 mode when WTX2 = 0: $F_{WDT} = F_{OSC}$.

Operation of the WDT during power reduction modes deserves special attention.

The WDT continues to count while the CPU core is in Idle mode. This means that you must dedicate some internal or external hardware to service the WDT during Idle mode. One approach is to use a peripheral Timer to generate an interrupt request when the Timer overflows. The interrupt service routine then clears the WDT, reloads the peripheral Timer for the next service period and puts the CPU core back into Idle mode.

The Power-down mode stops all phase clocks. This causes the WDT to stop counting and to hold its count. The WDT resumes counting from where it left off if the Power-down mode is terminated by INTO, INT1 or keyboard interrupt. To ensure that the WDT does not overflow shortly after exiting the Power-down mode, it is recommended to clear the WDT just before entering Power-down mode.

The WDT is cleared and disabled if the Power-down mode is terminated by a reset.

Behavior during Idle and Power-down Modes

Registers

Table 89. WDTRST Register

WDTRST (0.A6h Write only) - Watchdog Timer Reset Register

7	6	5	4	3	2	1	0		
-	-	-	-	-	-	-	-		
Bit Number	Bit Mnemonic	Description	Description						
7-0	-	Watchdog C	ontrol Value						

Reset Value = XXXX XXXXb

Table 90. WDTPRG Register

WDTPRG (0.A7h) – Watchdog Timer Program Register

7	6	5	4	3	2	1	0		
-	-	-	-	-	WTO2	WTO1	WTO0		
Bit Number	Bit Mnemonic	Description							
7-3	-	Reserved The value rea	Reserved The value read from these bits is indeterminate. Do not set these bits.						
2-0	WTO2:0	Watchdog T Refer to Tabl	imer Time-O e 88 for time-	ut Selection E out periods.	Bits				

Reset Value = XXXX X000b





Data Flow Controller

The Data Flow Controller (DFC) implemented in the AT85C51SND3B derivatives is the multimedia data transfer manager. Up to two data transfers can be established through two physical data channels between a source peripheral and a destination peripheral. Figure 45 shows which peripherals are connected to the internal bus which are: the CPU internal bus, the multimedia data bus and the DFC control bus.

Figure 45. DFC Internal Architecture



CPU Interface	The DFC interfaces to the C51 core through the following special function registers: DFCON the DFC control register, DFCSTA the channel status register, DFCCON the channel control register, DFD0 and DFD1, the physical channel 0 and channel 1 data flow descriptor registers and DFCRC the CRC data register.
Clock Unit	The DFC clock is generated based on the clock generator as detailed in Section "DFC/NFC Clock Generator", page 31. Depending on the power mode (USB powered or battery powered) and the throughput desired, different clock values may be selected to control the data transfer. The DFC does not receive its system clock until DFEN bit in DFCON is set, i.e. DFC enabled.
Data Flow Descriptor	As shown in Table 91 the data flow is characterized by a 5-byte data flow descriptor: the DFD composed of 4 fields. The data flow descriptor is written byte by byte to DFD0 (channel 0) or to DFD1 (channel 1). As soon as a DFD has been fully written, the channel is enabled and data flow transfer starts when both source and destination are ready to send and receive data respectively.

Table 92 shows the different peripherals (source or destination) ID number. These numbers are used to program the SID and the DID in the DFD.

Byte Number	Byte Mnemonic	Description
0	SID	Source Identifier See Table 92 for peripheral ID number.
1	DID	Destination Identifier See Table 92 for peripheral ID number.
2	DPS	Data Packet Size Decimal value giving the packet size as 2 ^{DPS} . DPS takes value from 0 (1-byte packet size) to 13 (8192-byte packet size). Packet size is limited to 8192 bytes in case of DPS value greater than 13
3	DFSH	Data Flow Size
4	DFSL	16-bit wide data leading to data flow size from 1 to 2 ¹⁶ - 1 data packets. Writing 0x0000 to this field enables continuous data flow.

Table 91. Data Flow Descriptor Content

Table 92. Peripheral ID Number

ID Number	Peripheral
0	C51 RAM
1	USB Controller
2	Audio Controller 1
3	Audio Controller 2
4	PSI Controller
5	SPI Controller
6	SIO Controller
7	Nand Flash Controller
8	MMC/SD Controller
$9 \le n \le 14$	Reserved
15	Null Device

CRC Processor

In order to verify integrity of data transferred through the DFC, a CRC calculation can be enabled using DFCRCEN bit in DFCON. It consists in a 16-bit CRC which is the remainder after transfer data (MSB first) is divided by G(X). Polynomial formula is: $G(X) = X^{16} + X^{15} + X^2 + 1$.

CRC16 operates on channel 0 only.

After an hardware reset, the CRC value is 0x0000 but can be set to any initial value by writing two bytes⁽¹⁾ (MSB first) in the DFCRC register.

At the end of the data flow transfer⁽²⁾, CRC is available to user by reading two bytes⁽¹⁾ (MSB first) from the DFCRC register.

- Notes: 1. This double write or read sequence can be reset by clearing the CRCEN bit.
 - 2. The CRC value is not reset at start-up of a new data transfer.

Null DeviceThe null device is used to allow CRC calculation on some data transfer (see
Section "CRC Processor"). When selected as destination, the null device is always
ready and simply acknowledges and discards data coming from the source. When





selected as source, the null device is always ready and sends the data (2 bytes) of the initialized CRC value MSB first.

Channel Priority The Data Flow Controller bandwidth is shared between Channel 0 and Channel 1. In case both channels are ready to transfer data, bus bandwidth is shared on a byte by byte basis.

In order to allocate maximum bandwidth to a specified channel, priority can be assigned to channel 0 or to channel 1 by setting the DFPRIO1:0 bits in DFCON according to Table 93.

DFPRIO1:0 can be modified at any time while transfer is on-going or not.

Table 93.	Channel	Priority	Assignment
-----------	---------	----------	------------

DFPRIO1	DFPRIO0	Assignment Description
0	0	No priority assigned: channel 0 & channel 1 have same priority.
0	1	Priority assigned to channel 0.
1	0	Priority assigned to channel 1.
1	1	Reserved, do not set both bits.

Data Flow Status An on-going data flow transfer is reported to user using the bits DFBSY0 and DFBSY1 in DFCSTA. These bits are set as soon as the DFD has been fully written to the corresponding channel and cleared at the end of transfer or abort.

Source peripheral and destination peripheral status is dynamically reported by SRDY0, DRDY0, SRDY1, DRDY1 ready flags in DFCSTA.

 Data Flow Abort
 The DFC allows asynchronous abort of any on-going flow. Abort is controlled by the DFABT0, DFABT1, the Channel Data Flow Abort control bits in DFCCON and DFABTM the Data Flow Abort Mode control bit in DFCON.

Setting DFABT0 or DFABT1 while a flow transfer is on-going triggers on the corresponding channel an immediate or delayed abort depending on the DFABTM value. DFABTM cleared triggers an immediate abort where data flow transfer is stopped at the end of the on-going byte transfer while DFABTM set triggers a delayed abort where data flow transfer is stopped at the end of the on-going data packet transfer. Above abort modes set the End of Flow interrupt flag of the corresponding channel.

Setting DFABT0 or DFABT1 while a DFD is under writing will reset the DFD content of the corresponding channel. Such abort does not set the End of Flow interrupt flag of the corresponding channel.

Abort Status In case a data flow transfer is aborted, the remaining number of data packets to be transmitted can be retrieved by reading two bytes with MSB first from the data flow descriptor register DFD0 (channel 0) or to DFD1 (channel 1). This feature is of interest in case of logical data flow management over a physical channel.

Note: In case of immediate abort, returned value is not significant since part of the DP is already transmitted.

	Figure 46. Immediate Data Flow Abort Diagram
	Data bus // · · DR · · / ·
	DFABTx
	DFBSYx
	Remaining DP N+2 N+1 N
	Figure 47. Delayed Data Flow Abort Diagram
	Data bus DP
	DFBSYx
	Remaining DP N+2 N+1 N
Data Flow Configuration	Prior to any operation, the DFC must be configured in term of clock source and channel priority, then DFC can be enabled. Each time a data flow must be established, a data flow descriptor must be written to the DFC.
Interrupts	As shown in Figure 48, the DFC interrupt request is generated by 2 different sources: the EOFI0 flag or EOFI1 flag in DFCSTA. Both sources can be enabled separately by using the EOFE0 and EOFE1 bits in DFCCON. A global enable of the DFC interrupt is provided by setting the EDFC bit in IENx register. The interrupt is requested each time one of the 2 sources is asserted.
	EOFI0 or EOFI1 flags are set:
	at the end of a data flow on respective channel.
	after an immediate abort command at the end of the byte transfer.
	after a delayed abort at the end of the data packet transfer.
	Note: An abort command never sets flags while in the process of writing DFD.
	bits in DFCCON, in order to acknowledge the interrupt. Setting these flags by software has no effect.
	Figure 48. DFC Interrupt System
	EOFIO DFCSTA.1 EOFE0 DECCON12 DFC Interrupt Request
	EOFI1 DFCSTA.5 EOFE1
	DECCON.6





Registers

Table 94. DFCON Register

DFCON (1.89h) – DFC Control Register

7	6	5	4	3	2	1	0
-	DFRES	-	DFCRCEN	DFPRIO1	DFPRIO0	DFABTM	DFEN
Bit Number	Bit Mnemonic	Description	Description				
5	-	Reserved The value re	Reserved The value read from this bit is always 0. Do not set this bit.				
6	DFRES	Data Flow C Set then clea	Data Flow Controller Reset Bit Set then clear this bit to reset the Data Flow Controller by software.				
5	-	Reserved The value read from this bit is always 0. Do not set this bit.					
4	DFCRCEN	CRC Enable Bit Set to enable CRC calculation on channel 0. Clear to disable CRC calculation.					
3-2	DFPRIO1:0	Data Flow Channel Priority Assignment Bits Refer to Table 93 for channel priority assignment description.					
1	DFABTM	Data Flow Abort Mode Bit Set to trigger a delayed abort. Clear to trigger an immediate abort.					
0	DFEN	Data Flow Controller Enable Bit Set to enable the Data Flow Controller. Clear to disable the Data Flow Controller.					

Reset Value = 0000 0000b

Table 95. DFCSTA Register

DFCSTA (1.88h Bit Addressable) – DFC Channel Status Register

7	6	5	4	3	2	1	0
DRDY1	SRDY1	EOFI1	DFBSY1	DRDY0	SRDY0	EOFI0	DFBSY0
Bit Number	Bit Mnemonic	Description					
7	DRDY1	Channel 1 D Set by hardw Cleared by h	estination Revealed when the ardware when the	eady Flag destination pe the destination	eripheral of ch on peripheral (annel 1 is rea of channel 1 is	dy. s not ready.
6	SRDY1	Channel 1 Source Ready Flag Set by hardware when the source peripheral of channel 1 is ready. Cleared by hardware when the source peripheral of channel 1 is not ready.				t ready.	
5	EOFI1	Channel 1 End Of Data Flow Interrupt Flag Set by hardware at the end of a channel 1 data flow transfer. Cleared by software by setting EOFIA1 in DFCCON. Can not be set by software.			by software.		
4	DFBSY1	Channel 1 B Set by hardw Cleared by h	usy Flag vare when a tr ardware wher	ansfer is on-g n no transfer is	oing on chanr s on-going on	iel 1. channel 1.	

Bit Number	Bit Mnemonic	Description
3	DRDY0	Channel 0 Destination Ready Flag Set by hardware when the destination peripheral of channel 0 is ready. Cleared by hardware when the destination peripheral of channel 0 is not ready.
2	SRDY0	Channel 0 Source Ready Flag Set by hardware when the source peripheral of channel 0 is ready. Cleared by hardware when the source peripheral of channel 0 is not ready.
1	EOFI0	Channel 0 End Of Data Flow Interrupt Flag Set by hardware at the end of a channel 0 data flow transfer. Cleared by software by setting EOFIA0 in DFCCON. Can not be set by software.
0	DFBSY0	Channel 0 Busy Flag Set by hardware when a transfer is on-going on channel 0. Cleared by hardware when no transfer is on-going on channel 0.

Reset Value = 0000 0000b

Table 96. DFCCON Register

DFCCON (1.85h) - DFC Channel Control Register

7	6	5	4	3	2	1	0
DFABT1	EOFE1	EOFIA1	-	DFABT0	EOFE0	EOFIA0	-
Bit Number	Bit Mnemonic	Description					
7	DFABT1	Channel 1 A Set to trigger This bit is cle	Channel 1 Abort Control Bit Set to trigger an abort on channel 1. This bit is cleared by hardware.				
6	EOFE1	Channel 1 E Set to enable Clear to disa	Channel 1 End Of Data Flow Interrupt Enable Bit Set to enable channel 1 EOF interrupt. Clear to disable channel 1 EOF interrupt.				
5	EOFIA1	Channel 1 E Set to ackno Clearing this The value re	Channel 1 End Of Flow Interrupt Acknowledge Bit Set to acknowledge the channel 1 EOF interrupt (clear EOFI1 flag). Clearing this bit has no effect. The value read from this bit is always 0.				
4	-	Reserved The value re	ad from this b	it is always 0.	Do not set thi	s bit.	
3	DFABT0	Channel 0 A Set to trigger This bit is cle	Channel 0 Abort Control Bit Set to trigger an abort on channel 0. This bit is cleared by hardware.				
2	EOFE0	Channel 0 E Set to enable Clear to disa	Channel 0 End Of Data Flow Interrupt Enable Bit Set to enable channel 0 EOF interrupt. Clear to disable channel 0 EOF interrupt.				
1	EOFIA0	Channel 0 E Set to ackno Clearing this The value re	Channel 0 End Of Flow Interrupt Acknowledge Bit Set to acknowledge the channel 0 EOF interrupt (clear EOFI0 flag). Clearing this bit has no effect. The value read from this bit is always 0.				
0	-	Reserved The value re	ad from this b	it is always 0.	Do not set thi	s bit.	

Reset Value = 0000 0000b





Table 97. DFD0 Register

DFD0 (1.8Ah) - DFC Channel 0 Data Flow Descriptor Register

7	6	5	4	3	2	1	0
DFD0D7	DFD0D6	DFD0D5	DFD0D4	DFD0D3	DFD0D2	DFD0D1	DFD0D0
Bit Number	Bit Mnemonic	Description					
7-0	DFD0D7:0	Channel 0 D Write data flo Read to get t read first.	ata Flow Des w descriptor t the remaining	criptor Data to this register number of da	as detailed in ata packet afte	n Table 91. er a delayed a	abort. MSB is

Reset Value = 0000 0000b

Table 98. DFD1 Register

DFD1 (1.8Bh) – DFC Channel 1 Data Flow Descriptor Register

7	6	5	4	3	2	1	0
DFD1D7	DFD1D6	DFD1D5	DFD1D4	DFD1D3	DFD1D2	DFD1D1	DFD1D0
Bit Number	Bit Mnemonic	Description					
7-0	DFD1D7:0	Channel 1 Data Flow Descriptor Data Write data flow descriptor to this register as detailed in Table 91. Read to get the remaining number of data packet after a delayed abort. MSB is read first.					

Reset Value = 0000 0000b

Table 99. DFCRC Register

DFCRC (1.8Ch) – DFC CRC Data Register

7	6	5	4	3	2	1	0
CRCD7	CRCD6	CRCD5	CRCD4	CRCD3	CRCD2	CRCD1	CRCD0
Bit Number	Bit Mnemonic	Description					
7-0	CRCD7:0	CRC 2-byte First reading reading retur First writing while second	Data FIFO of DFCRC ns the LSB. to DFCRC wi writing writes	returns the M rites the MSB s the LSB.	ISB of the C	RC16 data v	vhile second CRC16 data

Reset Value = 0000 0000b

USB Controller

The AT85C51SND3B derivatives implement a USB controller allowing the AT85C51SND3B to act as a USB device or a USB host.

The main features of the USB controller:

- Full-speed and high-speed device.
- Full-speed host with OTG compliance.
- Automatic Data Flow Controller (DFC) transfer without CPU support.
- 2368 bytes of DPRAM.
- Up to 7 endpoints/pipes
 - 1 endpoint of 64 bytes (default control),
 - 2 endpoints of 512 bytes max, (one or two banks),
 - 4 endpoints of 64 bytes max, (one or two banks).

Description The C51 core interfaces with the USB Controller using a set of special function registers detailed in Table 49, page 40.

As shown in Figure 49, the USB controller is based on seven functional blocks:

- the PLL clock (see Section "Clock Generator", page 29) which delivers 480 MHz clock for USB high-speed mode support.
- the USB HS/FS pad supporting speed negotiation, attach/detach and data transfer
- the USB OTG pad supporting OTG negotiation
- the device controller allowing AT85C51SND3B to act as a device
- the host controller allowing AT85C51SND3B to act as a device
- the 2368-byte dual port RAM for endpoints and pipes memory
- the interrupt controller

Figure 49. USB Controller Block Diagram



USB Connection

Figure 50 shows the connection of the AT85C51SND3B to the USB connector and the the connection of the RC filter to the UBIAS pin. DPF and DMF pins are connected through 2 termination resistors.

Value of all discrete components is detailed in the Section "DC Characteristics", page 242.





Figure 50. USB Connection



General Operating Modes

Introduction

After a hardware reset, the USB controller is disabled.

When enabled, the USB controller has to run the Device Controller or the Host Controller. This is performed using the ID detection.

- If the ID pin is not connected to ground, the ID bit is set by hardware (internal pull up on the UID pad) and the USB Device controller is selected.
- The ID bit is cleared by hardware when a low level has been detected on the ID pin. The Device controller is then disabled and the Host controller enabled.

The software anyway has to select the mode (Host, Device) in order to access to the Device controller registers or to the Host controller registers, which are multiplexed. For example, even if the USB controller has detected a Device mode (pin ID high), the software shall select the device mode (bit HOST cleared), otherwise it will access to the host registers. This is also true for the Host mode.

Power-On and Reset

Figure 51 shows the USB controller main states after power-on.

Figure 51. USB Controller Reset State Machine



USB Controller state after an hardware reset is 'Reset'. In this state:

- USBE is not set,
- the macro clock is stopped in order to minimize the power consumption (FRZCLK=1),
- the macro is disabled,
- the pad is in the suspend mode,
- the Host and Device USB controllers internal states are reset.

86 AT85C51SND3B

- The DPACC bit and the DPADD10:0 field can be set by software. The DPRAM is not cleared.
- The SPDCONF bits can be set by software.

After setting USBE, the USB Controller enters in the Host or in the Device state (according to the UID pin level). The selected controller is 'Idle'.

The USB Controller can at any time be 'stopped' by clearing USBE. In fact, clearing USBE acts as an hardware reset.

Interrupts As shown in Figure 52, the USB controller implements five main global interrupt sources: the USB general and OTG interrupts detailed in Figure 53, the USB device and endpoint interrupts detailed in Section "Interrupts", page 113, and the USB host and pipe interrupts detailed in Section "Interrupt", page 134.

Figure 52. USB Interrupt System









	There are 2 kinds of interrupts: processing (i.e. their generation are part of the normal processing) and exception (errors).
	 Processing interrupts are generated when the following events are triggered: IDTI: ID Pad detection (insert, remove) VBUSTI: VBUS plug-in detection (insert, remove) SRPI: SRP detected ROLEEXI: Role Exchanged
	 Exception Interrupts are generated when the following events are triggered: VBERRI: Drop on VBUS Detected BCERRI: Error during the B-Connection HNPERRI: HNP Error STOI: Time-out detected during Suspend mode
Power modes	
Idle Mode	In this mode, the CPU core is halted (CPU clock stopped). The Idle mode is taken regardless of the USB controller state (running or not). The CPU wakes up on any USB interrupts.
Power Down	 In this mode, the oscillator and PLL are stopped and the CPU and peripherals are frozen. The CPU "wakes up" when: the WAKEUPI interrupt is triggered in the Peripheral mode (HOST cleared), the RXRSMI or the SRPI interrupt is triggered in the Host mode (HOST set). the IDTI interrupt is triggered the VBUSTI interrupt is triggered
Freeze Clock	 The firmware has the ability to reduce the power consumption by setting the FRZCLK bit, which freezes the clock of USB controller. When FRZCLK is set, it is still possible to have an access to the following registers: USBCON, USBSTA, USBINT DPRAM direct access (DPADD10:0, UxDATX) UDCON (detach,) UDINT UDIEN UHCON UHINT UHIEN

Moreover, when FRZCLK is set, only the following interrupts may be triggered:

- WAKEUPI
- IDTI
- VBUSTI

Speed Control

Device Mode

When the USB interface is configured in device mode, the speed selection (Full Speed or High Speed) is performed automatically by the USB controller during the USB Reset. A the end of the USB reset, the USB controller automatically enables or disables high-speed terminations and pull-up.

Note: It is possible to force the speed of the protocol, through the SPDCONF1:0 bits. For normal operations, SPDCONF1:0 must be cleared. For all other operations (e.g. running in Full-Speed only), SPDCONF1:0 shall be written before enabling the controller (USBE set), in order to avoid any side effects. The following table summarizes all the possible configurations:

Mode	SPDCONF1:0	Description
Peripheral	00	Normal Mode (default) Use High-Speed pad in Full-Speed or High-Speed.
	01	Full-Speed only mode (Full-Speed pad) Shall be done before setting USBE.
	10	High-Speed only mode (High-Speed pad) Shall be used in debug mode.
	11	Full-Speed only mode (High-Speed pad)
Host	XX	Use Full-Speed pad

Table 100. Speed configuration

Clearing USBE resets SPDCONF1:0.

vated on both DMF and DPF lines.

Host Mode

Memory Access Capability

The CPU has the capability to directly access to the USB internal memory (DPRAM).

When the USB interface is configured in host mode, internal pull down resistors are acti-

The memory access mode is performed using UDPADDH and UDPADDL registers.

To enter in this mode:

- USBE bit must be cleared.
- DPACC bit and the base address DPADD10:0 must be set.

The DPACC bit and DPADD10:0 field can be used by the firmware even if the USBE bit is cleared.

Then, a read or a write in UEDATX (device mode) or in UPDATX (host mode) is performed according to DPADD10:0 and the base address DPADD10:0 field is automatically increased. The endpoint FIFO pointers and the value of the UxNUM registers are discarded in this mode.

The aim of this functionality is to use the DPRAM as extra-memory.





When using this mode, there is no influence over the USB controller.



Memory Management The controller only supports the following memory allocation management:

The reservation of a Pipe or an Endpoint can only be made in the growing order (Pipe/Endpoint 0 to the last Pipe/Endpoint). The firmware shall thus configure them in the same order.

The reservation of a Pipe or an Endpoint "kⁱ" is done when its ALLOC bit is set. Then, the hardware allocates the memory and insert it between the Pipe/Endpoints "kⁱ⁻¹" and "kⁱ⁺¹". The "kⁱ⁺¹" Pipe/Endpoint memory "slides" up and its data is lost. Note that the "kⁱ⁺²" and upper Pipe/Endpoint memory does not slide.

Clearing a Pipe enable (PEN) or an Endpoint enable (EPEN) does not clear neither its ALLOC bit, nor its configuration (EPSIZE/PSIZE, EPBK/PBK). To free its memory, the firmware should clear ALLOC. Then, the "kⁱ⁺¹" Pipe/Endpoint memory automatically "slides" down. Note that the "kⁱ⁺²" and upper Pipe/Endpoint memory does not slide.

The following figure illustrates the allocation and reorganization of the USB memory in a typical example:





- First, Pipe/Endpoint 0 to Pipe/Endpoint 5 are configured, in the growing order. The memory of each is reserved in the DPRAM.
- Then, the Pipe/Endpoint 3 is disabled (EPEN=0), but its memory reservation is internally kept by the controller.
- Its ALLOC bit is cleared: the Pipe/Endpoint 4 "slides" down, but the Pipe/Endpoint 5 does not "slide".
- Finally, if the firmware chooses to reconfigure the Pipe/Endpoint 3, with a bigger size. The controller reserved the memory after the endpoint 2 memory and automatically "slide" the Pipe/Endpoint 4. The Pipe/Endpoint 5 does not move and a memory conflict appear, in that both Pipe/Endpoint 4 and 5 use a common area. The data of those endpoints are potentially lost.
- Notes: 1. the data of Pipe/Endpoint 0 are never lost whatever the activation or deactivation of the higher Pipe/Endpoint. Its data is lost if it is deactivated.
 - Deactivate and reactivate the same Pipe/Endpoint with the same parameters does not lead to a "slide" of the higher endpoints. For those endpoints, the data are preserved.
 - 3. CFGOK is set by hardware even in the case that there is a "conflict" in the memory allocation.

PAD suspend

Figure 55 and Figure 56 illustrate the pad behaviour:

- In the "idle" mode, the pad is put in low power consumption mode.
- In the "active" mode, the pad is working.

Figure 55. Pad Behaviour State Machine



The SUSPI flag indicates that a suspend state has been detected on the USB bus. This flag automatically puts the USB pad in Idle state. The detection of a non-idle event sets the WAKEUPI flag and wakes-up the USB pad.

Figure 56. Pad Behavior Waveforms



Moreover, the pad can also be put in the "idle" mode if the DETACH bit is set. It come back in the active mode when the DETACH bit is cleared.





OTG Timers Customizing

It is possible to refine some OTG timers thanks to the OTGTCON register (see Table 108). This register is multiplexed with the OTGCON register. The timers are as defined in the OTG specification:

- AWaitVrise time-out. [OTG] chapter 6.6.5.1
- VbBusPulsing. [OTG] chapter 5.3.4
- PdTmOutCnt. [OTG] chapter 5.3.2

•

• SRPDetTmOut. [OTG] chapter 5.3.3

Table 101.	OTG	Timer Configuration
------------	-----	----------------------------

PAGE1:0	VALUE2:0	Timing Parameter
	00	AWaitVrise time-out = 20 ms.
00	01	AWaitVrise time-out = 50 ms.
00	10	AWaitVrise time-out = 70 ms.
	11	AWaitVrise time-out = 100 ms.
	00	VbBusPulsing = 15 ms.
01	01	VbBusPulsing = 23 ms.
01	10	VbBusPulsing = 31 ms.
	11	VbBusPulsing = 40 ms.
	00	PdTmOutCnt = 96 ms.
10	01	PdTmOutCnt = 105 ms.
10	10	PdTmOutCnt = 118 ms.
	11	PdTmOutCnt = 131 ms.
	00	SRPDetTmOut = 10 μs.
11	01	SRPDetTmOut = 100 μs.
	10	SRPDetTmOut = 1 ms.
	11	SRPDetTmOut = 11 ms.

Plug-in detection

The USB connection is detected by the VBUS pad, thanks to the following architecture:

Figure 57. Plug-in Detection Input Block Diagram



The control logic of the UVCC pad outputs 2 signals:

- The "session_valid" signal is active high when the voltage on the UVCC pin is higher or equal to 1.4V.
- The "Va_Vbus_valid" signal is active high when the voltage on the UVCC pin is higher or equal to 4.4V.

In the Host mode, the VBUS flag follows the next hysteresis rule:

- VBUS is set when the voltage on the UVCC pin is higher or equal to 4.4 V.
- VBUS is cleared when the voltage on the UVCC pin is lower than 1.4 V.

In the Peripheral mode, the VBUS flag follows the next rule:

- VBUS is set when the voltage on the UVCC pin is higher or equal to 1.4 V.
- VBUS is cleared when the voltage on the UVCC pin is lower than 1.4 V.

The VBUSTI interrupt is triggered at each transition of the VBUS flag.





ID Detection

The ID pin transition is detected thanks to the following architecture:

Figure 58. ID Detection Input Block Diagram



By default, (no A-plug or B-plug), the macro is in the Peripheral mode (internal pull-up). The IDTI interrupt is triggered when a A-plug (Host) is plugged or unplugged. The interrupt is not triggered when a B-plug (Peripheral) is plugged or unplugged.

The IDTI interrupt may be triggered even if the USB controller is disabled.

Registers

USB general registers

Table 102. USBCON Register

USBCON (1.E1h) – USB General Control Register

7	6	5	4	3	2	1	0	
USBE	HOST	FRZCLK	OTGPADE	-	-	IDTE	VBUSTE	
Bit Number	Bit Mnemonic	Description						
7	USBE	USB Contro Set to enable Clear to disa to disable the	USB Controller Enable Bit Set to enable the USB controller. Clear to disable and reset the USB controller, to disable the USB transceiver and to disable the USB controller clock inputs.					
6	HOST	HOST Bit Set to acces Clear to acce	HOST Bit Set to access to the Host registers. Clear to access to the Device registers.					
5	FRZCLK	Freeze USB Clock Bit Set to disable the clock inputs (the "Resume Detection" is still active) and save power consumption. Clear to enable the clock inputs.					ve) and save	
4	OTGPADE	OTG Pad Enable Set to enable the OTG pad. Clear to disable the OTG pad. Note that this bit can be set/cleared even if USBE= 0 (this allows the VBUS detection even if the USB macro is disable).					is the VBUS	
3-2	-	Reserved The value re	ad from these	bits is always	0. Do not set	these bits.		
1	IDTE	ID Transition Set this bit to Clear this bit	n Interrupt Ei enable the II to disable the	hable Bit D Transition in e ID Transition	terrupt genera interrupt gene	ation. eration.		

Bit Number	Bit Mnemonic	Description
0	VBUSTE	VBUS Transition Interrupt Enable Bit Set this bit to enable the VBUS Transition interrupt generation. Clear this bit to disable the VBUS Transition interrupt generation.

Reset Value = 0010 0000b

Table 103. USBSTA Register

USBSTA (1.E2h) - USB General Status Register

7	6	5	4	3	2	1	0	
-	-	-	-	-	SPEED	ID	VBUS	
Bit Number	Bit Mnemonic	Description						
7-3	-	Reserved The value rea	eserved he value read from these bits is always 0. Do not set these bits.					
2	SPEED	Speed Statu Set by hardw Cleared by h	Speed Status Flag Set by hardware when the controller is in HIGH-SPEED mode. Cleared by hardware when the controller is in FULL-SPEED mode.					
1	ID	IUD Pin Flag Set / cleared	IUD Pin Flag Set / cleared by hardware and reflects the state of the UID pin.					
0	VBUS	VBus Flag Set / cleared See Section	by hardware "Plug-in detec	and reflects th ction" for more	ne level of the details.	UVCC pin.		

Reset Value = 0000 0000b

Table 104. USBINT Register

USBINT (1.E3h) – USB Global Interrupt Register

7	6	5	4	3	2	1	0	
-	-	-	-	-	-	IDTI	VBUSTI	
Bit Number	Bit Mnemonic	Description						
7-2	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.					
1	IDTI	ID Transition Set by hardw on the UID p Shall be clea	ID Transition Interrupt Flag Set by hardware when a transition (high to low, low to high) has been detected on the UID pin. Shall be cleared by software.					
0	VBUSTI	VBUS Trans Set by hardw on the UVCC Shall be clea	ition Interrup vare when a t) pin. red by softwa	ot Flag transition (high tre.	n to low, low t	o high) has b	een detected	

Reset Value = 0000 0000b





Table 105. UDPADDH Register

UDPADDH (1.E4h) – USB Dual Port Ram Direct Access High Register

7	6	5	4	3	2	1	0
DPACC	-	-	-	-		DPADD10:8	
Bit Number	Bit Mnemonic	Description					
7	DPACC	DPRAM Dire Set this bit to the UEDATX more details. Clear this bi FIFO.	ect Access B o directly read or UPDATX of t for normal of	it d the content registers. See operation and	the Dual-Por Section "Mer access the	t RAM (DPR) mory Access (DPR through	data through Capability" for the endpoint
6-3	-	Reserved The value rea	ad from these	bits is always	0. Do not se	t these bits.	
2-0	DPADD10:8	DPRAM Add DPADD10:8 provided by t	Iress High Bi is the most s he UDPADDL	it ignificant part - register.	of DPADD.	The least sign	ificant part is

Reset Value = 0000 0000b

Table 106. UDPADDL Register

UDPADDL (1.E5h) - USB Dual Port Ram Direct Access High Register

7	6	5	4	3	2	1	0
			DPAI	DD7:0			
Bit Number	Bit Mnemonic	Description					
7-0	DPADD7:0	DPRAM Add DAPDD7:0 is provided by t	Iress Low Bi s the least si he UDPADDI	t gnificant part H register.	of DPADD. T	he most sign	ificant part is

Reset Value = 0000 0000b

Table 107. OTGCON Register

OTGCON (1.E6h) - USB OTG Control Register

7	6	5	4	3	2	1	0	
0	-	HNPREQ	SRPREQ	SRPSEL	VBUSHWC	VBUSREQ	VBUSRQC	
Bit Number	Bit Mnemonic	Description	Description					
7	0	OTGCON pa This bit must	OTGCON pagination This bit must be cleared to access the OTGCON register.					
6	-	Reserved The value rea	ad from these	bits is always	0. Do not set	these bits.		

Bit Number	Bit Mnemonic	Description
5	HNPREQ	HNP Request Bit Set to initiate the HNP when the controller is in the Device mode (B). Set to accept the HNP when the controller is in the Host mode (A). Cleared by hardware after the HNP completion.
4	SRPREQ	SRP Request Bit Set to initiate the SRP when the controller is in Device mode. Cleared by hardware when the controller is initiating a SRP.
3	SRPSEL	SRP Selection Bit Set to choose VBUS pulsing as SRP method. Clear to choose data line pulsing as SRP method.
2	VBUSHWC	VBus Hardware Control Bit Set to disable the hardware control over the UVCON pin. Clear to enable the hardware control over the UVCON pin.
1	VBUSREQ	VBUS Request Bit Set to assert the UVCON pin in order to enable the VBUS power supply generation. This bit shall be used when the controller is in the Host mode. Cleared by hardware when VBUSRQC is set.
0	VBUSRQC	VBUS Request Clear Bit Set to deassert the UVCON pin in order to enable the VBUS power supply generation. This bit shall be used when the controller is in the Host mode. Cleared by hardware immediately after the set.

Reset Value = 0000 0000b

Table 108. OTGTCON Register

OTGTCON (1.E6h) – USB OTG Timer Control Register

7	6	5	4	3	2	1	0		
1	PAG	iE1:0	-	-		VALUE2:0			
Bit Number	Bit Mnemonic	Description	escription						
7	1	OTGTCON F This bit must	TGTCON Pagination his bit must be set to access the OTGTCON register.						
6-5	PAGE1:0	Timer Page Set/clear to a See Section	Fimer Page Access Bit Set/clear to access a special timer register. See Section "OTG Timers Customizing" for more details.						
4-3	-	Reserved The value re	Reserved The value read from these bits is always 0. Do not set these bits.						
2-0	VALUE2:0	Value Bit Set to initializ See Section	ze the new va "OTG Timers	lue of the time Customizing"	er. for more det	ails.			

Reset Value = 0000 0000b





Table 109. OTGIEN Register

OTGIEN (1.E7h) – USB OTG Interrupt Enable Register

7	6	5	4	3	2	1	0	
-	-	STOE	HNPERRE	ROLEEXE	BCERRE	VBERRE	SRPE	
Bit Number	Bit Mnemonic	Description						
7-6	-	Reserved The value re	leserved The value read from these bits is always 0. Do not set these bits.					
5	STOE	Suspend Tin Set to enable Clear to disa	Jspend Time-out Error Interrupt Enable Bit et to enable the STOI interrupt. lear to disable the STOI interrupt.					
4	HNPERRE	HNP Error II Set to enable Clear to disa	HNP Error Interrupt Enable Bit Set to enable the HNPERRI interrupt. Clear to disable the HNPERRI interrupt.					
3	ROLEEXE	Role Exchar Set to enable Clear to disa	nge Interrupt e the ROLEE> ble the ROLE	Enable Bit (I interrupt. EXI interrupt.				
2	BCERRE	B-Connection Set to enable Clear to disa	B-Connection Error Interrupt Enable Bit Set to enable the BCERRI interrupt. Clear to disable the BCERRI interrupt.					
1	VBERRE	VBus Error Interrupt Enable Bit Set to enable the VBERRI interrupt. Clear to disable the VBERRI interrupt.						
0	SRPE	SRP Interru Set to enable Clear to disa	SRP Interrupt Enable Bit Set to enable the SRPI interrupt. Clear to disable the SRPI interrupt.					

Reset Value = 0000 0000b

Table 110. OTGINT Register

OTGINT (1.D1h) – USB Global Interrupt Register

7	6	5	4	3	2	1	0
-	-	STOI	HNPERRI	ROLEEXI	BCERRI	VBERRI	SRPI
Bit Number	Bit Mnemonic	Description					
7-6	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.				
5	STOI	Suspend Tir Set by hardw after a suspe Shall be clea	Suspend Time-out Error Interrupt Flag Set by hardware when a time-out error (more than 150 ms) has been detected after a suspend. Shall be cleared by software. See for more details.				
4	HNPERRI	HNP Error Ir Set by hardw Shall be clea	nterrupt Flag vare when an red by softwa	error has beer re. See for mc	n detected dur pre details.	ing the protoc	col.

Bit Number	Bit Mnemonic	Description
3	ROLEEXI	Role Exchange Interrupt Flag Set by hardware when the USB controller has successfully swapped its mode, due to an HNP negotiation: Host to Device or Device to Host. Shall be cleared by software. See for more details.
2	BCERRI	B-Connection Error Interrupt Flag Set by hardware when an error occur during the B-Connection. Shall be cleared by software.
1	VBERRI	V-Bus Error Interrupt Flag Set by hardware when a drop on VBus has been detected. Shall be cleared by software.
0	SRPI	SRP Interrupt Flag Set by hardware when a SRP has been detected. Shall be used in the Host mode only. Shall be cleared by software.

Reset Value = 0000 0000b





USB Software Operating modes

Depending on the USB operating mode, the software should perform some of the following operations:

Power On the USB interface

- Power-On USB pads regulator
- Wait USB pads regulator ready state
- Configure PLL interface
- Enable PLL
- Check PLL lock
- Enable USB interface
- Configure USB interface (USB speed, Endpoints configuration...)
- Wait for USB VBUS information connection
- Attach USB device

Power Off the USB interface

- Detach USB interface
- Disable USB interface
- Disable PLL
- Disable USB pin regulator

Suspending the USB interface

- Clear Suspend Bit
- Set USB suspend clock
- Disable PLL
- Be sure to have interrupts enable to exit sleep mode
- Make the MCU enter sleep mode

Resuming the USB interface

- Enable PLL
- Wait PLL lock
- Clear USB suspend clock
- Clear Resume information

USB Device Operating modes

Introduction	 The USB device controller supports high speed and full speed data transfers. In addition to the default control endpoint, it provides six other endpoints, which can be configured in control, bulk, interrupt or isochronous modes: Endpoint 0: programmable size FIFO up to 64 bytes, default control endpoint. Endpoints 1 and 2: programmable size FIFO up to 512 bytes in ping-pong mode. Endpoints 3 to 6: programmable size FIFO up to 64 bytes in ping-pong mode.
	The controller starts in the "idle" mode. In this mode, the pad consumption is reduced to the minimum.
Power-On and Reset	Figure 59 shows the USB device controller main states after power-on.
	Figure 59. USB Device Controller Reset State Machine
	(any other



The reset state of the Device controller is:

- the macro clock is stopped in order to minimize the power consumption (FRZCLK set)
- the USB device controller internal state is reset (all the registers are reset to their default value. Note that DETACH is set.)
- the endpoint banks are reset
- the D+ or D- pull up are not activated (mode Detach)

The D+ or D- pull-up will be activated as soon as the DETACH bit is cleared and VBUS is present.

The macro is in the 'Idle' state after reset with a minimum power consumption and does not need to have the PLL activated to enter in this state.

The USB device controller can at any time be reset by clearing USBE.

Speed Identification The high-speed reset is managed by the hardware. At the connection, the host makes a reset that can be:

- a classic reset (Full-speed) or
- a High-speed reset (High-speed).



	At the end of the reset process (Full or High), the end of reset interrupt (EORSTI) is gen- erated. Then the CPU should read the SPEED bit to know the speed mode of the device.
	Note that the USB device controller starts in the Full-speed mode after power on.
Endpoint Reset	An endpoint can be reset at any time by setting in the UERST register the bit corresponding to the endpoint (EPRSTx). This resets:
	 the internal state machine on that endpoint,
	 the Rx and Tx banks are cleared and their internal pointers are restored,
	 the UEINTX, UESTA0X and UESTA1X are restored to their reset value.
	The data toggle field remains unchanged.
	The other registers remain unchanged.
	The endpoint configuration remains active and the endpoint is still enabled.
	The endpoint reset may be associated with a clear of the data toggle command (RSTDT bit) as an answer to the CLEAR_FEATURE USB command.
USB Reset	When an USB reset is detected on the USB line, the next operations are performed by the controller:
	 all the endpoints are disabled, except the default control endpoint,
	• the default control endpoint is reset (see Section "Endpoint Reset" for more details).
	The data toggle of the default control endpoint is cleared.
Endpoint Selection	
Endpoint Selection	Prior to any operation performed by the CPU, the endpoint must first be selected. This is done by:
Endpoint Selection	Prior to any operation performed by the CPU, the endpoint must first be selected. This is done by:Clearing EPNUMS.
Endpoint Selection	 Prior to any operation performed by the CPU, the endpoint must first be selected. This is done by: Clearing EPNUMS. Setting EPNUM with the endpoint number which will be managed by the CPU.
Endpoint Selection	 Prior to any operation performed by the CPU, the endpoint must first be selected. This is done by: Clearing EPNUMS. Setting EPNUM with the endpoint number which will be managed by the CPU. The CPU can then access to the various endpoint registers and data.
Endpoint Selection	 Prior to any operation performed by the CPU, the endpoint must first be selected. This is done by: Clearing EPNUMS. Setting EPNUM with the endpoint number which will be managed by the CPU. The CPU can then access to the various endpoint registers and data. In the same manner, if the endpoint must be accessed by the DFC, it must first be selected. This is done by: Setting EPNUMS.
Endpoint Selection	 Prior to any operation performed by the CPU, the endpoint must first be selected. This is done by: Clearing EPNUMS. Setting EPNUM with the endpoint number which will be managed by the CPU. The CPU can then access to the various endpoint registers and data. In the same manner, if the endpoint must be accessed by the DFC, it must first be selected. This is done by: Setting EPNUMS. Setting EPNUMS. Setting EPNUMS. Setting EPNUM with the endpoint number which will be managed by the DFC. Setting EPNUM with the endpoint number which will be managed by the DFC.
Endpoint Selection	 Prior to any operation performed by the CPU, the endpoint must first be selected. This is done by: Clearing EPNUMS. Setting EPNUM with the endpoint number which will be managed by the CPU. The CPU can then access to the various endpoint registers and data. In the same manner, if the endpoint must be accessed by the DFC, it must first be selected. This is done by: Setting EPNUMS. Setting EPNUMS. Setting EPNUMS. Setting EPNUMS. Setting EPNUM with the endpoint number which will be managed by the DFC. Setting DFCRDY when the data-flow is ready to take place. The DFC can then access to the banks (read / write).
Endpoint Selection	 Prior to any operation performed by the CPU, the endpoint must first be selected. This is done by: Clearing EPNUMS. Setting EPNUM with the endpoint number which will be managed by the CPU. The CPU can then access to the various endpoint registers and data. In the same manner, if the endpoint must be accessed by the DFC, it must first be selected. This is done by: Setting EPNUMS. Setting EPNUMS. Setting EPNUM with the endpoint number which will be managed by the DFC. Setting EPNUMS. Setting EPNUM with the endpoint number which will be managed by the DFC. Setting DFCRDY when the data-flow is ready to take place. The DFC can then access to the banks (read / write). The controller internally keeps in memory the EPNUM for the CPU and the EPNUM for the DFC. In fact, there are 2 EPNUM registers multiplexed by the EPNUMS bit. Each of them can be read or written by the CPU.
Endpoint Selection	 Prior to any operation performed by the CPU, the endpoint must first be selected. This is done by: Clearing EPNUMS. Setting EPNUM with the endpoint number which will be managed by the CPU. The CPU can then access to the various endpoint registers and data. In the same manner, if the endpoint must be accessed by the DFC, it must first be selected. This is done by: Setting EPNUMS. Setting EPNUMS. Setting EPNUM with the endpoint number which will be managed by the DFC. Setting EPNUMS. Setting DFCRDY when the data-flow is ready to take place. The DFC can then access to the banks (read / write). The controller internally keeps in memory the EPNUM for the CPU and the EPNUM for the DFC. In fact, there are 2 EPNUM registers multiplexed by the EPNUMS bit. Each of them can be read or written by the CPU. These two registers permits to easily switch from an endpoint under DFC data transfer to the default control endpoint when a SETUP is received, without reprogramming the EPNUM register:
Endpoint Selection	 Prior to any operation performed by the CPU, the endpoint must first be selected. This is done by: Clearing EPNUMS. Setting EPNUM with the endpoint number which will be managed by the CPU. The CPU can then access to the various endpoint registers and data. In the same manner, if the endpoint must be accessed by the DFC, it must first be selected. This is done by: Setting EPNUMS. Setting EPNUMS. Setting EPNUM with the endpoint number which will be managed by the DFC. Setting EPNUMS. Setting DFCRDY when the data-flow is ready to take place. The DFC can then access to the banks (read / write). The controller internally keeps in memory the EPNUM for the CPU and the EPNUM for the DFC. In fact, there are 2 EPNUM registers multiplexed by the EPNUMS bit. Each of them can be read or written by the CPU. These two registers permits to easily switch from an endpoint under DFC data transfer to the default control endpoint when a SETUP is received, without reprogramming the EPNUM register: Set EPNUMS,
Endpoint Selection	 Prior to any operation performed by the CPU, the endpoint must first be selected. This is done by: Clearing EPNUMS. Setting EPNUM with the endpoint number which will be managed by the CPU. The CPU can then access to the various endpoint registers and data. In the same manner, if the endpoint must be accessed by the DFC, it must first be selected. This is done by: Setting EPNUMS. Setting EPNUMS. Setting EPNUMS. Setting DFCRDY when the endpoint number which will be managed by the DFC. Setting DFCRDY when the data-flow is ready to take place. The DFC can then access to the banks (read / write). The controller internally keeps in memory the EPNUM for the CPU and the EPNUM for the DFC. In fact, there are 2 EPNUM registers multiplexed by the EPNUMS bit. Each of them can be read or written by the CPU. These two registers permits to easily switch from an endpoint under DFC data transfer to the default control endpoint when a SETUP is received, without reprogramming the EPNUM register: Set EPNUMS, EPNUMS, EPNUMS, EPNUMS = endpoint,
Endpoint Selection	 Prior to any operation performed by the CPU, the endpoint must first be selected. This is done by: Clearing EPNUMS. Setting EPNUM with the endpoint number which will be managed by the CPU. The CPU can then access to the various endpoint registers and data. In the same manner, if the endpoint must be accessed by the DFC, it must first be selected. This is done by: Setting EPNUMS. Setting EPNUMS. Setting EPNUM with the endpoint number which will be managed by the DFC. Setting EPNUMS. Setting EPNUM with the endpoint number which will be managed by the DFC. Setting DFCRDY when the data-flow is ready to take place. The DFC can then access to the banks (read / write). The controller internally keeps in memory the EPNUM for the CPU and the EPNUM for the DFC. In fact, there are 2 EPNUM registers multiplexed by the EPNUMS bit. Each of them can be read or written by the CPU. These two registers permits to easily switch from an endpoint under DFC data transfer to the default control endpoint when a SETUP is received, without reprogramming the EPNUM register: Set EPNUMS, EPNUM = endpoint_x Set DFCRDY when the DFC transfer is ready to take place,
Endpoint Selection	 Prior to any operation performed by the CPU, the endpoint must first be selected. This is done by: Clearing EPNUMS. Setting EPNUM with the endpoint number which will be managed by the CPU. The CPU can then access to the various endpoint registers and data. In the same manner, if the endpoint must be accessed by the DFC, it must first be selected. This is done by: Setting EPNUMS. Setting EPNUMS. Setting EPNUMS. Setting EPNUM with the endpoint number which will be managed by the DFC. Setting EPNUM with the endpoint number which will be managed by the DFC. Setting DFCRDY when the data-flow is ready to take place. The DFC can then access to the banks (read / write). The controller internally keeps in memory the EPNUM for the CPU and the EPNUM for the DFC. In fact, there are 2 EPNUM registers multiplexed by the EPNUMS bit. Each of them can be read or written by the CPU. These two registers permits to easily switch from an endpoint under DFC data transfer to the default control endpoint when a SETUP is received, without reprogramming the EPNUM register: Set EPNUMS, EPNUM = endpoint_x Set DFCRDY when the DFC transfer is ready to take place,
Endpoint Selection	 Prior to any operation performed by the CPU, the endpoint must first be selected. This is done by: Clearing EPNUMS. Setting EPNUM with the endpoint number which will be managed by the CPU. The CPU can then access to the various endpoint registers and data. In the same manner, if the endpoint must be accessed by the DFC, it must first be selected. This is done by: Setting EPNUMS. Setting EPNUMS. Setting EPNUM with the endpoint number which will be managed by the DFC. Setting EPNUMS. Setting DFCRDY when the data-flow is ready to take place. The DFC can then access to the banks (read / write). The controller internally keeps in memory the EPNUM for the CPU and the EPNUM for the DFC. In fact, there are 2 EPNUM registers multiplexed by the EPNUMS bit. Each of them can be read or written by the CPU. These two registers permits to easily switch from an endpoint under DFC data transfer to the default control endpoint when a SETUP is received, without reprogramming the EPNUM register: Set EPNUMS, EPNUM = endpoint_x Set DFCRDY when the DFC transfer is ready to take place, SETUP received on endpoint₀ (EPINT0 set, RXSTPI set),

_

102 AT85C51SND3B

- Clear DFCRDY to freeze the DFC transfer,
- If the CPU EPNUM has to be changed: EPNUMS cleared, EPNUM = $endpoint_0$
- Read endpoint₀ data (UEDATX)
- Set DFCRDY. This resumes the DFC transfer.

Endpoint Activation The endpoint is maintained under reset as long as the EPEN bit is not set. The following flow must be respected in order to activate an endpoint:





As long as the endpoint is not correctly configured (CFGOK cleared), the hardware does not acknowledge the packets sent by the host.

CFGOK is will not be sent if the Endpoint size parameter is bigger than the DPRAM size.

A clear of EPEN acts as an endpoint reset (see Section "Endpoint Reset" for more details). It also performs the next operation:

- The configuration of the endpoint is kept (EPSIZE, EPBK, ALLOC kept)
- It resets the data toggle field.
- The DPRAM memory associated to the endpoint is still reserved.

See Section "Memory Management", page 90 for more details about the memory allocation/reorganization.

Address Setup

The USB device address is set up according to the USB protocol:

the USB device, after power-up, responds at address 0





	 the host sends a SETUP command (SET_ADDRESS(addr)),
	 the firmware records that address in UADD, but keep ADDEN cleared,
	 the USB device sends an IN command of 0 bytes (IN 0 Zero Length Packet),
	 then, the firmware can enable the USB device address by setting ADDEN. The only accepted address by the controller is the one stored in UADD.
	ADDEN and UADD shall not be written at the same time.
	UADD contains the default address 00h after a power-up or USB reset.
	ADDEN is cleared by hardware:
	after a power-up reset,
	when an USB reset is received,
	or when the macro is disabled (USBE cleared)
	When this bit is cleared, the default device address 00h is used.
Suspend, Wake-Up and Resume	After a period of 3 ms during which the USB line was inactive, the controller switches to the full-speed mode and triggers (if enabled) the SUSPI (suspend) interrupt. The firmware may then set the FRZCLK bit.
	The CPU can also, depending on software architecture, enter in the idle mode to lower again the power consumption.
	There are two ways to recover from the "Suspend" mode:
	 First one is to clear the FRZCLK bit. This is possible if the CPU is not in the Idle mode.
	 Second way, if the CPU is "idle", is to enable the WAKEUPI interrupt (WAKEUPE set). Then, as soon as an non-idle signal is seen by the controller, the WAKEUPI interrupt is triggered. The firmware shall then clear the FRZCLK bit to restart the transfer.
	There are no relationship between the SUSPI interrupt and the WAKEUPI interrupt: the WAKEUPI interrupt is triggered as soon as there are non-idle patterns on the data lines. Thus, the WAKEUPI interrupt can occurs even if the controller is not in the "suspend" mode.
	When the WAKEUPI interrupt is triggered, if the SUSPI interrupt bit was already set, it is cleared by hardware.
	When the SUSPI interrupt is triggered, if the WAKEUPI interrupt bit was already set, it is cleared by hardware.
Detach	The reset value of the DETACH bit is 1.
	It is possible to re-enumerate a device, simply by setting and clearing the DETACH bit.
	 If the USB device controller is in full-speed mode, setting DETACH will disconnect the pull-up on the D+ or D- pad (depending on full or low speed mode selected). Then, clearing DETACH will connect the pull-up on the D+ or D- pad.









This function is compliant with the Chapter 8 test from PMTC that send extra status for a GET_DESCRIPTOR. The firmware sets the STALL request just after receiving the status. All extra status will be automatically STALL'ed until the next SETUP request.

STALL Handshake and RetryThe Retry mechanism has priority over the STALL handshake. A STALL handshake is
sent if the STALLRQ request bit is set and if there is no retry required.

CONTROL EndpointA SETUP request is always ACK'ed. When a new setup packet is received, the RXSTPIManagementinterrupt is triggered (if enabled). The RXOUTI interrupt is not triggered.

The FIFOCON and RWAL fields are irrelevant with CONTROL endpoints. The firmware shall thus never use them on that endpoints. When read, their value is always 0.

CONTROL endpoints are managed by the following bits:

- RXSTPI is set when a new SETUP is received. It shall be cleared by firmware to acknowledge the packet and to clear the endpoint bank.
- RXOUTI is set when a new OUT data is received. It shall be cleared by firmware to acknowledge the packet and to clear the endpoint bank.
- TXINI is set when the bank is ready to accept a new IN packet. It shall be cleared by firmware to send the packet and to clear the endpoint bank.

CONTROL endpoints should not be managed by interrupts, but only by polling the status bits.

Control Write

The next figure shows a control write transaction. During the status stage, the controller will not necessary send a NAK at the first IN token:

- If the firmware knows the exact number of descriptor bytes that must be read, it can then anticipate on the status stage and send a ZLP for the next IN token,
- or it can read the bytes and poll NAKINI, which tells that all the bytes have been sent by the host, and the transaction is now in the status stage.





A NAK handshake is always generated at the first status stage command.

When the controller detect the status stage, all the data written by the CPU are erased, and clearing TXINI has no effects.

The next figure shows a control read transaction. The USB controller has to manage the

The firmware checks if the transmission is complete or if the reception is complete.

The OUT retry is always ack'ed. This reception:

- set the RXOUTI flag (received OUT data)
- set the TXINI flag (data sent, ready to accept new data)

software algorithm:

```
set transmit ready
wait (transmit complete OR Receive complete)
if receive complete, clear flag and return
if transmit complete, continue
```

Once the OUT status stage has been received, the USB controller waits for a SETUP request. The SETUP request have priority over any other request and has to be ACK'ed. This means that any other flag should be cleared and the fifo reset when a SETUP is received.

WARNING: the byte counter is reset when the OUT Zero Length Packet is received. The firmware has to take care of this.

OUT EndpointOUT packets are sent by the host. All the data can be read by the CPU, which acknowl-
edges or not the bank when it is empty.

The Endpoint must be configured first.

"Manual" Mode

Overview

Control Read

Each time the current bank is full, the RXOUTI and the FIFOCON bits are set. This triggers an interrupt if the RXOUTE bit is set. The firmware can acknowledge the USB interrupt by clearing the RXOUTI bit. The Firmware read the data and clear the FIFO-CON bit in order to free the current bank. If the OUT Endpoint is composed of multiple





banks, clearing the FIFOCON bit will switch to the next bank. The RXOUTI and FIFO-CON bits are then updated by hardware in accordance with the status of the new bank.

RXOUTI shall always be cleared before clearing FIFOCON.

The RWAL bit always reflects the state of the current bank. This bit is set if the firmware can read data from the bank, and cleared by hardware when the bank is empty.





• The CPU can read the number of byte (N) in the current bank (N=BYCT),
	 The CPU can read the data from the current bank ("N" read of UEDATX), The CPU can free the bank by clearing FIFOCON when all the data is read, that is: after "N" read of UEDATX, as soon as RWAL is cleared by hardware. If the endpoint uses 2 banks, the second one can be filled by the HOST while the current one is being read by the CPU. Then, when the CPU clear FIFOCON, the next bank may be already ready and RXOUTI is set immediately.
Standard Mode with AUTOSW	 In this mode (AUTOSW set), the flow operation is the same as Section "standard Mode Without AUTOSW", page 108, with the exception that the CPU does not have to free the bank (FIFOCON cleared): this will automatically be done when the CPU read the last byte of the bank. EPINTx (RXOUTE set, RXOUTI set) or polling on RXOUTI=1 or FIFOCON=1, The CPU acknowledges the interrupt by clearing RXOUTI, The CPU read the number of byte (N) in the current bank (N=BYCT) (or already knows the number "N" of bytes at each packet), The CPU can read the data from the current bank ("N" read of UEDATX, or can read while RWAL is set). A clear of FIFOCON does not have any effects in this mode.
Using the DFC with AUTOSW	 In this mode (AUTOSW set, DFC programmed), the data are handled by the DFC without any intervention from the CPU. The flow is: programming of the DFC, poll End Of Transfer from the DFC. The bank switching is automatically done: when a bank is emptied, it is freed and the switch occurs. If the End Of Transfer occurs while the bank is not emptied, the CPU has the responsibility to free it. The CPU shall not use UEDATX or the byte counter BYCT in this mode. A clear of FIFOCON does not have any effects in this mode. If a ZLP is received, it will be filtered by the USB device controller, and the flag ZLP-SEEN is set.
Using the DFC without AUTOSW	 In this mode (AUTOSW cleared, DFC programmed), the data are handled by the DFC but the CPU have to acknowledge each bank read. programming of the DFC, EPINTx (RXOUTE set, RXOUTI set) or polling on RXOUTI=1 or FIFOCON=1, The CPU acknowledges the interrupt by clearing RXOUTI, poll the wait of the transfer: (while RWAL is set: wait), Clear FIFOCON which frees the bank and switch to the next one.
IN Endpoint Management	IN packets are sent by the USB device controller, upon an IN request from the host. All the data can be written by the CPU, which acknowledge or not the bank when it is full.
Overview	The Endpoint must be configured first.
"Manual" Mode	The TXINI bit is set by hardware when the current bank becomes free. This triggers an interrupt if the TXINE bit is set. The FIFOCON bit is set at the same time. The CPU





writes into the FIFO and clears the FIFOCON bit to allow the USB controller to send the data. If the IN Endpoint is composed of multiple banks, this also switches to the next data bank. The TXINI and FIFOCON bits are automatically updated by hardware regarding the status of the next bank.

TXINI shall always be cleared before clearing FIFOCON.

The RWAL bit always reflects the state of the current bank. This bit is set if the firmware can write data to the bank, and cleared by hardware when the bank is full.



"Autoswitch" Mode

In this mode, the clear of the FIFOCON bit is performed automatically by hardware each time the Endpoint bank is full. The firmware has to check if the next bank is empty or not before writing the next data. On TXINI interrupt, the firmware fills a complete bank. A new interrupt will be generated each time the current bank becomes free.

Detailed Description

Standard Mode without AUTOSW

In this mode (AUTOSW cleared), the data are written by the CPU, following the next flow:

- When the bank is empty, an endpoint interrupt (EPINTx) is triggered, if enabled (TXINE set) and TXINI is set. The CPU can also poll TXINI or FIFOCON, depending the software architecture choice,
- The CPU acknowledges the interrupt by clearing TXINI,
- The CPU can write the data into the current bank (write in UEDATX),

110 **AT85C51SND3B**

- The CPU can free the bank by clearing FIFOCON when all the data are written, that is:
 - after "N" write into UEDATX
 - as soon as RWAL is cleared by hardware.

If the endpoint uses 2 banks, the second one can be read by the HOST while the current is being written by the CPU. Then, when the CPU clears FIFOCON, the next bank may be already ready (free) and TXINI is set immediately.

Standard Mode with AUTOSW In this mode (AUTOSW set), the flow operation is the same as Section "Standard Mode without AUTOSW", page 110, with the exception that the CPU does not have to free the bank (FIFOCON cleared): this will automatically be done when the CPU fills the bank.

- EPINTx (TXINE set, TXINI set) or polling on TXINI=1 or FIFOCON=1,
- The CPU acknowledges the interrupt by clearing TXINI,
- The CPU can write the data to the current bank (write in UEDATX) while RWAL is set.

A clear of FIFOCON does not have any effects in this mode.

Using the DFC with AUTOSW In this mode (AUTOSW set, DFC programmed), the data are handled by the DFC without any intervention from the CPU. The flow is:

- programming of the DFC,
- poll End Of Transfer from the DFC.

The bank switching is automatically done: when a bank is filled, it is freed and the switch occurs. If the End Of Transfer occurs while the bank is not filled, the CPU has the responsibility to free it.

The CPU shall not use UEDATX or the byte counter BYCT in this mode. A clear of FIFOCON does not have any effects in this mode.

Using the DFC without AUTOSW In this mode (AUTOSW=0, DFC programmed), the data are handled by the DFC but the CPU have to acknowledge each bank written:

- programming of the DFC,
- EPINTx (TXINE set, TXINI set) or polling on TXINI=1 or FIFOCON=1,
- The CPU acknowledges the interrupt by clearing TXINI,
- poll the wait of the transfer: (while RWAL is set: wait),
- Clear FIFOCON which frees the bank and switch to the next one.

Abort

- An "abort" stage can be produced by the host in some situations:
- In a control transaction: ZLP data OUT received during a IN stage,
- In an isochronous IN transaction: ZLP data OUT received on the OUT endpoint during a IN stage on the IN endpoint

...

The KILLBK bit is used to kill the last "written" bank. The best way to manage this abort is to perform the following operations:





Table 111. Abort flow

hardware.



A clear of FIFOCON does not have any effects in this mode.

In the case that a SOF is missing (noise on USB pad, ...), the controller will automatically build internally a "pseudo" start of frame and the bank switching is made. The SOFI interrupt is triggered and the frame number FNUM10:0 is increased.

Underflow An underflow can occur during IN stage if the host attempts to read a bank which is empty. In this situation, the UNDERFI interrupt is triggered.

An underflow can also occur during OUT stage if the host send a packet while the banks are already full. Typically, he CPU is not fast enough. The packet is lost.

It is not possible to have underflow error during OUT stage, in the CPU side, since the CPU should read only if the bank is ready to give data (RXOUTI=1 or RWAL=1)

CRC Error A CRC error can occur during OUT stage if the USB controller detects a bad received packet. In this situation, the STALLI interrupt is triggered. This does not prevent the RXOUTI interrupt from being triggered.

Overflow In Control, Isochronous, Bulk or Interrupt Endpoint, an overflow can occur during OUT stage, if the host attempts to write in a bank that is too small for the packet. In this situation, the OVERFI interrupt is triggered (if enabled). The packet is acknowledged and the RXOUTI interrupt is also triggered (if enabled). The bank is filled with the first bytes of the packet.

It is not possible to have overflow error during IN stage, in the CPU side, since the CPU should write only if the bank is ready to access data (TXINI=1 or RWAL=1).

Isochronous Mode

Interrupts

Figure 62 shows all the device interrupts sources while Figure 63 details the endpoint interrupt sources.

Figure 62. USB Device Controller Interrupt System



There are 2 kinds of interrupts: processing (i.e. their generation are part of the normal processing) and exception (errors).

Processing interrupts are generated when the following events are triggered:

- VBUSTI: VBUS plug-in detection (insert, remove)
- UPRSMI: upstream resume
- EORSMI: end of resume
- WAKEUPI: Wake up
- EORSTI: end of reset (Speed Initialization)
- SOFI: start of frame (FNCERR= 0)
- MSOFI: micro start of frame (FNCERR= 0)
- SUSPI: suspend detected after 3 ms of inactivity

Exception Interrupts are generated when the following events are triggered:

- SOFI: CRC error in frame number of SOF (FNCERR= 1)
- MSOFI: CRC error in frame number of micro-SOF (FNCERR= 1)









Processing interrupts are generated when the following events are triggered:

- TXINI: ready to accept IN data
- RXOUTI: OUT data received
- RXSTPI: SETUP received

Exception Interrupts are generated when the following events are triggered:

- STALLI: stalled packet
- STALLI: CRC error on OUT in isochronous mode
- OVERFI: overflow in isochronous mode
- UNDERFI: underflow in isochronous mode
- NAKINI: NAK IN sent
- NAKOUTI: NAK OUT sent

Registers

USB Device General Registers

Table 112. UDCON Register

UDCON (1.D9h) - USB Device General Control Register

7	6	5	4	3	2	1	0		
-	-	-	-	-	-	RMWKUP	DETACH		
Bit Number	Bit Mnemonic	Description	Description						
7-2	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.						
1	RMWKUP	Remote Wall Set to send a Cleared by h See Section	Remote Wake-up Bit Set to send an "upstream-resume" to the host for a remote wake-up. Cleared by hardware. Clearing by software has no effect. See Section "Remote Wake-Up" for more details.						
0	DETACH	Detach Bit Set to physically detach de device. Clear to reconnect the device. See Section "Detach" for more details.							

Reset Value = 0000 0001b

Table 113. UDINT Register

UDINT (1.D8h) – USB Device Global Interrupt Register

7	6	5	4	3	2	1	0				
-	UPRSMI	EORSMI	WAKEUPI	EORSTI	SOFI	MSOFI	SUSPI				
Bit Number	Bit Mnemonic	Description	Description								
7	-	Reserved The value re	ad from these	bits is always	0. Do not set	these bits.					
6	UPRSMI	Upstream R Set by hard "Upstream R Shall be clea software has	Upstream Resume Interrupt Flag Set by hardware when the USB controller is sending a resume signal called "Upstream Resume". This triggers an USB interrupt if UPRSME is set. Shall be cleared by software (USB clocks must be enabled before). Setting by software has no effect.								
5	EORSMI	End Of Rest Set by hard signal initiate Shall be clea	End Of Resume Interrupt Flag Set by hardware when the USB controller detects a good "End Of Resume" signal initiated by the host. This triggers an USB interrupt if EORSME is set. Shall be cleared by software. Setting by software has no effect.								
4	WAKEUPI	Wake-up CF Set by hardw signal from ti WAKEUPE is Shall be clea by software I See Section	Shall be cleared by software. Setting by software has no effect. Wake-up CPU Interrupt Flag Set by hardware when the USB controller is re-activated by a filtered non-idle signal from the lines (not by an upstream resume). This triggers an interrupt if WAKEUPE is set. Shall be cleared by software (USB clock inputs must be enabled before). Setti by software has no effect. See Section "Suspend, Wake-Up and Resume" for more details.								



Bit Number	Bit Mnemonic	Description
3	EORSTI	End Of Reset Interrupt Flag Set by hardware when an "End Of Reset" has been detected by the USB controller. This triggers an USB interrupt if EORSTE is set. Shall be cleared by software. Setting by software has no effect.
2	SOFI	Start Of Frame Interrupt Flag Set by hardware when an USB "Start Of Frame" PID (SOF) has been detected (every 1 ms). This triggers an USB interrupt if SOFE is set.
1	MSOFI	Micro-Start Of Frame Interrupt Flag Set by hardware when an USB "Micro-Start Of Frame" PID (μ SOF) has been detected (every 125 μ s). This triggers an USB interrupt if MSOFE is set.
0	SUSPI	Suspend Interrupt Flag Set by hardware when an USB "Suspend" 'idle bus for 3 frame periods: a J state for 3 ms) is detected. This triggers an USB interrupt if SUSPE is set. Shall be cleared by software. Setting by software has no effect. See Section "Suspend, Wake-Up and Resume" for more details.

Table 114. UDIEN Register

UDIEN (1.DAh) – USB Device Global Interrupt Enable Register

7	6	5	4	3	2	1	0	
-	UPRSME	EORSME	WAKEUPE	EORSTE	SOFE	MSOFE	SUSPE	
Bit Number	Bit Mnemonic	Description						
7	-	Reserved The value re	ad from these	bits is always	0. Do not set	these bits.		
6	UPRSME	Upstream R Set to enable Clear to disa	esume Interro the UPRSMI ble the UPRS	upt Enable Bi interrupt. MI interrupt.	it			
5	EORSME	End Of Resu Set to enable Clear to disa	End Of Resume Interrupt Enable Bit Set to enable the EORSMI interrupt. Clear to disable the EORSMI interrupt.					
4	WAKEUPE	Wake-Up CF Set to enable Clear to disa	VU Interrupt E the WAKEUF ble the WAKE	Enable Bit PI interrupt. UPI interrupt.				
3	EORSTE	End Of Rese Set to enable Clear to disa	End Of Reset Interrupt Enable Bit Set to enable the EORSTI interrupt. This bit is set after a reset. Clear to disable the EORSTI interrupt.					
2	SOFE	Start Of Frame Interrupt Enable Bit Set to enable the SOFI interrupt. Clear to disable the SOFI interrupt.						
1	MSOFE	Micro-Start Set to enable Clear to disa	Of Frame Inte the MSOFI ir ble the MSOF	errupt Enable nterrupt. Tinterrupt.	Bit			

Bit Number	Bit Mnemonic	Description
0	SUSPE	Suspend Interrupt Enable Bit Set to enable the SUSPI interrupt. Clear to disable the SUSPI interrupt.

Table 115. UDADDR Register

UDADDR (1.DBh) - USB Device Address Register

7	6	5	4	3	2	1	0
ADDEN	UADD6	UADD5	UADD4	UADD3	UADD2	UADD1	UADD0
Bit Number	Bit Mnemonic	Description					
7	ADDEN	Address En Set to activat Cleared by h See Section	able Bit te the UADD (ardware. Clea "Address Setu	USB address) aring by softwa up" for more d). are has no effe etails.	ect.	
6-0	UADD6:0	USB Addres Set to configue Shall not be o	s Bits ure the device cleared.	address.			

Reset Value = 0000 0000b

Table 116. UDFNUMH Register

UDFNUMH (1.DCh) – USB Device Frame Number High Register

7	6	5	4	3	2	1	0	
-	-	-	-	-	FNUM10	FNUM9	FNUM8	
Bit Number	Bit Mnemonic	Description						
7-3	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.					
2-0	FNUM10:8	Frame Numl Set by hard information. updated if a d	ber Upper Fla ware. These They are pro corrupted SOI	ag bits are the ovided in the F is received.	3 MSB of th last receive	ne 11-bits Fra d SOF packe	ame Number et. FNUM is	

Reset Value = 0000 0000b

Table 117. UDFNUML Register

UDFNUML (1.DDh) – USB Device Frame Number Low Register

7	6	5	4	3	2	1	0
FNUM7	FNUM6	FNUM5	FNUM4	FNUM3	FNUM2	FNUM1	FNUM0





Bit Number	Bit Mnemonic	Description
7-0	FNUM7:0	Frame Number Lower Flag Set by hardware. These bits are the 8 LSB of the 11-bits Frame Number information.

Table 118. UDMFN Register

UDMFN (1.DEh) – USB Device Frame Number Register

7	6	5	4	3	2	1	0			
-	-	-	FNCERR	-		MFNUM2:0				
Bit Number	Bit Mnemonic	Description	Description							
7-5	-	Reserved The value rea	ad from these	bits is always	0. Do not se	t these bits.				
4	FNCERR	Frame Num Set by hardw received. This bit and t	ber CRC Erro vare when a he SOFI inter	r Flag corrupted Fra rupt are updat	ted at the sar	in start of fram ne time.	ne packet is			
3	-	Reserved The value rea	Reserved The value read from this bit is always 0. Do not set this bit.							
2-0	MFNUM2:0	Micro-Frame Number Flag Number of micro-frames (0 to 7) received in one frame. MFNUM is reset at the beginning of each new frame (every 1 ms).					reset at the			

Reset Value = 0000 0000b

USB Device Endpoint Registers

Table 119. UENUM Register

UENUM (1.C9h) – USB Endpoint Number Selection Register

7	6	5	4	3	2	1	0	
-	-	-	-	-	EPNUM2	EPNUM1	EPNUM0	
Bit Number	Bit Mnemonic	Description	Description					
7-3	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.					
2-0	EPNUM2:0	Endpoint Nu Set to select by the DFC Selection" for EPNUM = 11	the number of depending of more details b is forbidde	f the endpoint n UPNUMS t n.	which shall b bit in UECON	e accessed b IX. See Secti	y the CPU or on "Endpoint	

Reset Value = 0000 0000b

118 AT85C51SND3B

Table 120. UERST Register

UERST (1.CAh) – USB Endpoint Reset Register

7	6	5	4	3	2	1	0		
-	EPRST6	EPRST5	EPRST4	EPRST3	EPRST2	EPRST1	EPRST0		
Bit Number	Bit Mnemonic	Description	Description						
7	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.						
6-0	EPRST6:0	Endpoint FII Set to reset hardware re Section "End Then, cleare FIFO.	FO Reset Bits the selected eset or whe point Reset" f d by software	s l endpoint FII n an USB or more inforn to complete	FO prior to a bus reset h nation. the reset ope	ny other ope as been re eration and st	eration, upon ceived. See art using the		

Reset Value = 0000 0000b

Table 121. UECONX Register

UECONX (1.CBh) - USB Endpoint Control Register

7	6	5	4	3	2	1	0	
-	-	STALLRQ	STALLRQC	RSTDT	EPNUMS	DFCRDY	EPEN	
Bit Number	Bit Mnemonic	Description						
7-6	-	Reserved The value re	ad from these	bits is always	0. Do not set	these bits.		
5	STALLRQ	STALL Request Set to request Cleared by h no effect. See Section	TALL Request Handshake Bit Set to request a STALL answer to the host for the next handshake. Cleared by hardware when a new SETUP is received. Clearing by software has to effect. See Section "STALL Request" for more details.					
4	STALLRQC	STALL Requ Set to disabl Cleared by effect. See Section	STALL Request Clear Handshake Bit Set to disable the STALL handshake mechanism. Cleared by hardware immediately after the set. Clearing by software has no effect. See Section "STALL Request" for more details.					
3	RSTDT	Reset Data Toggle Bit Set to automatically clear the data toggle sequence: For OUT endpoint: the next received packet will have the data toggle 0. For IN endpoint: the next packet to be sent will have the data toggle 0. Cleared by hardware instantaneously. The firmware does not have to wait that the bit is cleared. Clearing by software has no effect.						
2	EPNUMS	Endpoint Number Select Bit Set to configure the EPNUM used by the DFC. Clear to select the EPNUM used by the CPU.						
1	DFCRDY	DFC Ready Set to resum Clear to paus	Bit e/enable the [se the DFC int	DFC interface erface.				





Bit Number	Bit Mnemonic	Description
0	EPEN	Endpoint Enable Bit Set to enable the endpoint according to the device configuration. Endpoint 0 shall always be enabled after a hardware or USB reset and participate in the device configuration. Clear this bit to disable the endpoint. See Section "Endpoint Activation" for more details.

Table 122. UECFG0X Register

UECFG0X (1.CCh) – USB Endpoint Configuration 0 Register

7	6	5	4	3	2	1	0		
EPTY	PE1:0	-	-	ISOSW	AUTOSW	NYETDIS	EPDIR		
Bit Number	Bit Mnemonic	Description							
7-6	EPTYPE1:0	Endpoint Ty Set this bit at 00b: Control 01b: Isochrol	Endpoint Type Bits Set this bit according to the endpoint configuration: 00b: Control 10b: Bulk 01b: Isochronous 11b: Interrupt						
5-4	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.						
3	ISOSW	Isochronous Switch Bit Set to automatically switch banks on each SOF. Clear to disable the automatic bank switching on each SOF. See Section "Isochronous Mode" for more details.							
2	AUTOSW	Automatic S Set to autom Clear to disa See Sectio Management	witch Bit atically switch ble the autom n "OUT End " for more de	i bank when it atic bank swit dpoint Mana tails.	is ready. ching. gement" an	d Section "II	N Endpoint		
1	NYETDIS	Not Yet Disable Bit Set to automatically send a "ACK" handshake instead of "Not Yet" handshake. Thus, the host will not have to "ping" for the next packet. Clear to automatically send "Not Yet" handshake. Thus, the host will have to "ping" for the next packet.							
0	EPDIR	Endpoint Di Set to config Clear to con endpoints.	rection Bit ure an IN dire figure an OU	ction for bulk, T direction fo	interrupt or is r bulk, interru	ochronous end pt, isochronoi	dpoints. us or control		

Reset Value = 0000 0000b

Table 123. UECFG1X Register

UECFG1X (1.CDh) – USB Endpoint Configuration 1 Register

7	6	5	4	3	2	1	0
-	EPSIZE2	EPSIZE1	EPSIZE0	EPBK1	EPBK	ALLOC	-

Bit Number	Bit Mnemonic	Description
7	-	Reserved The value read from these bits is always 0. Do not set these bits.
6-4	EPSIZE2:0	Endpoint Size BitsSet this bit according to the endpoint size:000b: 8 bytes100b: 128 bytes001b: 16 bytes101b: 256 bytes010b: 32 bytes110b: 512 bytes011b: 64 bytes111b: Reserved. Do not use this configuration.
3-2	EPBK1:0	Endpoint Bank Bits Set this field according to the endpoint size: 00b: Single bank 01b: Double bank 1xb: Reserved. Do not use this configuration.
1	ALLOC	Endpoint Allocation Bit Set this bit to allocate the endpoint memory. Clear to free the endpoint memory. See Section "Endpoint Activation" for more details.
0	-	Reserved The value read from these bits is always 0. Do not set these bits.

Table 124. UESTA0X Register

UESTA0X (1.CEh) – USB Endpoint Status 0 Register

7	6	5	4	3	2	1	0		
CFGOK	OVERFI	UNDERFI	ZLPSEEN	DTSEQ1	DTSEQ0	NBUSYBK1	NBUSYBK0		
Bit Number	Bit Mnemonic	Description							
7	CFGOK	Configuration Set by hardwork parametrizat max number If this bit is correct EPSI	Configuration Status Flag Set by hardware when the endpoint X size parameter (EPSIZE) and the bank barametrization (EPBK) are correct compared to the max FIFO capacity and the max number of allowed bank. This bit is updated when the bit ALLOC is set. If this bit is cleared, the user should reprogram the UECFG1X register with correct EPSIZE and EPBK values.						
6	OVERFI	Overflow Er Set by hardw interrupt (EP See Section Shall be clea	Overflow Error Interrupt Flag Set by hardware when an overflow error occurs in an isochronous endpoint. An interrupt (EPINTx) is triggered (if enabled). See Section "Isochronous Mode" for more details. Shall be cleared by software. Setting by software has no effect.						
5	UNDERFI	Flow Error Interrupt Flag Set by hardware when an underflow error occurs in an isochronous endpoint. An interrupt (EPINTx) is triggered (if enabled). See Section "Isochronous Mode" for more details. Shall be cleared by software. Setting by software has no effect.							
4	ZLPSEEN	Zero Length Set by hardw Shall be clea	a Packet Seer vare, as soon ared by the sof	ι (bit / Flag) as a ZLP has ftware. Setting	been filtered by software	during a trans has no effect.	fer.		



Bit Number	Bit Mnemonic	Description
3-2	DTSEQ1:0	Data Toggle Sequencing Flag Set by hardware to indicate the PID data of the current bank: 00b: Data0 01b: Data1 1xb: Reserved. For OUT transfer, this value indicates the last data toggle received on the current bank. For IN transfer, it indicates the Toggle that will be used for the next packet to be sent. This is not relative to the current bank.
1-0	NBUSYBK1: 0	Busy Bank Flag Set by hardware to indicate the number of busy bank. For IN endpoint, it indicates the number of busy bank(s), filled by the user, ready for IN transfer. For OUT endpoint, it indicates the number of busy bank(s) filled by OUT transaction from the host. 00b: All banks are free 01b: 1 busy bank 10b: 2 busy banks 11b: Reserved.

Table 125. UESTA1X Register

UESTA1X (1.CFh) – USB Endpoint Status 1 Register

7	6	5	4	3	2	1	0				
-	-	-	-	-	CTRLDIR	CURRBK1	CURRBK0				
Bit Number	Bit Mnemonic	Description	Description								
7-3	-	Reserved The value re	Reserved The value read from these bits is always 0. Do not set these bits.								
2	CTRLDIR	Control Dire Set by hardw packet: - 1 for IN end - 0 for OUT e Can not be s	Control Direction (Flag, and bit for debug purpose) Set by hardware after a SETUP packet, and gives the direction of the following packet: - 1 for IN endpoint - 0 for OUT endpoint. Can not be set or cleared by software.								
1-0	CURRBK1:0	Current Bar Set by hardw 00b: Bank0 01b: Bank1 1xb: Reserve Can not be s	ik (all endpoi vare to indicat ed. et or cleared	nts except Co e the number by software.	ontrol endpoi of the current	int) Flag bank:					

Table 126. UEINTX Register (bit addressable)

UEINTX (1.C8h) – USB Endpoint Interrupt Register

7	6	5	4	3	2	1	0			
FIFOCON	NAKINI	RWAL	NAKOUTI	RXSTPI	RXOUTI	STALLI	TXINI			
Bit Number	Bit Mnemonic	Description								
7	FIFOCON	FIFO Contro For OUT and Set by hardv same time th Clear to free software has For IN Endpo Set by hardw Clear to sen effect.	FIFO Control Bit For OUT and SETUP Endpoint: Set by hardware when a new OUT message is stored in the current bank, at the same time than RXOUT or RXSTP. Clear to free the current bank and to switch to the following bank. Setting by software has no effect. For IN Endpoint: Set by hardware when the current bank is free, at the same time than TXIN. Clear to send the FIFO data and to switch the bank. Setting by software has no effect.							
6	NAKINI	NAK IN Rec Set by hardwrequest from Shall be clea	NAK IN Received Interrupt Flag Set by hardware when a NAK handshake has been sent in response of a IN request from the host. This triggers an USB interrupt if NAKINE is sent. Shall be cleared by software. Setting by software has no effect.							
5	RWAL	Read/Write Allowed Flag Set by hardware to signal: - for an IN endpoint: the current bank is not full i.e. the firmware can push data into the FIFO, - for an OUT endpoint: the current bank is not empty, i.e. the firmware can read data from the FIFO. The bit is never set if STALLRQ is set, or in case of error. Cleared by hardware otherwise.								
4	NAKOUTI	NAK OUT R Set by hard OUT/PING r sent. Shall be clea	eceived Intern ware when a equest from th ared by softwa	r upt Flag NAK hands le host. This t re. Setting by	hake has be riggers an US software has	en sent in re B interrupt if no effect.	sponse of a NAKOUTE is			
3	RXSTPI	Received SETUP Interrupt Flag Set by hardware to signal that the current bank contains a new valid SETUP packet. An interrupt (EPINTx) is triggered (if enabled). Shall be cleared by software to acknowledge the interrupt. Setting by software has no effect. This bit is inactive (cleared) if the endpoint is an IN endpoint.								
2	RXOUTI / KILLBK	Received O Set by hard interrupt (EP Shall be clea has no effect Kill Bank IN Set this bit to Cleared by h See Section	UT Data Intern ware to signa INTx) is trigge ared by softwa t. Bit b kill the last w ardware when "Abort" for mo	rupt Flag Il that the cu red (if enable are to acknow ritten bank. I the bank is k re details on t	rrent bank cd d). /ledge the intr illed. Clearing the Abort.	ontains a nev errupt. Setting y by software t	v packet. An) by software nas no effect.			





Bit Number	Bit Mnemonic	Description
1	STALLI	Stall Interrupt Flag Set by hardware to signal that a STALL handshake has been sent, or that a CRC error has been detected in a OUT isochronous endpoint. Shall be cleared by software. Setting by software has no effect.
0	TXINI	Transmitter Ready Interrupt Flag Set by hardware to signal that the current bank is free and can be filled. An interrupt (EPINTx) is triggered (if enabled). Shall be cleared by software to acknowledge the interrupt. Setting by software has no effect. This bit is inactive (cleared) if the endpoint is an OUT endpoint.

Table 127. UEIENX Register

UEIENX (1.D2h) – USB Endpoint Interrupt Enable Register

7	6	5	4	3	2	1	0		
FLERRE	NAKINE	-	NAKOUTE	RXSTPE	RXOUTE	STALLE	TXINE		
Bit Number	Bit Mnemonic	Description							
7	FLERRE	Flow Error I Set to enabl sent. Clear to disa sent.	Flow Error Interrupt Enable Flag Set to enable an endpoint interrupt (EPINTx) when OVERFI or UNDERFI are sent. Clear to disable an endpoint interrupt (EPINTx) when OVERFI or UNDERFI are sent.						
6	NAKINE	NAK IN Inter Set to enable Clear to disa	NAK IN Interrupt Enable Bit Set to enable an endpoint interrupt (EPINTx) when NAKINI is set. Clear to disable an endpoint interrupt (EPINTx) when NAKINI is set.						
5	-	Reserved The value re	ad from these	bits is always	0. Do not set	these bits.			
4	NAKOUTE	NAK OUT In Set to enable Clear to disa	terrupt Enab e an endpoint ble an endpoi	le Bit interrupt (EPII nt interrupt (E	NTx) when NA PINTx) when	AKOUTI is set NAKOUTI is s	set.		
3	RXSTPE	Received SI Set to enable Clear to disa	ETUP Interrup e an endpoint ble an endpoi	ot Enable Fla interrupt (EPII nt interrupt (E	g NTx) when RX PINTx) when	(STPI is sent. RXSTPI is se	nt.		
2	RXOUTE	Received O Set to enable Clear to disa	UT Data Inter e an endpoint ble an endpoi	rupt Enable I interrupt (EPII nt interrupt (E	Flag NTx) when RX PINTx) when	(OUTI is sent. RXOUTI is se	nt.		
1	STALLE	Stall Interrupt Enable Flag Set to enable an endpoint interrupt (EPINTx) when STALLI is sent. Clear to disable an endpoint interrupt (EPINTx) when STALLI is sent.							
0	TXINE	Transmitter Set to enable Clear to disa	Transmitter Ready Interrupt Enable Flag Set to enable an endpoint interrupt (EPINTx) when TXINI is sent. Clear to disable an endpoint interrupt (EPINTx) when TXINI is sent.						

Table 128. UEDATX Register

UEDATX (1.D3h) - USB Endpoint Data Register

7	6	5	4	3	2	1	0
DAT7	DAT6	DAT5	DAT4	DAT3	DAT2	DAT1	DAT0
Bit Number	Bit Mnemonic	Description					
7-0	DAT7:0	Data Bits Set by the s EPNUM.	oftware to rea	ad/write a byte	e from/to the e	endpoint FIFC) selected by

Reset Value = 0000 0000b

Table 129. UEBCHX Register

UEBCHX (1.D4h) - USB Endpoint Byte Counter High Register

7	6	5	4	3	2	1	0	
-	-	-	-	-	BYCT10	BYCT9	BYCT8	
Bit Number	Bit Mnemonic	Description						
7-3	-	Reserved The value re	eserved he value read from these bits is always 0. Do not set these bits.					
2-0	BYCT10:8	Byte count of Set by hardw The LSB par	(high) Bits vare. This fiel t is provided b	d is the MSB by the UEBCL	of the byte co X register.	ount of the FI	FO endpoint.	

Reset Value = 0000 0000b

Table 130. UEBCLX Register

UEBCLX (1.D5h) - USB Endpoint Byte Counter Low Register

7	6	5	4	3	2	1	0
BYCT7	BYCT6	BYCT5	BYCT4	BYCT3	BYCT2	BYCT1	BYCT0
Bit Number	Bit Mnemonic	Description					
7-0	BYCT7:0	Byte Count Set by the ha - (for IN e decremented - (for OUT decremented	(low) Bits ardware. BYC ndpoint) incr after each by endpoint) in after each by	T10:0 is: eased after rte sent, creased afte rte read by the	each writing r each byte e software.	into the e sent by the	ndpoint and e host, and





Table 131. UEINT Register

UEINT (1.D6h) – USB Endpoint Interrupt Register

7	6	5	4	3	2	1	0		
-	EPINT6	EPINT5	EPINT4	EPINT3	EPINT2	EPINT1	EPINT0		
Bit Number	Bit Mnemonic	Description	Description						
7	-	Reserved The value rea	eserved he value read from these bits is always 0. Do not set these bits.						
6-0	EPINT6:0	Endpoint Int Set by hardw correspondin Cleared by h	errupts Bits rare when an g endpoint int ardware wher	interrupt is trig terrupt enable the interrupt	gered by the bit is set. source is serv	UEINTX regis ved.	ter and if the		

USB Host Operating Modes

Pipe Description

For the USB Host controller, the term of Pipe is used instead of Endpoint for the USB Device controller (see Figure 64). A Host Pipe corresponds to a Device Endpoint, as described in the USB specification.





In the USB host controller, a Pipe will be associated to a Device Endpoint, considering the Device Configuration Descriptors.

Detach The reset value of the DETACH bit is 1. Thus, the firmware has the responsibility of clearing this bit before switching to the Host mode (HOST set).

Power-on and Reset

Figure 65 shows the USB host controller main states after power-on.

Figure 65. USB Host Controller Reset State Machine



USB host controller state after an hardware reset is 'Reset'. When the USB controller is enabled and the USB Host controller is selected, the USB controller is in 'Idle' state. In this state, the USB Host controller waits for the Device connection, **with a minimum power consumption**. The USB Pad should be in Idle mode. The macro does not need to have the PLL activated to enter in 'Host Ready' state.





The Host controller enters in Suspend state when the USB bus is in Suspend state, i.e. when the Host controller doesn't generate the Start of Frame. In this state, the USB consumption is minimum. The Host controller exits to the Suspend state when starting to generate the SOF over the USB line.

Device Detection A Device is detected by the USB controller when the USB bus if different from D+ and D- low. In other words, when the USB Host Controller detects the Device pull-up on the D+ line. To enable this detection, the Host Controller has to provide the Vbus power supply to the Device.

The Device Disconnection is detected by the USB Host controller when the USB Idle correspond to D_{+} and D_{-} low on the USB line.

Pipe SelectionPrior to any operation performed by the CPU, the Pipe must first be selected. This is
done by:

- Clearing PNUMS.
- Setting PNUM with the Pipe number which will be managed by the CPU.

The CPU can then access to the various Pipe registers and data.

In the same manner, if the Pipe must be accessed by the DFC, it must first be selected. This is done by:

- Setting PNUMS.
- Setting PNUM with the Pipe number which will be managed by the DFC.
- Setting DFCRDY when the data-flow is ready to take place.

The DFC can then access to the banks (read / write).

The controller internally keeps in memory the PNUM for the CPU and the PNUM for the DFC. In fact, there are 2 PNUM registers multiplexed by the PNUMS bit. Each of them can be read or written by the CPU.

These two registers permits to easily switch from a Pipe under DFC data transfer to the default control Pipe when a SETUP has to be sent, without reprogramming the EPNUM register:

- Set PNUMS,
- PNUM = $Pipe_x$
- Set DFCRDY when the DFC transfer is ready to take place,
- ...<DFC transfer>...
- SETUP required on Pipe₀,
- Clear DFCRDY to freeze the DFC transfer,
- PNUMS cleared,
- PNUM = Pipe₀
- Manage Pipe₀ data
- Set DFCRDY. This resumes the DFC transfer.

Pipe Configuration

The following flow must be respected in order to activate a Pipe:

Figure 66. Pipe activation flow:



Once the Pipe is activated (EPEN set) and, the hardware is ready to send requests to the Device.

When configured (CFGOK = 1), only the Pipe Token (PTOKEN) and the polling interval for Interrupt pipe can be modified.

A Control type pipe supports only 1 bank. Any other value will lead to a configuration error (CFGOK = 0).

A clear of PEN will reset the configuration of the Pipe. All the corresponding Pipe registers are reset to there reset values. Please refers to the Memory Management chapter for more details.

Note: The firmware has to configure the Default Control Pipe with the following parameters:

- Type: Control
- Token: SETUP
- Data bank: 1
- Size: 64 Bytes

The firmware asks for 8 bytes of the Device Descriptor sending a GET_DESCRIPTOR request. These bytes contains the MaxPacketSize of the Device default control endpoint and the firmware re-configures the size of the Default Control Pipe with this size parameter.



USB Reset	The USB controller sends a USB Reset when the firmware set the RESET bit. The RSTI bit is set by hardware when the USB Reset has been sent. This triggers an interrupt if the RSTE has been set.
	When a USB Reset has been sent, all the Pipe configuration and the memory allocation are reset. The General Host interrupt enable register is left unchanged.
	If the bus was previously in suspend mode (SOFE = 0), the USB controller automatically switches to the resume mode (HWUPI is set) and the SOFE bit is set by hardware in order to generate SOF immediately after the USB Reset.
Address Setup	Once the Device has answer to the first Host requests with the default address (0), the Host assigns a new address to the device. The Host controller has to send a USB reset to the device and perform a SET ADDRESS control request, with the new address to be used by the Device. This control request ended, the firmware write the new address into the UHADDR register. All following requests, on every Pipes, will be performed using this new address.
	When the Host controller send a USB reset, the UHADDR register is reset by hardware and the following Host requests will be performed using the default address (0).
Remote Wake-Up Detection	The Host Controller enters in Suspend mode when clearing the SOFE bit. No more Start Of Frame is sent on the USB bus and the USB Device enters in Suspend mode 3ms later.
	The Device awakes the Host Controller by sending an Upstream Resume (Remote Wake-Up feature). The Host Controller detects a non-idle state on the USB bus and set the HWUPI bit. If the non-Idle correspond to an Upstream Resume (K state), the RXRSMI bit is set by hardware. The firmware has to generate a downstream resume within 1ms and for at least 20ms by setting the RESUME bit.
	Once the downstream Resume has been generated, the SOFE bit is automatically set by hardware in order to generate SOF immediately after the USB resume.
	Host Ready SOFE=0 Host
	or HWUP=1 Suspend
USB Pipe Reset	The firmware can reset a Pipe using the pipe reset register. The configuration of the pipe and the data toggle remains unchanged. Only the bank management and the status bits are reset to their initial values.
	To completely reset a Pipe, the firmware has to disable and then enable the pipe.
Pipe Data Access	In order to read or to write into the Pipe Fifo, the CPU selects the Pipe number with the UPNUM register and performs read or write action on the UPDATX register.
Control Pipe Management	 A Control transaction is composed of 3 phases: SETUP Data (IN or OUT) Status (OUT or IN)

The firmware has to change the Token for each phase.

The initial data toggle is set for the corresponding token (ONLY for Control Pipe):

- SETUP: Data0
- OUT: Data1
- IN: Data1 (expected data toggle)

OUT Pipe Management The Pipe must be configured and not frozen first.

Note: if the firmware decides to switch to suspend mode (clear SOFE) even if a bank is ready to be sent, the USB controller will automatically exit from Suspend mode and the bank will be sent.





"Manual" Mode

The TXOUT bit is set by hardware when the current bank becomes free. This triggers an interrupt if the TXOUTE bit is set. The FIFOCON bit is set at the same time. The CPU writes into the FIFO and clears the FIFOCON bit to allow the USB controller to send the data. If the OUT Pipe is composed of multiple banks, this also switches to the next data bank. The TXOUT and FIFOCON bits are automatically updated by hardware regarding the status of the next bank.





132 **AT85C51SND3B**

"Autoswitch" Mode	In this mode, the clear of the FIFOCON bit is performed automatically by hardware each time the Pipe bank is full. The firmware has to check if the next bank is empty or not before writing the next data. On TXOUT interrupt, the firmware fills a complete bank. A new interrupt will be generated each time the current bank becomes free.
IN Pipe management	The Pipe must be configured first.
"Manual" Mode	When the Host requires data from the device, the firmware has to determine first the IN mode to use using the INMODE bit:
	 INMODE = 0. The INRQX register is taken in account. The Host controller will perform (INRQX+1) IN requests on the selected Pipe before freezing the Pipe. This mode avoids to have extra IN requests on a Pipe.
	 INMODE – 1. The USB controller will perform infinite IN request until the firmware

 INMODE = 1. The USB controller will perform infinite IN request until the firmware freezes the Pipe.

The IN request generation will start when the firmware clear the PFREEZE bit.

Each time the current bank is full, the RXIN and the FIFOCON bits are set. This triggers an interrupt if the RXINE bit is set. The firmware can acknowledge the USB interrupt by clearing the RXIN bit. The Firmware read the data and clear the FIFOCON bit in order to free the current bank. If the IN Pipe is composed of multiple banks, clearing the FIFO-CON bit will switch to the next bank. The RXIN and FIFOCON bits are then updated by hardware in accordance with the status of the new bank.







"Autoswitch" Mode In this mode, the clear of the FIFOCON bit is performed automatically by hardware each time the Pipe bank is empty. The firmware has to check if the next bank is empty or not before reading the next data. On RXIN interrupt, the firmware reads a complete bank. A new interrupt will be generated each time the current bank contains data to read.

The acknowledge of the RXIN interrupt is always performed by software.

CRC Error (isochronous only) A CRC error can occur during IN stage if the USB controller detects a bad received packet. In this situation, the STALLEDI/CRCERRI interrupt is triggered. This does not prevent the RXINI interrupt from being triggered.

Interrupt Figure 67 shows all the host interrupts sources while Figure 68 details the pipe interrupt sources.







Figure 68. USB Host Controller Pipe Interrupt System





Registers

General USB Host Registers

Table 132. UHCON Register

UHCON (1.D9h) - USB Host General Control Register

7	6	5	4	3	2	1	0		
-	-	-	-	-	RESUME	RESET	SOFE		
Bit Number	Bit Mnemonic	Description							
7-3	-	Reserved The value re	ad from these	bits is always	0. Do not set	these bits.			
2	RESUME	Send USB F Set this bit to Cleared by software has	Send USB Resume Set this bit to generate a USB Resume on the USB bus. Cleared by hardware when the USB Resume has been sent. Clearing by software has no effect.						
1	RESET	Send USB F Set this bit to Cleared by h has no effect Refer to the	leset generate a L ardware whe USB reset see	JSB Reset on n the USB Re ction for more	the USB bus. set has been details.	sent. Clearing	g by software		
0	SOFE	Start Of Fran Set this bit to Clear this bir state.	me Generation generate SC t to disable th	on Enable OF on the USB ne SOF gener	bus. ration and to	leave the US	B bus in Idle		

Reset Value = 0000 0000b

Table 133. UHINT Register

UHINT (1.D8h) – USB Host General Interrupt Register

7	6	5	4	3	2	1	0				
-	HWUP	HSOF	RXRSMI	RSMEDI	RSTI	DDISCI	DCONNI				
Bit Number	Bit Mnemonic	Description	Description								
7	-	Reserved The value rea	Reserved The value read from this bit is always 0. Do not set this bit.								
6	HWUP	Host Wake-I Set by hardw Shall be clea no effect.	Host Wake-Up Interrupt Set by hardware when a non-idle state is detected on the USB bus. Shall be clear by software to acknowledge the interrupt. Setting by software has no effect.								
5	HSOFI	Host Start O Set by hardw USB interrup Shall be clea has no effect	f Frame Inter vare when a t when HSOF ared by softwa	r rupt SOF is issued E is set. are to acknow	d by the Host ledge the inte	controller. Th errupt. Setting	nis triggers a I by software				

Bit Number	Bit Mnemonic	Description
4	RXRSMI	Upstream Resume Received Interrupt Set by hardware when an Upstream Resume has been received from the Device. Shall be cleared by software. Setting by software has no effect.
3	RSMEDI	Downstream Resume Sent Interrupt Set by hardware when a Downstream Resume has been sent to the Device. Shall be cleared by software. Setting by software has no effect.
2	RSTI	USB Reset Sent Interrupt Set by hardware when a USB Reset has been sent to the Device. Shall be cleared by software. Setting by software has no effect.
1	DDISCI	Device Disconnection Interrupt Set by hardware when the device has been removed from the USB bus. Shall be cleared by software. Setting by software has no effect.
0	DCONNI	Device Connection Interrupt Set by hardware when a new device has been connected to the USB bus. Shall be cleared by software. Setting by software has no effect.

Table 134. UHIEN Register

UHIEN (1.DAh) – USB Host General Interrupt Enable Register

7	6	5	4	3	2	1	0		
-	HWUPE	HSOFE	RXRSME	RSMEDE	RSTE	DDISCE	DCONNE		
Bit Number	Bit Mnemonic	Description							
7	-	Reserved The value re	ad from this b	it is always 0.	Do not set thi	s bit.			
6	HWUPE	Host Wake- Set this bit to Clear this bit	Host Wake-Up Interrupt Enable Set this bit to enable HWUP interrupt. Clear this bit to disable HWUP interrupt.						
5	HSOFE	Host Start C Set this bit to Clear this bit	Host Start Of frame Interrupt Enable Set this bit to enable HSOF interrupt. Clear this bit to disable HSOF interrupt.						
4	RXRSME	Upstream R Set this bit to Clear this bit	esume Recei enable the R to disable the	ved Interrupt XRSMI interru RXRSMI inte	E nable upt. errupt.				
3	RSMEDE	Downstream Set this bit to Clear this bit	Downstream Resume Sent Interrupt Enable Set this bit to enable the RSMEDI interrupt. Clear this bit to disable the RSMEDI interrupt.						
2	RSTE	USB Reset Set this bit to Clear this bit	USB Reset Sent Interrupt Enable Set this bit to enable the RSTI interrupt. Clear this bit to disable the RSTI interrupt.						
1	DDISCE	Device Disc Set this bit to Clear this bit	onnection In enable the D to disable the	terrupt Enabl DISCI interrup DDISCI inter	e ot. rupt.				





Bit Number	Bit Mnemonic	Description
0	DCONNE	Device Connection Interrupt Enable Set this bit to enable the DCONNI interrupt. Clear this bit to disable the DCONNI interrupt.

Table 135. UHADDR Register

UHADDR (1.DBh) – USB Host Address Register

7	6	5	4	3	2	1	0		
-	HADDR6	HADDR5	HADDR4	HADDR3	HADDR2	HADDR1	HADDR0		
Bit Number	Bit Mnemonic	Description							
7	-	Reserved The value rea	leserved he value read from this bit is always 0. Do not set this bit.						
6-0	HADDR6:0	USB Host A These bits co	USB Host Address These bits contains the address of the USB Device.						

Reset Value = 0000 0000b

Table 136. UHFNUMH Register

UHFNUMH (1.DCh) – USB Host Frame Number High Register

7	6	5	4	3	2	1	0			
-	-	-	-	-	FNUM10	FNUM9	FNUM8			
Bit Number	Bit Mnemonic	Description	Description							
7-4	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.							
3-0	FNUM10:8	Frame Number The value contained in tis register is the current SOF number. This value can be modified by software.								

Table 137. UHFNUML Register

UHFNUML (1.DDh) – USB Host Frame Number Low Register

7	6	5	4	3	2	1	0		
FNUM7	FNUM6	FNUM5	FNUM4	FNUM3	FNUM2	FNUM1	FNUM0		
Bit Number	Bit Mnemonic	Description							
7-0	FNUM7:0	Frame Numl The value co This value ca	Frame Number The value contained in tis register is the current SOF number. This value can be modified by software.						

Reset Value = 0000 0000b

Table 138. UHFLEN Register

UHFLEN (1.DEh) - USB Host Frame Length Register

7	6	5	4	3	2	1	0
FLEN7	FLEN6	FLEN5	FLEN4	FLEN3	FLEN2	FLEN1	FLEN0
		i					
Bit Number	Bit Mnemonic	Description					
7-0	FLEN7:0	Frame Leng The value co	th ntained				

Reset Value = 0000 0000b

USB Host Pipe Registers

Table 139. UPNUM Register

UPNUM (1.C9h) - USB Host Pipe Number Register

7	6	5	4	3	2	1	0			
-	-	-	-	-	PNUM2	PNUM1	PNUM0			
Bit Number	Bit Mnemonic	Description	Description							
7-3	-	Reserved The value read from these bits is always 0. Do not set these bits.								
2-0	PNUM2:0	Pipe Number Select the p correspond t This number	Pipe Number Select the pipe using this register. The USB Host registers ended by a X correspond then to this number. This number is used for the USB controller following the value of the PNUMD bit.							





Table 140. UPRST Register

UPRST (1.CAh) – USB Host Pipe Reset Register

7	6	5	4	3	2	1	0				
-	P6RST	P5RST	P4RST	P3RST	P2RST	P1RST	PORST				
Bit Number	Bit Mnemonic	Description	Description								
7	-	Reserved The value rea	leserved The value read from this bit is always 0. Do not set this bit.								
6	P6RST	Pipe 6 Reset Set this bit to	ipe 6 Reset et this bit to 1 and reset this bit to 0 to reset the Pipe 6.								
5	P5RST	Pipe 5 Reset Set this bit to	Pipe 5 Reset Set this bit to 1 and reset this bit to 0 to reset the Pipe 5.								
4	P4RST	Pipe 4 Reset Set this bit to	Pipe 4 Reset Set this bit to 1 and reset this bit to 0 to reset the Pipe 4.								
З	P3RST	Pipe 3 Reset Set this bit to	t 1 and reset t	his bit to 0 to r	eset the Pipe	3.					
2	P2RST	Pipe 2 Reset Set this bit to	t 1 and reset t	his bit to 0 to r	eset the Pipe	2.					
1	P1RST	Pipe 1 Reset Set this bit to	Pipe 1 Reset Set this bit to 1 and reset this bit to 0 to reset the Pipe 1.								
0	PORST	Pipe 0 Reset Set this bit to	t 1 and reset t	his bit to 0 to r	eset the Pipe	0.					

Reset Value = 0000 0000b

Table 141. UPCONX Register

UPCONX (1.CBh) – USB Host Pipe Control Register

7	6	5	4	3	2	1	0				
-	PFREEZE	INMODE	AUTOSW	RSTDT	PNUM	DFCRDY	PEN				
Bit Number	Bit Mnemonic	Description									
7	-	Reserved The value rea	Reserved The value read from this bit is always 0. Do not set this bit.								
6	PFREEZE	Pipe Freeze Set this bit to Clear this bit This bit is set - the pipe is r - a STALL ha - An error occ - (INRQ+1) In This bit is set	Pipe Freeze Set this bit to Freeze the Pipe requests generation. Clear this bit to enable the Pipe request generation. This bit is set by hardware when: • the pipe is not configured • a STALL handshake has been received on this Pipe • An error occurs on the Pipe (PERR = 1) • (INRQ+1) In requests have been processed Dis bit is set at 1 by bardware offer a Pipe processed								

Bit Number	Bit Mnemonic	Description
5	INMODE	IN Request mode Set this bit to allow the USB controller to perform infinite IN requests when the Pipe is not frozen. Clear this bit to perform a pre-defined number of IN requests. This number is stored in the UINRQX register.
4	AUTOSW	Auto Switch Bank Set this bit to allow the auto switch bank mode for this Pipe. Clear this bit to otherwise.
3	RSTDT	Reset Data Toggle Set this bit to reset the Data Toggle to its initial value for the current Pipe. Cleared by hardware when proceed. Clearing by software has no effect.
2	PNUMS	Pipe Number Select Bit Set to configure the PNUM used by the DFC. Clear to configure the PNUM used by the CPU.
1	DFCRDY	DFC Ready Bit Set to resume/enable the DFC interface. Clear to pause the DFC interface.
0	PEN	Pipe Enable Set to enable the Pipe. Clear to disable and reset the Pipe.

Table 142. UPCFG0X Register

UPCFG0X (1.CCh) – USB Pipe Configuration 0 Register

7	6	5	4	3	2	1	0			
PTYPE1	PTYPE0	PTOKEN1	PTOKEN0	PEPNUM3	PEPNUM2	PEPNUM1	PEPNUM0			
Bit Number	Bit Mnemonic	Description								
7-6	PTYPE1:0	Pipe Type Select the ty - 00: Control - 01: Isochro - 10: Bulk - 11: Interrup	tipe Type ielect the type of the Pipe: 00: Control 01: Isochronous 10: Bulk 11: Interrupt							
5-4	PTOKEN1:0	Pipe Token Select the To - 00: SETUP - 01: IN - 10: OUT - 11: reserve	Pipe Token Select the Token to associate to the Pipe: - 00: SETUP - 01: IN - 10: OUT - 11: reserved							
3-0	PEPNUM3:0	Pipe Endpoi Set this field targeted by t	int Number according to the Pipe. This	the Pipe config value is from	guration. Set t 0 and 15.	he number of	the Endpoint			





Table 143. UPCFG1X Register

UPCFG1X (1.CDh) – USB Pipe Configuration 1 Register

7	6	5	4	3	2	1	0					
-	PSIZE2	PSIZE1	PSIZE0	PBK1	PBK0	ALLOC	-					
Bit Number	Bit Mnemonic	Description	escription									
7	-	Reserved The value rea	ad from this b	it is always 0.	Do not set thi	s bit.						
6-4	PSIZE2:0	Pipe Size Select the siz - 000: 8 - 001: 16 - 010: 32 - 011: 64 - 100: 128 - 101: 256 - 110: 512 - 111: 1024	ze of the Pipe	:								
3-2	PBK1:0	Pipe Bank Select the nu - 00: 1 bank - 01: 2 banks - 10: invalid - 11: invalid	Pipe Bank Select the number of bank to declare for the current Pipe. - 00: 1 bank - 01: 2 banks - 10: invalid - 11: invalid									
1	ALLOC	Configure P Set to configu Clear to upo chapter for m	Configure Pipe Memory Set to configure the pipe memory with the characteristics. Clear to update the memory allocation. Refer to the Memory Management chapter for more details.									
0	-	Reserved The value rea	ad from these	bits is always	0. Do not set	these bits.						

Reset Value = 0000 0000b

Table 144. UPCFG2X Register

UPCFG2X (1.CFh) – USB Pipe Configuration 2 Register

7	6	5	4	3	2	1	0
INTFRQ7	INTFRQ6	INTFRQ5	INTFRQ4	INTFRQ3	INTFRQ2	INTFRQ1	INTFRQ0
Bit Number	Bit Mnemonic	Description					
7-0	INTFRQ7:0	Interrupt Pip These bits a Interrupt Pipe This value ha	be Request F are the maxim e. as no effect fo	requency num value in r a non-Interru	millisecond o upt Pipe.	f the pulling p	period for an

Table 145. UPSTAX Register

UPSTAX (1.CEh) – USB Pipe Status Register

7	6	5	4	3	2	1	0				
CFGOK	OVERFI	UNDERFI	-	DTSEQ1	DTSEQ0	NBUSYBK1	NBUSYBK0				
Bit Number	Bit Mnemonic	Description									
7	CFGOK	Configure P Set by hard performed. Cleared by I pipe have no	ipe Memory ware if the re nardware whe o effect on the	OK equired memo en the pipe is configuration	ory configurat disabled. The of the pipe.	ion has been e USB reset a	successfully and the reset				
6	OVERFI	Overflow Set by hard maximum ler set. Shall be clea	verflow et by hardware when a the current Pipe has received more data than the laximum length of the current Pipe. An interrupt is triggered if the FLERRE bit is et. hall be cleared by software. Setting by software has no effect.								
5	UNDERFI	Underflow Set by hardw or interrupt F will be sent ii Shall be clea Note: the Ho will be sent a underflow for	Jnderflow Set by hardware when a transaction underflow occurs in the current isochronous or interrupt Pipe. The Pipe can't send the data flow required by the device. A ZLP vill be sent instead. An interrupt is triggered if the FLERRE bit is set. Shall be cleared by software. Setting by software has no effect. Note: the Host controller has to send a OUT packet, but the bank is empty. A ZLP vill be sent and the UNDERFI bit is set underflow for interrupt Pipe:								
4	-	Reserved The value re	ad from this b	it is always 0.	Do not set thi	is bit.					
3-2	DTSEQ1:0	Toggle Sequ Set by hardw 00bData0 01bData1 1xbReserved For OUT Pip not relative to For IN Pipe, bank.	Toggle Sequencing Flag Set by hardware to indicate the PID data of the current bank: 00bData0 01bData1 1xbReserved. For OUT Pipe, this value indicates the next data toggle that will be sent. This not relative to the current bank. For IN Pipe, this value indicates the last data toggle received on the current bank.								
1-0	NBUSYBK1: 0	Busy Bank Set by hardw For OUT Pip for OUT tran For IN Pipe, the Device. 00bAll banks 01b1 busy b 10b2 busy b 11bReserved	bank. 3usy Bank Flag Set by hardware to indicate the number of busy bank. For OUT Pipe, it indicates the number of busy bank(s), filled by the user, ready or OUT transfer. For IN Pipe, it indicates the number of busy bank(s) filled by IN transaction from he Device. 00bAll banks are free 01b1 busy bank 10b2 busy banks 11bReserved.								





Table 146. UPINRQX Register

UPINRQX (1.DFh) – USB Pipe IN Number Of Request Register

7	6	5	4	3	2	1	0
INRQ7	INRQ6	INRQ5	INRQ4	INRQ3	INRQ2	INRQ1	INRQ0
Bit Number	Bit Mnemonic	Description					
7-0	INRQ7:0	IN Request I Enter the nur The USB cor This counter successfully	Number Befo mber of IN tra ntroller will per is automatica performed.	re Freeze Insactions befor rform (INRQ+ ally decreased	ore the USB o 1) IN requests by 1 each tir	controller free before to free me a IN reque	zes the pipe. eze the Pipe. est has been

Reset Value = 0000 0000b

Table 147. UPERRX Register

UPERRX (1.D7h) – USB Pipe Error Register

7	6	5	4	3	2	1	0
-	COUNTER1	COUNTER0	CRC16	TIMEOUT	PID	DATAPID	DATATGL
Bit Number	Bit Mnemonic	Description					
7-6	-	Reserved The value read from these bits is always 0. Do not set these bits.					
5	COUNTER1: 0	Error counter This counter is increased by the USB controller each time an error occurs on the Pipe. When this value reaches 3, the Pipe is automatically frozen. Clear these bits by software.					
4	CRC16	CRC16 Error Set by hardware when a CRC16 error has been detected. Shall be cleared by software. Setting by software has no effect.					
3	TIMEOUT	Time-out Error Set by hardware when a time-out error has been detected. Shall be cleared by software. Setting by software has no effect.					
2	PID	PID Error Set by hardware when a PID error has been detected. Shall be cleared by software. Setting by software has no effect.					
1	DATAPID	Data PID Error Set by hardware when a data PID error has been detected. Shall be cleared by software. Setting by software has no effect.					
0	DATATGL	Bad Data Toggle Set by hardware when a data toggle error has been detected. Shall be cleared by software. Setting by software has no effect.					
Table 148. UPINTX Register

UPINTX (1.C8h) – USB Pipe Interrupt Register

7	6	5	4	3	2	1	0	
FIFOCON	NAKEDI	RWAL	PERRI	TXSTPI	TXOUTI	RXSTALLI	RXINI	
Bit Number	Bit Mnemonic	Description						
7	FIFOCON	FIFO Contro For OUT and Set by hardw TXSTP. Clear to send effect. For IN Pipe: Set by hardw same time th Clear to free software has	FIFO Control For OUT and SETUP Pipe: Set by hardware when the current bank is free, at the same time than TXOUT o TXSTP. Clear to send the FIFO data and to switch the bank. Setting by software has no effect. For IN Pipe: Set by hardware when a new IN message is stored in the current bank, at the same time than RXIN. Clear to free the current bank and to switch to the following bank. Setting by software has no effect.					
6	NAKEDI	NAK Hands Set by hardw This triggers Shall be clea	VAK Handshake received Set by hardware when a NAK has been received on the current bank of the Pipe. This triggers an interrupt if the NAKEDE bit is set in the UPIENX register. Shall be clear to handshake the interrupt. Setting by software has no effect.					
5	RWAL	Read/Write Allowed OUT Pipe: Set by hardware when the firmware can write a new data into the Pipe FIFO. Cleared by hardware when the current Pipe FIFO is full. IN Pipe: Set by hardware when the firmware can read a new data into the Pipe FIFO. Cleared by hardware when the current Pipe FIFO is empty. This bit is also cleared by hardware when the RXSTALL or the PERR bit is set						
4	PERRI	PIPE Error Set by hardware when an error occurs on the current bank of the Pipe. Th triggers an interrupt if the PERRE bit is set in the UPIENX register. Refers to t UPERRX register to determine the source of the error. Automatically cleared by hardware when the error source bit is cleared.						
3	TXSTPI	SETUP Bank ready Set by hardware when the current SETUP bank is free and can be filled. T triggers an interrupt if the TXSTPE bit is set in the UPIENX register. Shall be cleared to handshake the interrupt. Setting by software has no effect						
2	TXOUTI	OUT Bank ready Set by hardware when the current OUT bank is free and can be filled. Th triggers an interrupt if the TXOUTE bit is set in the UPIENX register. Shall be cleared to handshake the interrupt. Setting by software has no effect.						
1	RXSTALLI / CRCERR	STALL Received / Isochronous CRC Error Set by hardware when a STALL handshake has been received on the curr bank of the Pipe. The Pipe is automatically frozen. This triggers an interrupt if RXSTALLE bit is set in the UPIENX register. Shall be cleared to handshake the interrupt. Setting by software has no effect For Isochronous Pipe: Set by hardware when a CRC error occurs on the current bank of the Pipe. [¬] triggers an interrupt if the TXSTPE bit is set in the UPIENX register. Shall be cleared to handshake the interrupt. Setting by software has no effect						





Bit Number	Bit Mnemonic	Description
0	RXINI	IN Data received Set by hardware when a new USB message is stored in the current bank of the Pipe. This triggers an interrupt if the RXINE bit is set in the UPIENX register. Shall be cleared to handshake the interrupt. Setting by software has no effect.

Reset Value = 0000 0000b

Table 149. UPIENX Register

UPIENX (1.D2h) – USB Pipe Interrupt Enable Register

7	6	5	4	3	2	1	0	
FLERRE	NAKEDE	-	PERRE	TXSTPE	TXOUTE	RXSTALLE	RXINE	
Bit Number	Bit Mnemonic	Description						
7	FLERRE	Flow Error I Set to enable Clear to disa	Tow Error Interrupt enable Set to enable the OVERFI and UNDERFI interrupts. Clear to disable the OVERFI and UNDERFI interrupts.					
6	NAKEDE	NAK Hands Set to enable Clear to disa	IAK Handshake Received Interrupt Enable Set to enable the NAKEDI interrupt. Clear to disable the NAKEDI interrupt.					
5	-	Reserved The value re	Reserved The value read from this bit is always 0. Do not set this bit.					
4	PERRE	PIPE Error I Set to enable Clear to disa	PIPE Error Interrupt Enable Set to enable the PERRI interrupt. Clear to disable the PERRI interrupt.					
3	TXSTPE	SETUP Ban Set to enable Clear to disa	SETUP Bank ready Interrupt Enable Set to enable the TXSTPI interrupt. Clear to disable the TXSTPI interrupt.					
2	TXOUTE	OUT Bank re Set to enable Clear to disa	OUT Bank ready Interrupt Enable Set to enable the TXOUTI interrupt. Clear to disable the TXOUTI interrupt.					
1	RXSTALLE	STALL Received Interrupt Enable Set to enable the RXSTALLI interrupt. Clear to disable the RXSTALLI interrupt.						
0	RXINE	IN Data rece Set to enable Clear to disa	IN Data received Interrupt Enable Set to enable the RXINI interrupt. Clear to disable the RXINI interrupt.					

Reset Value = 0000 0000b

Table 150. UPDATX Register

UPDATX (1.D3h) – USB Pipe Data Register

7	6	5	4	3	2	1	0
PDAT7	PDAT6	PDAT5	PDAT4	PDAT3	PDAT2	PDAT1	PDAT0

Bit Number	Bit Mnemonic	Description
7-0	PDAT7:0	Pipe Data Bits Set by the software to read/write a byte from/to the Pipe FIFO selected by PNUM.

Reset Value = 0000 0000b

Table 151. UPBCHX Register

UPBCHX (1.D4h) – USB Pipe Data Counter High Register

7	6	5	4	3	2	1	0	
-	-	-	-	-	PBYCT10	PBYCT9	PBYCT8	
Bit Number	Bit Mnemonic	Description						
7-3	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.					
2-0	PBYCT10:8	Byte count (high) Bits Set by hardware. This field is the MSB of the byte count of the FIFO endpoint. The LSB part is provided by the UPBCLX register.						

Reset Value = 0000 0000b

Table 152. UPBCLX Register

UPBCLX (1.D5h) – USB Pipe Data Counter Low Register

7	6	5	4	3	2	1	0
PBYCT7	PBYCT6	PBYCT5	PBYCT4	PBYCT3	PBYCT2	PBYCT1	PBYCT0
Bit Number	Bit Mnemonic	Description					
7-0	PBYCT7:0	Byte Count (low) Bits Set by the hardware. PBYCT10:0 is: - (for OUT Pipe) increased after each writing into the Pipe and decremented aft each byte sent, - (for IN Pipe) increased after each byte received by the host, and decrement after each byte read by the software.					

Reset Value = 0000 0000b





Table 153. UPINT Register

UPINT (1.D6h) – USB Pipe IN Number Of Request Register

7	6	5	4	3	2	1	0	
-	PINT6	PINT5	PINT4	PINT3	PINT2	PINT1	PINT0	
Bit Number	Bit Mnemonic	Description						
7	-	Reserved The value rea	Reserved The value read from this bit is always 0. Do not set this bit.					
6-0	PINT6:0	Pipe Interrupts Bits Set by hardware when an interrupt is triggered by the UPINTX register and if the corresponding endpoint interrupt enable bit is set. Cleared by hardware when the interrupt source is served.						

Reset Value = 0000 0000b

Audio Controller

The Audio Controller implemented in AT85C51SND3B derivatives is based on four functional blocks detailed in the following sections:

- The Clock Generator
- The Audio Processor
- The Audio Codec
- The Audio DAC Interface

Figure 69. Audio Controller Block Diagram



Clock GeneratorThe clock generator generates the audio controller clocks based on the audio clock
issued by the clock controller as detailed in Section "System Clock Generator", page 30.
As shown in Figure 70, it contains an Audio Frequencies Generator able to generate the

issued by the clock controller as detailed in Section "System Clock Generator", page 30. As shown in Figure 70, it contains an Audio Frequencies Generator able to generate the audio sampling and over-sampling frequencies fed by a normalized clock. This generator is based on a PLL and is entirely controlled by the audio processor depending on the encoded or decoded audio stream characteristics.

Figure 70. Audio Controller Clock Generator



Audio Processor

The audio processor is based on three functional blocks as shown in Figure 71.

- The Audio Buffer
- The Digital Audio Processor
- The Baseband Processor





Figure 71. Audio Processor Block Diagram



Audio Buffer

The audio buffer receives the audio data flow coming from DFC or the C51. It is based on 1 Kbyte of dual-port RAM.

Buffer Description

The audio buffer can be accessed in read or write mode by both C51 and DFC. Access selection is done by the ABACC bit in APCON1. Considering the DFC, two channels can be established at the same time one in which the audio processor is the source and one in which the audio processor is the destination. To achieve such scheme, the audio buffer can be configured using ABSPLIT in APCON1 as one (see Figure 72a) or two (see Figure 72b) buffers, each containing two data packets of 512 or 256 bytes size.

Figure 72. Audio Buffer Configuration



Internal read or write pointers can be reset at any time by setting respectively ABRPR and ABWPR bits in APCON1. These bits are automatically reset by hardware.

Buffer Management

The C51 reads from or writes to the buffer through the APDAT register. Management is controlled by a couple of flags informing the user that data can be written to the buffer or read from the buffer depending on the current operation.

In case of write (audio stream decoding or codec firmware update) APREQI flag in APINT is set every time a data packet (256 or 512 bytes) can be written to the buffer i.e. buffer empty or half full. APREQI is cleared when the buffer becomes full.

In case of read (audio stream encoding) APRDYI flag in APINT is set every time a data packet (256 or 512 bytes) can be retrieved from the buffer i.e. buffer full or half full. APRDYI is cleared when the buffer becomes empty.

These flags can generate an interrupt when APREQE bit and APRDYE bit in APIEN are respectively set (see Section "Interrupts").

	In order to avoid any spurious interrupts on the CPU side when a data transfer with the data flow controller is established, APREQE and APRDYE must be left cleared.
Digital Audio Processor	The digital audio processor is based on a proprietary digital signal processor. It provides capability to decode many digital audio formats like MP3, WMA, G726, RAW PCM and to encode some digital audio formats like G726, RAW PCM
Processor Initialization	Prior to enable the digital audio processor by setting the DAPEN bit in APCON1 ⁽¹⁾ , the C51 must load the processor codec firmware which is the stream decoder or encoder. This can be achieved by setting APLOAD ⁽²⁾ bit in APCON1 and loading data using the C51 (through APDAT) or the DFC as detailed in the Section "Audio Buffer". As soon as the codec firmware is fully loaded, the digital audio processor can be enabled with the effect to start the codec execution. Then the audio stream type that can be decoded or encoded depends on the codec firmware loaded. Note: 1. Clearing DAPEN bit resets the code writing pointer address to 0000h. 2. Toggling APLOAD bit leaves the code writing pointer address unchanged.
Processor Interface	The C51 interfacing the processor through 3 registers: APCON0 by using APCMD6:0 bits, APSTA and APINT by using APEVTI bit. APCMD field is used to send commands to the processor while APSTA and APEVTI are used by the processor to trigger an event or give a status to the C51. Command and status relies on the processor codec firmware and are beyond the scope of this document.
Play Time	In order to allow time stamping in case of synchronized lyrics (karaoke mode), a 24-bit time stamp is provided by APTIM2:0 registers with APTIM2 being the MSB and APTIM0 being the LSB. Time unit is millisecond.
	Getting the time value is done by reading first APTIM0, then APTIM1 and APTIM2. The counter value is latched during read sequence, avoiding bad reading if increment occurs. Initializing the time value is done by writing first APTIM0, then APTIM1 and APTIM2.
	Time value is automatically updated by the audio processor in case of fast for- ward/rewind operating mode. Time value is reset when operating mode switches from Stop to Play mode and frozen when in Pause mode.
Audio Stream Interface	Every codec firmwares (decoder or encoder) share a set of registers allowing to perform configuration and control and to get status from the decoding or encoding process. This set of registers is composed of ASCON, the audio stream control register and ASSTA0 ASSTA1 and ASSTA2, the audio stream status registers. The content of these registers depends on the codec firmware loaded and are beyond the scope of this document.
Baseband Processor	 Several digital baseband treatments can be applied to the digital audio signal immediately before internal or external D/A conversion: Digital volume control 3-bands equalizer Bass boost effect Virtual surround effect Miving mode

The baseband processor is enabled by setting BPEN bit in AUCON. When disabled (BPEN bit cleared) all of the above treatments are disabled.





Digital Volume Control

The digital volume is controlled separately on right and left channel by setting the DVR4:0 and DVL4:0 bits respectively in APRDVOL and APLDVOL according to Table 154.

DVx4:0	Gain Value	DVx4:0	Gain Value	DVx4:0	Gain Value
00000	+6 dB	01011	-16dB	10110	-38 dB
00001	+4 dB	01100	-18 dB	10111	-40 dB
00010	+2 dB	01101	-20 dB	11000	-42 dB
00011	+0 dB	01110	-22 dB	11001	-44 dB
00100	-2 dB	01111	-24 dB	11010	-46 dB
00101	-4 dB	10000	-26 dB	11011	-48 dB
00110	-6 dB	10001	-28 dB	11100	-50 dB
00111	-8 dB	10010	-30 dB	11101	-52 dB
01000	-10 dB	10011	-32 dB	11110	-54 dB
01001	-12 dB	10100	-34 dB	11111	Mute ⁽¹⁾
01010	-14 dB	10101	-36 dB		•

Table 154. Digital Volume Control Gain

Note: 1. When DVR4:0 and DVL4:0 are set to mute, audio processor is still sending data to the audio codec or the audio interface with data set to the corresponding 0 value.

Equalizer Volume Control

A 3-band equalizer control is provided for tone adjustment or predefined tone shapes like classic, jazz, rock...

The equalizer gain is controlled in each band by programing DVB4:0 in APBDVOL for the bass band, DVM4:0 in APMDVOL for the medium band and DVT4:0 in APTDVOL for the treble band according to Table 154. Cut frequencies are defined in Table 155. In order to optimize the power consumption, the 3-band equalizer can be disabled by setting EQUDIS in AUCON. In this case the band gain control is saved but no filtering is applied.

Table 155. Equalizer Band Frequency

Band	Frequencies
Bass	F < 750 Hz
Medium	750 Hz < F < 3300 Hz
Treble	F > 3300 Hz

Bass Boost EffectA bass boost effect can be established by setting BBOOST bit in AUCON. It consists in
a gain increase of +6 dB in the frequency range under 200 Hz.

Virtual surround Effect

A virtual surround effect can be established by setting VSURND bit in AUCON. It consists in applying a spatial effect to sound on both right and left channels.

Equalizer Bar-GraphAn 8-band bar-graph equalizer allows dynamic audio volume report inside 8 frequency
bands. To read the level of each band, first select the band by setting the EQBS2:0 bits
in APEBS from 000b (lowest frequency band) to 111b (highest frequency band) then get
the 5-bit band level by reading EQLEV4:0 bits in APELEV.

Mixing Mode

Signal Clipping

A mixing mode can be established by setting MIXEN bit in AUCON. It consists in mixing the ADC output coming from microphone or line-in inputs with the output coming from the audio processor before feeding the internal or external audio DAC.

When volume controls (global + equalizer + bass boost) leads to signal saturation, output signal is clipped and ACLIPI flag is set in APINT. In such case, strategy to reduce volume is under user's firmware responsibility. ACLIPI flag can generate an interrupt by setting ACLIPE bit in APIEN.

Interrupts

As shown in Figure 73, the audio processor interrupt request is generated by 8 different sources: the APREQI, APRDYI, ACLIPI and APGPI4:0 flags in APINT. Both sources can be enabled separately by using the APREQE, APRDYE, ACLIPE and APGPE4:0 bits in APIEN. A global enable of the audio processor interrupt is provided by setting the EAUP bit in IEN0 register.

The interrupt is requested each time one of the sources is asserted.



Figure 73. Audio Processor Interrupt System





Audio Codec

Audio Outputs

AT85C51SND3B1 &

AT85C51SND3B2

Anti-Pop Circuitry

Output Sources

The audio codec is controlled by four registers as detailed in Figure 74:

Figure 74. Audio Codec Block Diagram



The audio output system of AT85C51SND3B1 & AT85C51SND3B2 is based on a pair of sigma-delta D/A converter used to convert the audio data with high linearity and high S/N. It is enabled by setting the AOEN bit in ACCON (see Table 178). Audio input system features are detailed in the following sections.

In order to avoid any noise when enabling the audio output system an anti-pop circuitry has been implemented on the audio outputs (OUTR and OUTL). It consists in a discharge circuit controlled by AODIS bit in ACAUX (see Table 179) and a preload circuit controlled by AOPRE bit in ACAUX. Prior to enable the audio output system, user must take care to discharge then charge the audio outputs.

The audio output source can come from either the audio processor or the stereo lines Inputs sources. The selection of the source is done by setting or clearing the AOSSEL bit in ACCON according to Table 156.

AOSSEL	Selection
0	Line Input (stereo)
1	Audio Processor (mono or stereo) ⁽¹⁾

Note: 1. Stereo or mono choice is done by the audio processor depending on the audio flow under decoding.

Output Gain Control

Analog volume is controlled separately on both channel by setting the AORG4:0 bits in ACORG for the right channel and the AOLG4:0 bits in ACOLG for the left channel. Table 157 shows the gain value versus the programmed AORG or AOLG value.

AORG4:0 AOLG4:0	Gain Value	AORG4:0 AOLG4:0	Gain Value	AORG4:0 AOLG4:0	Gain Value
00000	6 dB	00111	-8 dB	01110	-22 dB
00001	4 dB	01000	-10 dB	01111	-24 dB
00010	2 dB	01001	-12 dB	10000	-26 dB
00011	0 dB	01010	-14 dB	10001	-28 dB
00100	-2 dB	01011	-16 dB	10010	-30 dB
00101	-4 dB	01100	-18 dB	≥ 10011	Mute
00110	-6 dB	01101	-20 dB		•

Table 157. Audio Codec Output Gain

Output Drive Control

Output buffers can operate in two modes depending on the power supply voltage. These are low impedance or high impedance modes. The low impedance mode is only available in high power supply configuration and allows to drive a typical 32 Ω stereo headphone, while the high impedance mode is available in low or high voltage power supply configurations and allows to drive a typical 50 K Ω stereo amplifier. Control is done by setting or clearing AODRV bit in ACCON according to Table 158.

Table 158. Audio Codec Output Drive Selection

AODRV	Drive Selection
0	Low/high voltage 50 K Ω drive
1	High voltage 32 Ω drive

Audio Inputs

The audio input system is based on a single sigma-delta A/D converter provided for mono recording. It is enabled by setting the AIEN bit in ACCON. Audio input system features are detailed in the following sections.

Inputs Sources

The audio input source can come from either an electret type microphone input or the stereo lines inputs sources. The selection of the source is done by setting or clearing the AISSEL bit in ACCON according to Table 159. When line inputs are selected as audio input source, stereo channels are combined together in a mono signal prior to feed the preamplifier.

Table 159. Audio Codec Input Source Selection

AISSEL	Selection
0	Line Inputs
1	Microphone Input

Audio Input Preamplifier Gain

The signals coming from audio inputs goes through a preamplifier to adapt levels prior to feed the A/D converter. The preamplifier gain is controlled by AIPG2:0 bits in ACIPG according to Table 160.

Table Tou. Audio Codec input Preampliller Gain
--

AIPG2:0	Gain Value	AIPG2:0	Gain Value	AIPG2:0	Gain Value
000	0 dB	010	+12 dB	100	+24 dB





AIPG2:0	Gain Value	AIPG2:0	Gain Value	AIPG2:0	Gain Value
001	+6 dB	011	+18 dB	≥ 101	Reserved

Line Inputs Preamplifier Gain In AT85C51SND3B1 & AT85C51SND3B2, when Line Inputs are selected as output source (e.g. FM decoder playback) two preamplifier gain values can be applied by setting or clearing AILPG bit in ACIPG according to Table 161.

 Table 161.
 Audio Codec Line Inputs Preamplifier Gain

AILPG	Gain Value
0	+6 dB
1	+12 dB

Microphone Bias

In addition, voltage supply function for an electret type microphone is integrated delivering High bias (1.5V) or low bias (2v) voltage. The high bias voltage output is only available in high power supply configuration, while the low bias voltage output is available in low or high voltage power supply configurations. Bias voltage output is selected by AMBSEL bit in ACCON according to Table 163 and is enabled by AMBEN bit in ACCON according to Table 162.

Table 162. Audio Codec Microphone Bias Control

AMBEN	Control
0	Microphone bias output disabled
1	Microphone bias output enabled

Table 163. Audio Codec Microphone Bias Voltage Selection

AMBSEL	Voltage Selection
0	high bias voltage 2V output
1	Low bias voltage 1.5 V output

Audio DAC Interface

The C51 core interfaces to the audio DAC interface through two special function registers: ADICON0 and ADICON1, the Audio DAC Interface Control registers (see Table 183 and Table 184).

Figure 75 shows the audio interface block diagram where blocks are detailed in the following sections.





Clock Controller

As soon as audio DAC interface is enabled by setting ADIEN bit in ADICON0, the master clock generated by the clock generator (see Section "Clock Generator") is output on the OCLK pin which is the DAC over-sampling clock. The over-sampling ratio is defined by OVERS1:0 bits in ADICON0 according to Table 164 and is selected depending on the DAC capabilities.

Table 164. Audio DAC Interface Over-sampling Ratio

OVERS1:0	Over-sampling Ratio
00	Reserved
01	128 · F _S
10	256 · F _S
11	384 · F _S

For DAC compatibility, the bit clock frequency is programmable for outputting 16 bits or 32 bits per channel using the DSIZE bit in ADICON0 (see Section "Data Converter", page 157), and the word selection signal (DSEL) is programmable for outputting left channel on low or high level according to CSPOL bit in ADICON0 as shown in Figure 76.

Figure 76. DSEL Output Polarity



Data Converter

The data converter block converts the audio stream coming from the audio processor to a serial format. For accepting all PCM formats and I²S format, JUST4:0 bits in ADICON1 register are used to shift the data output point. As shown in Figure 77, these bits allow MSB justification by setting JUST4:0 = 00000, LSB justification by setting JUST4:0 = 10000, I²S Justification by setting JUST4:0 = 00001, and more than 16-bit LSB justification by filling the low significant bits with logic 0.





Figure 77. Audio Output Format

-	-
DSEL DCI K	$ \begin{array}{c c c c c c c c c c c c c c c c c c c $
DDAT	
	I2S Format with DSIZE = 0 and JUST4:0 = 00001.
DSEL	Left Channel Right Channel
DCLK	
DDAT	<u>(MSB(B14)(]] (LSB)</u> (<u>MSB(B14)(]] (LSB)</u>
	I2S Format with DSIZE = 1 and JUST4:0 = 00001.
DSEL	Left Channel Right Channel
DCLK	
DDAT	<u></u>
	MSB/LSB Justified Format with DSIZE = 0 and JUST4:0 = 00000.
DSEL	Left Channel Right Channel
DCLK	
DDAT	
	16-bit LSB Justified Format with DSIZE = 1 and JUST4:0 = 10000.
DSEL	Left Channel Right Channel
DCLK	
DDAT	<u>(MSB(B16)(B2)</u> B1_LSB <u>(MSB(B16)(B2)</u> B1_LSB
	18-bit LSB Justified Format with DSIZE = 1 and JUST4:0 = 01110.

Registers

Table 165. AUCON Register

7	6	5	4	3	2	1	0
BPEN	VSURND	BBOOST	MIXEN	EQUDIS	-	-	ACCKEN
Bit Number	Bit Mnemonic	Description					
7	BPEN	Baseband P Set to enable Clear to bypa	rocessor Ena the baseban ass the baseb	able Bit d processing. and processin	g and disable	the baseband	d features.
6	VSURND	Virtual Surro Set to enable Clear to disa	ound Enable the virtual suble the virtual	Bit arround effect. surround effe	ct.		
5	BBOOST	Bass Boost Set to enable Clear to disa	Enable Bit the bass boo ble the bass b	ost effect. boost effect.			
4	MIXEN	Mixing Enable Set to enable Clear to disa	Ie Bit mixing of AD ble mixing of A	C output with ADC output w	DAC output. ith DAC outpu	ıt.	
3	EQUDIS	Equalizer Di Set to disable Clear to enal	sable Bit e the 3-band e ble the 3-band	equalizer. I equalizer.			

Bit Number	Bit Mnemonic	Description
2-1	-	Reserved The value read from these bits is always 0. Do not set these bits.
0	ACCKEN	Audio Controller Clock Enable Bit Set to enable the Audio Controller Clock. Clear to disable the Audio Controller Clock.

Reset Value = 0000 0000b

Table 166. APCON0 Register

APCON0 (1.F2h) – Audio Processor Control Register 0

7	6	5	4	3	2	1	0
0	APCMD6	APCMD5	APCMD4	APCMD3	APCMD2	APCMD1	APCMD0
Bit Number	Bit Mnemonic	Description					
7	0	Always 0 The value rea	ad from this bi	it is always 0.	Can not be se	et by software.	
6-0	APCMD6:0	Audio Proce Codec firmwa	essor Operati are dependan	i ng Comman t.	d Bits		

Reset Value = 0000 0000b

Table 167. APCON1 Register

APCON1 (1.F3h) – Audio Processor Control Register 1

7	6	5	4	3	2	1	0
-	-	ABACC	ABWPR	ABRPR	ABSPLIT	APLOAD	DAPEN
Bit Number	Bit Mnemonic	Description					
7-5	-	Reserved The value rea	ad from these	bits is always	0. Do not set	these bits.	
5	ABACC	Audio Buffe Set to enable Clear to enab	r Access Bit e buffer acces ble buffer acce	s by C51 core ess by DFC.			
4	ABWPR	Audio Buffe Set to reset t Cleared by h Can not be c	r Write Point he audio buffe ardware wher leared by soft	er Reset Bit er write pointe n write pointer ware.	r. is reset.		
3	ABRPR	Audio Buffe Set to reset t Cleared by h Can not be c	r Read Point he audio buff ardware wher leared by soft	er Reset Bit er read pointer n read pointer ware.	r. is reset.		
2	ABSPLIT	Audio Buffe Set to config Clear to conf	r Split Bit ure the audio igure the audi	buffer as a do io buffer as a s	uble buffer. single buffer.		





Bit Number	Bit Mnemonic	Description
1	APLOAD	Audio Processor Load Enable Bit Set to enable audio processor codec code update. Clear to disable audio processor codec code update.
0	DAPEN	Digital Audio Processor Enable Bit Set to enable the digital audio processor. Clear to disable the digital audio processor.

Reset Value = 0000 0000b

Table 168. APSTA Register

APSTA (1.EAh) – Audio Processor Status Register

7	6	5	4	3	2	1	0
APSTAT7	APSTAT6	APSTAT5	APSTAT4	APSTAT3	APSTAT2	APSTAT1	APSTAT0
Bit Number	Bit Mnemonic	Description					
7-0	APSTAT7:0	Audio Proce	essor Status I are dependan	Byte t.			

Reset Value = 0000 0000b

Table 169. APINT Register

APINT ((1.F4h) -	- Audio	Processor	Interrupt	Register

7	6	5	4	3	2	1	0
APGPI3	APGPI2	APGPI1	APGP10	APEVTI	ACLIPI	APRDYI	APREQI
Bit Number	Bit Mnemonic	Description					
7-4	APGPI3:0	Audio Proce Set by hardw Cleared by h	essor Genera vare to trigger ardware after	I Purpose Int a general pur writing APCO	errupt Flag pose interrupt N0.		
3	APEVTI	Audio Proce Set by hardw Cleared by h	essor Event I vare to signal ardware after	nterrupt Flag an event from writing APCO	the audio pro N0.	cessor.	
2	ACLIPI	Audio Clipp Set by hard saturation. Cleared by h	ing Interrupt ware when a ardware after	Flag audio gain (d writing APCO	igital volume N0.	or bass boo	ost) leads to
1	APRDYI	Audio Packa Set by hardw (512 or 256 b Cleared by h	et Ready Inte vare when auc bytes dependi ardware wher	rrupt Flag lio buffer has a ng on buffer c n audio buffer	at least one da onfiguration). is empty.	ata packet rea	dy to be read
0	APREQI	Audio Packo Set by hardw 256 bytes de Cleared by h	et Request In vare when au pending on b ardware when	terrupt Flag Idio buffer is a uffer configura n audio buffer	able to receiv tion). is full.	e one data pa	acket (512 or

Reset Value = 0000 0000b

Table 170. APIEN Register

APIEN (1.E9h) – Audio Processor Interrupt Enable Register

7	6	5	4	3	2	1	0
APGPE3	APGPE2	APGPE1	APGPE0	APEVTE	ACLIPE	APRDYE	APREQE
Bit Number	Bit Mnemonic	Description					
7-4	APGPE3:0	Audio Proce Set to enable Clear to disa	essor Genera the audio pro ble the audio	I Purpose Int ocessor gener processor ger	errupt Enable al purpose int neral purpose	e Bits errupt. interrupt.	
3	APEVTE	Audio Proce Set to enable Clear to disa	essor Event I the audio proble the audio	nterrupt Enat ocessor event processor eve	ole Bit interrupt. ent interrupt.		
2	ACLIPE	Audio Clipp Set to enable Clear to disa	i ng Interrupt the audio cli ble the audio	Enable Bit pping interrupt clipping interru	t. upt.		
1	APRDYE	Audio Packo Set to enable Clear to disa	et Ready Inte the audio pa ble the audio	rrupt Enable cket ready inte packet ready i	Bit errupt. nterrupt.		
0	APREQE	Audio Packe Set to enable Clear to disa	et Request In the audio pa ble the audio	terrupt Enabl cket request in packet reques	le Bit nterrupt. t interrupt.		

Reset Value = 0000 0000b

Table 171. APTIM0 Register

APTIM0 (2.C6h) – Audio Processor Timer Register 0

7	6	5	4	3	2	1	0
APT7	APT6	APT5	APT4	APT3	APT2	APT1	APT0
Bit Number	Bit Mnemonic	Description					
7-0	APT7:0	Audio Proce	essor Timer L	east Signific	ant Byte.		

Reset Value = 0000 0000b

Table 172. APTIM1 Register

APTIM1 (2.C7h) – Audio Processor Timer Register 1

7	6	5	4	3	2	1	0
APT15	APT14	APT13	APT12	APT11	APT10	APT9	APT8
Bit Number	Bit Mnemonic	Description					

Reset Value = 0000 0000b





Table 173. APTIM2 Register

APTIM2 (2.C9h) - Audio Processor Timer Register 2

7	6	5	4	3	2	1	0
APT23	APT22	APT21	APT20	APT19	APT18	APT17	APT16
		1					
Bit Number	Bit Mnemonic	Description					

Reset Value = 0000 0000b

Table 174. APRDVOL, APLDVOL Registers

APRDVOL, APLDVOL (2.F1h, 2.F2h) – Audio Processor Right, Left Digital Volume Registers

7	6	5	4	3	2	1	0		
-	-	-	ADVOL4	ADVOL3	ADVOL2	ADVOL1	ADVOL0		
Bit Number	Bit Mnemonic	Description							
7-5	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.						
4-0	ADVOL4:0	Digital Volur Refer to Tabl	ne le 154 for info	rmation on ga	in control valu	es.			

Reset Value = 0000 0011b

Table 175. APBDVOL, APMDVOL, APTDVOL Registers

APBDVOL, APMDVOL, APTDVOL (2.F3h, 2.F4h, 2.F5h) – Audio Processor Bass, Medium, Treble Digital Volume Registers

7	6	5	4	3	2	1	0		
-	-	-	ADVOL4	ADVOL3	ADVOL2	ADVOL1	ADVOL0		
Bit Number	Bit Mnemonic	Description							
7-5	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.						
4-0	ADVOL4:0	Digital Volur Refer to Tabl	ne le 154 for info	rmation on ga	in control valu	es.			

Reset Value = 0001 1111b

Table 176. APEBS Register

APEBS (2.F6h) - Audio Processor Equalizer Band Select Register

7	6	5	4	3	2	1	0
-	-	-	-	0	EQBS2	EQBS1	EQBS0

Bit Number	Bit Mnemonic	Description
7-4	-	Reserved The value read from these bits is always 0. Do not set these bits.
3	0	Always Cleared This bit is permanently cleared by hardware to allow INC APEBS without affecting bits 7-4.
2-0	EQBS2:0	Equalizer Band Selection 000b: lowest frequency band to 111b highest frequency band.





Table 177. APELEV Register

APELEV (2.F7h) - Audio Processor Equalizer Level Status Register

7	6	5	4	3	2	1	0		
-	-	-	EQLEV4	EQLEV3	EQLEV2	EQLEV1	EQLEV0		
Bit Number	Bit Mnemonic	Description							
7-5	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.						
4-0	EQLEV4:0	Equalizer Au 00000b: min	u dio Level . level to 11111	b: max. level					

Reset Value = 0000 0000b

Table 178. ACCON Register

ACCON (2.EAh) - Audio Codec Control Register

7	6	5	4	3	2	1	0		
-	AMBSEL	AMBEN	AISSEL	AIEN	AODRV -	AOSSEL -	AOEN -		
Bit Number	Bit Mnemonic	Description							
7	-	Reserved The value re	Reserved The value read from this bit is always 0. Do not set this bit.						
5	AMBSEL	Microphone Set to select Clear to sele	Aicrophone Bias Select Bit Set to select 1.5V bias output voltage in high or low voltage configuration. Clear to select 2V bias output voltage in high voltage configuration.						
5	AMBEN	Microphone Set to enable Clear to disa	Vicrophone Bias Enable Bit Set to enable the microphone bias output. Clear to disable the microphone bias output.						
4	AISSEL	Audio Input Set to select Clear to sele	Audio Input Source Select Bit Set to select the microphone as input source. Clear to select the line inputs as input source.						
3	AIEN	Audio Input Set to enable Clear to disa	Enable Bit the audio inp ble the audio	out system. input system.					
2	AODRV -	AT85C51SND3B1 and AT85C51SND3B2: Audio Output Drive Select Bit Set to select the 32 Ω drive in high voltage configuration. Clear to select the 50 K Ω drive in high or low voltage configuration. AT85C51SND3B0: Reserved The value read from this bit is always 0. Do not set this bit.							
1	AOSSEL	AT85C51SN Set to select Clear to sele AT85C51SN The value re	D3B1 and AT the audio pro ct the line inp D3B0: Reser ad from this b	85C51SND3E cessor as out uts as output s ved it is always 0.	32: Audio Ou out source. source. Do not set thi	tput Source S	Select Bit		

Bit Number	Bit Mnemonic	Description
0	AOEN -	AT85C51SND3B1 and AT85C51SND3B2: Audio Output Enable Bit Set to enable the audio output system. Clear to disable the audio output system. AT85C51SND3B0: Reserved The value read from this bit is always 0. Do not set this bit.

Reset Value = 0000 0000b

Table 179. ACAUX Register (AT85C51SND3B1 and AT85C51SND3B2 only)

ACAUX (2.E4h) - Audio Codec Auxiliary Register

7	6	5	4	3	2	1	0	
-	-	-	-	-	-	AODIS	AOPRE	
Bit Number	Bit Mnemonic	Description						
7-2	-	Reserved The value re	Reserved The value read from these bits is always 0. Do not set these bits.					
1	AODIS	Audio Outpo Set to enable Clear to disa	Audio Output Discharge Bit Set to enable the audio output discharge mechanism. Clear to disable the audio output discharge mechanism.					
0	AOPRE	Audio Outpo Set to enable Clear to disa	ut Preload Bi the audio ou ble the audio	it htput preload n output preload	nechanism. d mechanism.			

Reset Value = 0000 0000b

Table 180. ACORG Register (AT85C51SND3B1 and AT85C51SND3B2 only)

ACORG (2.EBh) - Audio Codec Right Output Gain Register

7	6	5	4	3	2	1	0
-	-	-	AORG4	AORG3	AORG2	AORG1	AORG0
Bit Number	Bit Mnemonic	Description					
7-5	-	Reserved The value re	ad from these	bits is always	0. Do not set	these bits.	
4-0	AORG4:0	Audio Outpo Refer to Tab	u t Right Gain le 157 for gair	n value.			

Reset Value = 0000 0000b





Table 181. ACOLG Register (AT85C51SND3B1 and AT85C51SND3B2 only)

ACOLG (2.ECh) – Audio Codec Left Output Gain Register

7	6	5	4	3	2	1	0		
-	-	-	AOLG4	AOLG3	AOLG2	AOLG1	AOLG0		
Bit Number	Bit Mnemonic	Description							
7-5	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.						
4-0	AOLG4:0	Audio Outpu Refer to Tab	ut Left Gain le 157 for gair	ı value.					

Reset Value = 0000 0000b

Table 182. ACIPG Register

ACIPG (2.EDh) - Audio Codec Input Preamplifier Gain Register

7	6	5	4	3	2	1	0
-	-	-	-	AILPG -	AIPG2	AIPG1	AIPG0

Bit Number	Bit Mnemonic	Description
7-4	-	Reserved The value read from these bits is always 0. Do not set these bits.
3	AILPG	AT85C51SND3B1 and AT85C51SND3B2: Audio Input Line Preamplifier Gain Refer to Table 161 for gain value. AT85C51SND3B0: Reserved The value read from this bit is always 0. Do not set this bit.
2-0	AIPG4:0	Audio Input Preamplifier Gain Refer to Table 160 for gain value.

Reset Value = 0000 0000b

Table 183. ADICON0 Register

ADICON0 (2.EEh) - Audio DAC Interface Control Register 0

7	6	5	4	3	2	1	0	
-	-	-	CSPOL	DSIZE	OVERS1	OVERS0	ADIEN	
Bit Number	Bit Mnemonic	Description						
7-5	-	Reserved The value rea	ad from these	bits is always	0. Do not set	these bits.		
4	CSPOL	Channel Sel Set to output Clear to outp	Channel Select DSEL Signal Output Polarity Bit Set to output the left channel on high level of DSEL output (PCM mode). Clear to output the left channel on the low level of DSEL output (I ² S mode).					
3	DSIZE	Audio Data Set to select Clear to select	Size Bit 32-bit data ou ct 16-bit data	itput format. output format.				

Bit Number	Bit Mnemonic	Description
1-2	OVERS1:0	Audio Oversampling Ratio Bits Refer to Table 164 for bits description.
0	ADIEN	Audio DAC Interface Enable Bit Set to enable the audio DAC interface. Clear to disable the audio DAC interface.

Reset Value = 0000 0000b

Table 184. ADICON1 Register

ADICON1 (2.EFh) - Audio DAC Interface Control Register 1

7	6	5	4	3	2	1	0	
-	-	-	JUST4	JUST3	JUST2	JUST1	JUST0	
Bit Number	Bit Mnemonic	Description						
7-5	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.					
4-0	JUST4:0	Audio Stream Justification Bits Refer to Section "Audio DAC Interface" for bits description.						

Reset Value = 0000 1000b

Table 185. ASCON Register

ASCON (2.E1h) – Audio Stream Control Register

7	6	5	4	3	2	1	0
ASC7	ASC6	ASC5	ASC4	ASC3	ASC2	ASC1	ASC0
Bit Number	Bit Mnemonic	Description					
7-0	ASC7:0	Audio Strea Bits content of	m Control By depends on th	r te le audio codec	c firmware.		

Reset Value = 0000 0000b

Table 186. ASSTA0 Register

ASSTA0 (2.E2h) - Audio Stream Status Register 0

7	6	5	4	3	2	1	0
AS0S7	AS0S6	AS0S5	AS0S4	AS0S3	AS0S2	AS0S1	AS0S0
Bit	Bit	-					
Number	Mnemonic	Description					
7-0	AS0S7:0	Audio Strea	m Status Byt	e 0 le audio codec	; firmware.		

Reset Value = 0000 0000b





Table 187. ASSTA1 Register

ASSTA1 (2.E3h) - Audio Stream Status Register 1

7	6	5	4	3	2	1	0
AS1S7	AS1S6	AS1S5	AS1S4	AS1S3	AS1S2	AS1S1	AS1S0
Bit	Bit						
Number	Mnemonic	Description					

Reset Value = 0000 0000b

Table 188. ASSTA2 Register

ASSTA2 (2.E9h) - Audio Stream Status Register 2

7	6	5	4	3	2	1	0
AS2S7	AS2S6	AS2S5	AS2S4	AS2S3	AS2S2	AS2S1	AS2S0
Bit	Bit						
Number	Mnemonic	Description					
7-0	AS2S7:0	Audio Strea Bits content of	m Status Byte depends on th	e 2 e audio codec	c firmware.		

Reset Value = 0000 0000b

Nand Flash Controller	 The AT85C51SND3B derivatives implement a hardware Nand Flash Controller (NFC) embedding the following features: Up to 4 Nand Flash (NF) memories SMC/XD support with up to 3 NF memories 512-byte, 1024-byte, 2048-byte page size support (provision for up to 8192-byte page size) Hardware ECC support High speed: up to 35 ns cycle time NF support Two separated secured memory segments: application segment for user codes, audio codec codes, fonts, screens mass storage segment for FAT formatting Hardware write protection management for application code segment Very high data transfer rate in read and write using DFC interface Proprietary wear-levelling support with extremely reduced CPU load
Functional overview	 As shown in Figure 78 the NFC architecture is based on six hardware units: The Clock unit The Control unit The Data unit The Security unit

- The Card Unit
- The Interrupt unit

These units are detailed in the following sections.

Figure 78. NFC Controller Block Diagram







Figure 79. Nand Flash Connection



- Clock Unit The NFC clock is generated based on the clock generator as detailed in Section "DFC/NFC Clock Generator", page 31. As soon as NFEN bit in NFCON is set, the NFC controller receives its system clock and can then be configured.
- **Control Unit** The Control unit configures the NFC and gives the user all the flexibility to interface the NF devices. All the flash commands must be produced by the software, and the NFC just sends to the Flash basic operations such as "read Id", "write a byte", "erase a block", ...
- **Configuration Descriptor** Prior to any operation, the NFC must be configured with static information concerning the NF devices connected to the product as well as other important information relevant to the desired behavior. The configuration is done by writing a descriptor byte by byte in the NFCFG register. The NF descriptor is composed of eight bytes (detailed in Table 189). The first byte written is byte 0.

After writing a descriptor, a new one can be written to the NFC.

Byte Offset	Byte Mnemonic	Description
0	NFPGCFG	NF Device Page Configuration Register Refer to Table 190 for register content organization.
1	SMPGCFG	SMC Device Page Configuration Register Refer to Table 190 for register content organization.
2	SCFG1	Sub Configuration Register 1 Refer to Table 191 for register content organization.
3	SCFG2	Sub Configuration Register 2 Refer to Table 192 for register content organization.
4	FPBH	NF Device First Protected Block Address Registers
5	FPBL	First address block of protected area. Refer to Section "Write Protection" for detailed information. Reset Value is 0000 0000b, 0000 0000b.
6	LPBH	NF Device Last Protected Block Address Registers
7	LPBL	First address block of protected area. Refer to Section "Write Protection" for detailed information. Reset Value is 0000 0000b, 0000 0000b.

Table 189. Configuration Descriptor Content

Table 190. NFPGCFG / SMPGCFG Registers

NFPGCFG / SMPGCFG – NF / SMC Device Page Configuration Registers

7	6	5	4	3	2	1	0
NDB3	NDB2	NDB1	NDB0	NDB4	-	-	-
Bit Number	Bit Mnemonic	Description					
7-3	NDB4:0	Page Data N Number of da	lumber ata bytes in a	page (unit is 5	512 bytes).		
2-0	-	Reserved The value rea	ad from these	bits is always	0. Do not set	these bits.	

Reset Value = 0000 0000b

Table 191. SCFG1 Register

SCFG1 – Sub Configuration Register 1

7	6	5	4	3	2	1	0
-	NUMDEV1	NUMDEV0	PDEV3	PDEV2	PDEV1	PDEV0	SMCEN
Bit Number	Bit Mnemonic	Description					
7	-	Reserved The value rea	ad from this b	it is always 0.	Do not set this	s bit.	
6-5	NUMDEV1:0	Nand Flash Write the nun	Device Numl	ber es connected ((SMC/XD inclu	uded) minus 1	
4-1	PDEV3:0	Protected De Refer to Tabl	Protected Device Configuration Bits Refer to Table 199 for more details.				
0	SMCEN	SmartMedia Set to enable Clear to disal	XD Card Ena SMC support SMC supp	able Bit rt. port.			

Reset Value = 0001 1110b

Table 192. SCFG2 Register

SCFG2 – Sub Configuration Register 2

7	6	5	4	3	2	1	0
-	-	-	-	-	-	BSIZE1	BSIZE0
Bit	Bit						
Number	Mnemonic	Description					





Bit Number	Bit Mnemonic	Description
		Block Size Bits
1-0	BSIZE1:0	 Write following value to specify the number of pages per block. This information is needed by the controller for the block protection management. 0 0: 32 pages per block 0 1: 64 pages per block 1 0: 128 pages per block 1 1: 256 pages per block

Reset Value = 0000 0000b

Specific Action

As soon as the NFC is configured, the NFC is 'idle', i.e. ready for operation and its running status flag NFRUN in NFSTA is cleared. The controller is ready to accept events, typically to prepare a page for read or write.

As long as the NFC remains in the running state (NFRUN flag set), any attempt to new event will lead to an ILLEGAL interrupt.

Here is the list of the possible events:

Writing in the NFACT register as detailed in Table 193 launches a specific action:

- select a device,
- begin a read data transfer (thus the spare zone will be checked),
- begin a write data transfer (thus the spare zone will be set),
- stop a data transfer before the end of a page,
- force CE low.

Table 193. Action Decoding

EXT	Г1:0	ACT2:0			Launched Action
х	х	0	0	0	No action
DE	ΞV	0	0	1	Device selection. The device number is selected by EXT.
х	х	0	1	0	Read session.
х	х	0	1	1	Write session.
х	CELOW	1	0	0	Selected NFCE signal assertion.
х	х	1	0	1	Data transfer stop.
A9	A8	1	1	0	Column address extension.
х	х	1	1	1	Reserved for future use.

Device Selection

This command selects the device which will receive the next incoming events. The device number is memorized until a new device selection action is performed.

DEV is the device number. SMC shall always be connected on device 3. Table 194 summarizes the possible configurations: if DEV is a device that does not comply with the configuration allowed, an illegal interrupt is triggered.

SMCEN	NUMDEV	Allowed DEV	Comment
	0	0	
0	1	0, 1	
0	2	0, 1, 2	
	3	0, 1, 2, 3	
1	0	3 (SMC)	No NF memory is selected
	1	3 (SMC), 0	
	2	3 (SMC), 0, 1	The SMLCK signal can not be used in this configuration, the SMLCK bit is irrelevant.
	3	3 (SMC), 0, 1, 2	Neither SMLCK nor SMINS signals can be used in this configuration. SMCD and SMLCK bits have an irrelevant value. SMCTE shall be cleared.

Table 194. Device Selection Allowed Configur
--

"Read" Session A "read" session is launched and the DFC flow control is enabled. When processing the spare zone, its information will be checked. "Write" Session A "write" session is launched and the DFC flow control is enabled. When processing the spare zone, its information will be set. NFCE Signal Force Low The 512B-pages memories need to keep asserted the NFCE line during the access time of a data. This can be done by setting the CELOW bit. In this case, the NFCEx signal selected by the last 'device select' action is asserted (NFCE[DEV]= L). If a new 'device select' action occurs while the CELOW bit is set, the NFCEx signal of the old selected device is de-asserted (NFCE[OLD DEV]= H), and the NFCEx signal of the new one is asserted ($\overline{NFCE}[NEW DEV] = L$). Clearing the CELOW bit does not force the NFCE signal high: The NFCE signal is automatically asserted at the beginning of the execution of any new commands. The NFCE signal is automatically de-asserted at the completion of the commands. Data Transfer Stop This action stops the NFC when the data transfer is finished. In this case, the controller state becomes "not running" (NFRUN bit cleared). This can also be used as an abort signal in streaming mode. Column Address Extension The 512B-pages memories have different kind of read commands (00h, 01h, 50h) depending the data zone that need to be processed (1st half, 2nd half or spare). The column address given is relative to the zone chosen by the read command. The NFC needs to have the absolute column address to stop automatically at the end of the page. The column address extension is given thanks to that command. A9:8 holds the address extension. 00h selects the 1st half zone, i.e. the 0-255 range in the data zone. This is the default value. A read or a write in NFADC resets A9:8 to 00h. 01h selects the 2nd half zone, i.e. the 256-511 range in the data zone.

- 10h selects the spare zone, i.e. the 512-527 range in the data zone.



Note that it is not possible to reset A9:8 after each command (write in NFCMD): the device status read command is used after opening a page (for read) to poll the busy status.

Writing a command in NFCMD generates the following cycles:

Assembly code: mov direct, #



A write in that register re-initializes the ECC engine and the ECC FIFO. A read in that register returns an unexpected value.

Writing an address in NFADC (column address) or NFADR (row address) generates the following cycles:

Assembly code: mov direct, #



Address

The NFADC register is used to select the column address. The NFC uses that information to build an internal byte counter in the page, thus allowing it to stop at the end of the page. 512B NF memories (NDB= 1) have 1 column cycle. Other NF memories have 2 column cycles.

The NFADR register is used to select the raw address, i.e. the page address. The NFC uses that information to verify if the block is protected or not.

Both kind of information are reset after a read of a write of the NFCMD register. A read in NFADC or NFADR returns an unexpected value.

Command Sending

Address Sending

Data Reading/Writing

The NFDAT and NFDATF registers allow reading or writing of a byte without the use of the DFC as detailed in the Section "Data Unit". It launches an immediate read or write NF cycle, depending if the software reads or writes in those registers.

Note: The ECC is also computed when byte are read or written via NFDAT or NFDATF.

A write in NFDAT or NFDATF will produce an immediate "write cycle" (the NF signals will be asserted accordingly) to store the byte given by the CPU.

Assembly code: mov direct, #



Write data

- A read of NFDATF or NFADC returns to the CPU the byte contained in that register and launches in background a new "read cycle" (the NF signals will be asserted accordingly). Once the "read cycle" is completed, the byte is held in the NFDAT and NFDATF or NFADC registers. (*The NFC stays in the running state (NFRUN set) as* long as the "read cycle" is not performed).
- Note: The NFADC register is particularly suitable to read and poll the nand flash(es) status register.

Depending on the Nand Flash manufacturer, read cycle waveform may differ on the NFRE pulse width parameter. In order to be compliant with all memories, NFRE read pulse width can be programmed using TRS bit in NFCON according to Table 195.

Table 195.	Read Cycle C	onfiguration
------------	--------------	--------------

TRS	Description
0	[1.5; 0.5] Cycle NFRE asserted during 1.5 clock period and deasserted during 0.5 clock period.
1	[1.0;1.0] Cycle NFRE asserted during 1 clock period and deasserted during 1 clock period.





Assembly code: mov #, direct



A read of NFDAT returns to the CPU the byte contained in that register, but does not launch an extra background "read cycle".

Assembly code: mov #, direct

٠

In all the previous examples, the $\overline{\text{NFCE}}$ line is asserted low and de-asserted at the end of the cycle. This allows minimizing the power consumption.

Access Example Figure 80 shows a read access in a 512B page. Note that the NFCE must be held low during the access time for that kind of memory:





Legend:

- "ifc CPU" illustrates the commands given by the CPU to the NFC.
- "auto" illustrates the actions automatically launched by the NFC.
- "ready" is the flow control line between the DFC macro and the NFC interface.
- "BUSYD" is the busy state of the device D.
- "P" is the Polling action.

Data Unit

The Data Unit works closely to the DFC and is responsible of all the data transfer between the NF memories and on-chip memories (USB, SRAM, ...).

Data and Spare Zone For management convenience, the controller is mapping a memory page as some data and spare zones.

A 'data zone' is a data area composed of NDB contiguous bytes.

The 'spare zone' is located after the 'data zone' until the end of the page. NDB is part of the configuration descriptor (see Table 190) and its use is described in the following examples:

 SMC page, "512B" NF page, "512B" XD card A page is composed of 512 contiguous data bytes (NDB= 1), followed by a spare zone of 16 bytes.



"2kB" NF page

A page is composed of 1024 contiguous data bytes (NDB= 4), followed by a spare zone of 64 bytes.

	Data zone	Spare zone
•	2048 B	►4 _{64 B}

Spare Zone Content

The "16-byte" spare zone contains information as specified in Table 196.





Table 196. Spare Zone Content

Offset	Description
0-1	User Data Area. Shall be managed by software.
2	ECC Valid. Managed by NFC.
3	User Data Byte. Managed by NFC through NFUDAT register.
4	Data Status Flag. Shall be managed by software.
5	Block Status Flag. Shall be managed by software.
6-7	Logical Block Address. Managed by NFC through NFLOG register (see Section "Logical Block Address").
8-10	ECC Area-2. Managed by NFC.
11-12	Logical Block Address. Managed by NFC through NFLOG register (see Section "Logical Block Address").
13-15	ECC Area-1. Managed by NFC.

Write Session

The spare zone is processed after the 'data zone'.

The NFC will initialize the byte at offset 3 with the byte contained in the NFUDAT register, and the 'Logical Block Address' (offsets 6-7, also duplicated at offsets 11-12) with the 2-bytes-descriptor stored in NFLOG (see Table 198, page 180 for more details).

Then the ECC is written at position 13, 14 and 15 for the ECC group 1 (from data byte 0 to data byte 255), and at position 8, 9 and 10 for ECC group 2 (from data byte 256 to data byte 511).

The ECC used can detects 2 wrong bits or more, and correct one bit.

Read SessionThe NFC does only check (depending configuration explained in the next chapter) the
ECC (ECC-1 and ECC-2).

Spare Zone Management The way the spare zone is handled depends on 3 bits: the SPZEN bit in NFCON which is the automatic management enable bit, the ECCEN which is the ECC management enable bit and the ECCRDYE bit which is the ECC ready interrupt enable bit. Table 197 summarizes the spare zone behavior according to those control bits. Following section give detail on the management modes.

 Table 197.
 Spare Zone Management Modes

SPZEN	ECCEN	ECCRDYE	Description
0	0	х	Spare Zone Management Mode 1 The spare zone is not managed by the NFC.
1	1	0	Spare Zone Management Mode 2 The spare zone is entirely managed by the NFC.
х	1	1	Spare Zone Management Mode 3 The spare zone is not automatically managed by the NFC. However, an interrupt is triggered when the ECC FIFO is full, so after each 512 bytes processed. The user must program/verify the spare zone.

SPZEN	ECCEN	ECCRDYE	Description
0	1	0	Not Supported This configuration is reserved and must not be programmed.
1	0	х	Not Supported This configuration is reserved and must not be programmed.

Spare Zone Mode 1 The spare zone is not managed by the NFC. The data zone is contiguous.

The user sends the commands to prepare the page for read or write. The data flow starts when the READ or WRITE bits are set by the user (write in NFACT). The NFC did not manage the spare zone, and did not stop when the ECC FIFO is full. Thus, NFC stops when it reaches the end of the data zone, or when it receives a STOP action.

Spare Zone Mode 2 The spare zone is entirely managed by the NFC. The ECC is computed when the data flow starts. Each 256 bytes met, a 3-bytes ECC is built and stored in an ECC FIFO. When the ECC FIFO is full, the NFC stops the flow control to the DFC, and process the spare zone (ECC, logical value, parity... described later).

If the data flow stops before the end of the data zone, the user has the responsibility to stop the NFC and to program the spare zone.

The NFC will stop (idle mode) when it meet the end of the page. In this case, according to NECC, the controller will program/verify the appropriate spare zone(s). Let's take an example with 2kB memories:

- if the flow starts from the beginning of the page, NECC is 4 and the 4 spare zones will be verified or checked
- if the flow starts at offset 512, NECC is 3 and the 3 last spare zones of the page be verified or checked.
- etc.

Note that;

- For WRITE session, the byte at offset 2 is written to 0 (ECC valid) when the spare zone is written.
- For READ session, the ECC is verified only if the ECC is valid (byte at offset 2 is 0).

This mechanism ensures that the ECC is verified when it is valid.

This mode is particularly well suited for 512B and 2kB memories. For other kind of memories, mode 3 is preferable.

Spare Zone Mode 3 The spare zone is not automatically managed by the NFC. The ECC is computed and stored in the ECC FIFO. When the ECC FIFO is full, the flow control is stopped and an interrupt is sent. The NFC returns to the idle state.

For 512B memories, the ECCRDYI interrupt is always triggered after 512 data bytes seen.

For 2kB memories and higher memories, the ECCRDYI interrupt is always triggered after 2048 data bytes seen.

The ECC engine is reset after a write in the NFCMD register. NECC gives the number of ECC in the FIFO.

Depending on the mapping of the page, the user have the possibility to:

send the right events to program/verify the spare zone (reading the ECC FIFO). The READ or WRITE bits must be set (write in NFACT) to resume the data transfer, until the end of the page or an STOP action. The firmware shall also re-initialize the ECC FIFO by writing to NFECC.





read the ECC FIFO, (keeping the ECCs in memory), re-initialize it, resume the data transfer, and to write all the ECC bytes at the end of the page.

Logical Block Address In order to automatically and properly fill the spare zone, the logical block address must be provided to the NFC. This is done by writing a 2-bytes descriptor byte by byte to the NFLOG register according to Table 198. The first byte written is byte 0. The logical block addresses must be updated each time the data flow reaches the beginning of new logical blocks.

Byte Offset	Byte Mnemonic	Description
0	LBAH	Logical Block Address (MSB).
1	LBAL	Logical Block Address (LSB).

Table 198. Logical Block Address descriptor Content

Reset Value = 0000 0000b for each byte.

In order to keep SMC compatibility, LBA will be organized as follow:

0 0 0 1 0 A A A A A A A A A A P

Header 00010b and parity "P" are handled by software. "A" represents the logical block address.

End of Data Transfer When the data transfer stops, an interrupt is sent by the DFC macro to the CPU. The CPU has then to stop the NFC macro by sending a STOP action. This action can also be considered as an abort signal in a streaming mode. A STOP action makes the NFC return cleanly to the idle state (NFRUN cleared): it does not stop a spare area processing.

End of Transfer Closing When the NFC stops following a STOP action, in the case of a write session, the user must properly stop the page programming by copying old sectors to the new page. Moreover, the spare zone shall also be managed by the software.

To do this, the user needs to know where the NFC stopped: the NFBPH and NFBPL registers contain the byte position of the next data to be read or written. For example, it contains 0 after a reset, and 528 if the controller stops in a 512B page after the spare zone processing.

This register is incremented each time a byte is read through NFDATF or written through NFDAT or NFDATF, spare zone included.

A read of NFDAT or NFADC does not increment the NFBP counter.

The NFBP counter can be updated by software. Anyway, this shall be done in debug mode, and only when the NFC is not running.

Moreover, the NECC counter is updated when the controller reaches the end of the page. It gives the number of ECC that is ready to be written/updated. This feature shall be used when the flow does not start from the beginning of a page. For example, it contains 3 if the flow starts at offset 512 till the end of the page. In this situation, the three last ECC can be written/checked.

Security Unit The Security Unit provides hardware mechanisms to protect NF content from any firmware crash and prevent data loss and provides data recovery capability through ECC management.
Write Protection	The NFC provides a hardware mechanism to protect full or part of the memory against any spurious writing. This is achieved by using the NFWP signal and connecting it to the WP pins of the memories.
	The NFWP signal is automatically asserted in the following conditions:
	The internal voltage is out of specified value (brown-out detection)
	An external reset has been applied to the device
	 A watchdog reset has been triggered (bad code execution)
	A write or erase to the protected area has been triggered (bad code execution)
User Whole Memory Protection	The user has the possibility to protect all the flash devices (NF and SMC) by asserting the external NFWP signal. This is achieved by clearing the NFWP bit in NFCON. All the memories are protected at the same time, i.e. NF and SMC if a SMC is present.
Hardware Protected Area	A user defined area in the memories (a certain amount of blocks) can be locked against writing or erasing. This is done by giving to the controller the first protected block (FPB) address, the last protected block address (LPB) and the device number to be locked (PDEV). All this information is part of the Configuration Descriptor. Table 199 summarizes which device is locked or not.
	The protected area is practically used for user firmwares, codec firmwares, fonts and

The protected area is practically used for user firmwares, codec firmwares, fonts and other configuration data.

PDEV3	PDEV2	PDEV1	PDEV0	Description
0	0	0	0	No locked devices
х	х	х	1	The blocks [FPB; LPB] of NF device 0 are locked
х	х	1	х	The blocks [FPB; LPB] of NF device 1 are locked
х	1	х	х	The blocks [FPB; LPB] of NF device 2 are locked
1	x	х	x	The blocks [FPB; LPB] of NF device 3 (SMCEN=0) or of SMC (SMCEN=1) are locked

 Table 199.
 Protected Device versus PDEV Value

Then, if a device is protected, the following policy is applied:

- If FPB is lower than LPB, the protected area is a contiguous area starting from FPB to LPB.
- If FPB is higher than LPB, there are two protected areas: any block address that is below LPB and any block address that is above FPB.
- If FPB is equal to LPB, all the flash is protected. This is the default behavior.









Since the NFWP signal state is part of the device status, the user can detect a fault be reading it.

ECC Error Management When an ECC error is detected, the ECCERRI flag is set in NFINT and the 4-byte ECC error FIFO is updated. The FIFO content is read byte by byte using the NFERR register as detailed in Table 200.

First byte of the FIFO returns a status if the error can or can not be corrected. If it can no be corrected other 3-byte FIFO are cleared, If it can be corrected, the following 3 bytes return the address of the byte in error within the page (2 bytes) and the address of the bit in error within the byte (1 byte).

For example, if the byte read at offset 1921 (starting from 0) in a 2K page is E3 (wrong) instead of A3:

- byte offset MSB will be 07h
- byte offset LSB will be 81h
- bit offset will be 06h

Table 200. ECC Error Descriptor

Offset	Description
0	Error Identification Byte Refer to Table 201 for information on byte content.
1	First 256-byte group of the sector Byte offset
2	Second 256-byte group of the sector Byte offset
3	Bit offset in the byte Refer to Table 201 for information on byte content.

Table 201. ECC Error Identification Byte

7	6	5	4	3	2	1	0
0	0	0	0	SHERRID1	SHERRID0	FHERRID1	FHERRID0

Bit Number	Bit Mnemonic	Description
7-0	0	Reserved The value read from these bits is always 0.
3-2	SHERRID1-0	Second Half Error Id Flag Id of the error in the second "256-byte" group of the sector. 1: Correctable error. 2: Not correctable error. 3: Not correctable error in the ECC. Anyway, the data is good.
1-0	FHERRID1-0	First Half Error Id Flag Id of the error in the first "256-byte" group of the sector. 1: Correctable error. 2: Not correctable error. 3: Not correctable error in the ECC. Anyway, the data is good.

Table 202. ECC ERror Identification Byte

7	6	5	4	3	2	1	0	
0	0	SHFB2	SHFB1	SHFB0	FHFB2	FHFB1	FHFB0	
Bit Number	Bit Mnemonic	Description	Description					
7-6	-	Reserved The value rea	Reserved The value read from these bits is always 0.					
5-3	SHFB2:0	Second Half	Second Half Fail Bit Flag					
2-0	FHFB2:0	First Half Fa	il Bit Flag					

Card Unit

Enable

Card Detect Input

Smartmedia or XD card management is enabled by setting SMCEN bit in SCFG1 register as detailed in Section "Configuration Descriptor" where specific configuration must also be set.

ct Input As shown in Figure 82 the SMINS (SMC/XD Card Detect) input implements an internal pull-up, in order to provide static high level when card is not present in the socket.

SMINS level is reported by SMCD bit⁽¹⁾ in NFSTA.

As soon as SMC is enabled, all level modifications on SMINS input from H to L or from L to H (card insertion or removal) set SMCTI, the SM Card Toggle Interrupt flag in NFINT. Note: 1. SMCD bit is not relevant until SMC management is enabled.

Figure 82. Card Detection Input Block Diagram







Card Lock Input

As shown in Figure 83 the \overline{SMLCK} (SMC/XD Lock) input implements an internal pull-up, in order to provide static high level when card is not present in the socket.

SMLCK level is reported by SMLCK bit⁽¹⁾ in NFSTA register.

Note: 1. SDWP bit is not relevant until SMC management is enabled and a card is present in the socket (SMCD = 0).

Figure 83. Card Write Protection Input Block Diagram



Interrupt Unit

As shown in Figure 84, the NF controller implements five interrupt sources reported in SMCTI, ILGLI, ECCRDYI, ECCERRI, STOPI flags in NFINT register. These flags must be cleared by software when processing the interrupt service routine.

All these sources are enabled separately using SMCTE, ILGLE, ECCRDYE, ECCERRE, STOPE enable bits respectively in NFIEN register.

The interrupt request is generated each time an enabled flag is set, and the global NFC controller interrupt enable bit is set (ENFC in IEN1 register).



Figure 84. NFC Controller Interrupt System

There are 2 kinds of interrupts: processing (i.e. their generation is part of the normal processing) and exception (i.e. their generation correspond to error cases).

Processing interrupts are generated when:

- running to not running state transition (STOPI)
- ECC ready for operation (ECCRDYI)
- SMC insertion or removal (SMCTI)

Exception Interrupts are generated when the following events are met:

ECC error (ECCERRI)

184 **AT85C51SND3B**

or illegal operation (ILGLI)

.

- Attempt to access a NF device which is not declared (e.g. DEV= 4 while NUMDEV= 2)
- Write of events (NFDATF, NFDAT, NFCMD, NFADC, NFADR) while NFC is running (NFRUN= 1).
 Note that writing in NFACT while NFC is running (RUN=1) does not lead to an ILGLI interrupt.

As soon as an enabled interrupt is triggered, the NFC becomes not running (NFRUN= 0).

Registers

Table 203. NFCFG Register

NFCFG (1.99h) - Nand Flash Controller Configuration Register

7	6	5	4	3	2	1	0
NFGD7	NFGD6	NFGD5	NFGD4	NFGD3	NFGD2	NFGD1	NFGD0
Bit Number	Bit Mnemonic	Description					
7-0	NFGD7:0	Nand Flash Read Mode Reading from Write Mode Write 8 byte Table 189.	Configuratio In this register Is of data to t	n 8-byte Data resets the FIF update the N	FIFO O manager. FC configurat	ion registers	according to

Reset Value = 0000 0000b

Table 204. NFLOG Register

NFLOG (1.9Ah) - Nand Flash Controller Logical Block Address Register

7	6	5	4	3	2	1	0
NFLAD7	NFLAD6	NFLAD5	NFLAD4	NFLAD3	NFLAD2	NFLAD1	NFLAD0
Bit Number	Bit Mnemonic	Description					
7-0	NFLAD7:0	Nand Flash Read Mode Reading from Write Mode Write 2 byte according to	Logical Addr n this register es of data (M Table 198.	resets the FIF	ata FIFO O manager lo update the N	gical block ac FC logical b	ddress. lock address





Table 205. NFCON Register

NFCON (1.9Bh) - Nand Flash Controller Control Register

7	6	5	4	3	2	1	0		
-	-	- TRS NFWP SPZEN ECCEN NF							
Bit Number	Bit Mnemonic	Description	Description						
7-5	-	Reserved The value re	ad from these	bits is always	0. Do not set	these bits.			
4	TRS	Timing Read Set to use tir Clear to use	1 Select Bit ning [1; 1] for timing [1.5; 0.	read cycle. 5] for read cyc	cle.				
3	NFWP	Write Protect Set to unprot Clear to protect	et Bit ect the flash o ect the flash d	devices (<mark>NFW</mark> levices (NFWF	P signal de-as ⁵ signal asser	serted). ted).			
2	SPZEN	Spare Zone Set to enable Clear to disa	Spare Zone management enable Bit Set to enable the spare zone management Clear to disable the spare zone management.						
1	ECCEN	ECC manag Set to enable Clear to disa	ement enable the ECC call ble the ECC c	e Bit culation. calculation.					
0	NFEN	General NFC Set to enable Clear to put t	C Enable Bit the NF contr the NFC is in	oller. the 'suspend'	state.				

Table 206. NFERR Register

NFERR (1.9Ch) - Nand Flash Controller ECC Error Information Register

7	6	5	4	3	2	1	0
ERR7	ERR6	ERR5	ERR4	ERR3	ERR2	ERR1	ERR0
Bit Number	Bit Mnemonic	Description					
7-0	ERR7:0	Error Descri Sequential re This register	i ptor 4-byte E eading returns is updated fol	Data FIFO the 4-byte EC lowing an ECO	CC error desci C error (ECCE	riptor (see Tab ERRI set).	ble 200).

Reset Value = 0000 0000b

Table 207. NFADR Register

NFADR (1.9Dh) - Nand Flash Controller Row Address Register

7	6	5	4	3	2	1	0
NFRAD7	NFRAD6	NFRAD5	NFRAD4	NFRAD3	NFRAD2	NFRAD1	NFRAD0
Bit Number	Bit Mnemonic	Description					

Table 208. NFADC Register

NFADC (1.9Eh) - Nand-Flash Controller Column Address Register

7	6	5	4	3	2	1	0
NFCAD7	NFCAD6	NFCAD5	NFCAD4	NFCAD3	NFCAD2	NFCAD1	NFCAD0
Bi+	Bit						
DIL	ы						
Number	Mnemonic	Description					

Reset Value = 0000 0000b

A read of that register returns an unexpected value.

Table 209. NFCMD Register

NFCMD (1.9Fh) - Nand-Flash Controller Command Register

7	6	5	4	3	2	1	0
CMD7	CMD6	CMD5	CMD4	CMD3	CMD2	CMD1	CMD0
	D						
Bit Number	Bit Mnemonic	Description					
7-0	CMD7:0	Command D	ata Byte				

Reset Value = 0000 0000b

Table 210. NFACT Register

NFACT (1.A1h) - Nand-Flash Controller Action Register

7	6	5	4	3	2	1	0			
-	-	-	EXT1	EXT0	ACT2	ACT1	ACT0			
Bit Number	Bit Mnemonic	Description	Description							
7-5	-	Reserved The value rea	Reserved The value read from these bits is always 0. Do not set these bits.							
4-3	EXT1:0	Extension B Refer to Tab	Extension Bits Refer to Table 193 for the bit description.							
2-0	ACT2:0	Action Bits Refer to Tab	le 193 for the	bit description						





Table 211. NFDAT Register

NFDAT (1.A2h) - Nand-Flash Controller Data Access Register

7	6	5	4	3	2	1	0				
DATD7	DATD6	DATD5	DATD4	DATD3	DATD2	DATD1	DATD0				
Bit Number	Bit Mnemonic	Description	Description								
7-0	DATD7:0	Data Byte Writing data	sends a data t	to the currently a returned by t	y selected NF.	vcle.					

Reset Value = 0000 0000b

Table 212. NFDATF Register

NFDATF (1.A3h) - Nand-Flash Controller Data Access and Fetch Next Data Register

7	6	5	4	3	2	1	0
DATFD7	DATFD6	DATFD5	DATFD4	DATFD3	DATFD2	DATFD1	DATFD0
Bit Number	Bit Mnemonic	Description					
7-0	DATFD7:0	Data Byte Writing data Reading data cycle on the	sends a data t a gets the data currently seled	to the currentl a returned by cted NF.	y selected NF. the last read	cycle and rela	aunch a read

Reset Value = 0000 0000b

Table 213. NFSTA Register

NFSTA (1.98h) - Nand Flash Controller Status Register

7	6	5	4	3	2	1	0			
SMCD	SMLCK	-	NFEOP	NECC2	NECC1	NECC0	NFRUN			
Bit Number	Bit Mnemonic	Description								
7	SMCD	SmartMedia Set by hardw Cleared by h	martMediaCard Detection Flag Set by hardware when the SMINS input is High. Seared by hardware when the SMINS input is Low.							
6	SMLCK	SmartMedia Card Lock Flag Set by hardware when the SMC is write-protected. Cleared by hardware when the SMC is not write-protected.								
5	-	Reserved The value rea	Reserved The value read from this bit is always 0. Do not set this bit.							
4	NFEOP	End Of Page Set by hardw clear by hard	End Of Page Flag Set by hardware when the controller stops at the end of the page. clear by hardware if the controller did not reach the end of the page.							
3-1	NECC2:0	Number of E Set/clear by I	ECC Bits hardware. See	e Section "EC	C Error Manag	gement" for m	ore details.			

Bit Number	Bit Mnemonic	Description
0	NFRUN	Running Flag Set by hardware to signal that it is currently running. Cleared by hardware to signal it is not running.

Reset Value = 0000 0000b

Table 214. NFECC Register

NFECC (1.A4h) - Nand Flash Controller ECC 1 and ECC 2 Register

7	6	5	4	3	2	1	0
NFED7	NFED6	NFED5	NFED4	NFED3	NFED2	NFED1	NFED0
Bit Number	Bit Mnemonic	Description					
7-0	NFED7:0	Nand Flash Read Mode Sequential re Write Mode Writing any d	ECC 6-byte E eading returns ata resets the	Data FIFO 2 ECC values ECC engine	s of 3 bytes. and the FIFO	manager.	

Reset Value = 0000 0000b

Table 215. NFINT Register

NFINT (1.A5h) - Nand Flash Controller Interrupt Register

7	6	5	4	3	2	1	0					
-	-	-	SMCTI	ILGLI	ECCRDYI	ECCERRI	STOPI					
Bit Number	Bit Mnemonic	Description	Description									
7-5	-	Reserved The value re	Reserved The value read from these bits is always 0. Do not set these bits.									
4	SMCTI	SmartMedia Set by hardw Shall be clea	SmartMedia Card Transition Interrupt Flag Set by hardware every time SMCD bit in NFSTA is toggling. Shall be cleared by software.									
3	ILGLI	ILLEGAL operation Interrupt Flag Set by hardware when an illegal operation is performed. Shall be cleared by software.										
2	ECCRDYI	ECC Ready Interrupt Flag Set by hardware when the ECCs (6 bytes) are ready for operation. This bit is set/clear even if the spare zone is automatically managed (ECCEN). Shall be cleared by software.										
1	ECCERRI	ECC Error Interrupt Flag Set by hardware when a bad ECC is seen. Shall be cleared by software.										
0	STOPI	Stop Interru Set by hard transition is r Shall be clea	pt Flag ware when a net (end of pa ired by softwa	running (NF ge, end of da re.	RUN= 1) to ta transfer,)	not running (NFRUN= 0)					





Table 216. NFIEN Register

NFIEN (1.A6h) - Nand Flash Controller Interrupt Enable Register

7	6	5	4	3	2	1	0					
-	-	-	SMCTE	ILGLE	ECCRDYE	ECCERRE	STOPE					
Bit Number	Bit Mnemonic	Description	Description									
7-5	-	Reserved The value re	Reserved The value read from these bits is always 0. Do not set these bits.									
4	SMCTE	SMC Transit Set to enable Clear to disa	SMC Transition Interrupt Enable Bit Set to enable the SMCTI interrupt. Clear to disable the SMCTI interrupt.									
3	ILGLE	Illegal Opera Set to enable Clear to disa	Illegal Operation Interrupt Enable Bit Set to enable the ILGLI interrupt. Clear to disable the ILGLI interrupt.									
2	ECCRDYE	ECC Ready Set to enable Clear to disa	ECC Ready Interrupt Enable Bit Set to enable the ECCRDYI interrupt. Clear to disable the ECCRDYI interrupt.									
1	ECCERRE	ECC Error Interrupt Enable Bit Set to enable the ECCERRI interrupt. Clear to disable the ECCERRI interrupt.										
0	STOPE	Stop Interru Set to enable Clear to disa	pt Enable Bit the STOPI ir ble the STOP	t nterrupt. I interruption.								

Reset Value = 0000 0000b

Table 217. NFUDAT Register

NFUDAT (1.A7h) - Nand Flash Controller User Data Register

7	6	5	4	3	2	1	0		
NFUD7	NFUD6	NFUD5	NFUD4	NFUD3	NFUD2	NFUD1	NFUD0		
Bit Number	Bit Mnemonic	Description							
7-0	NFUD7:0	Nand Flash User Data Byte User defined byte stored in byte position 3 of each spare zone.							

Table 218. NFBPH Register

NFUDAT (1.94h) - Nand Flash Controller Byte Position (MSB) Register

7	6	5	4	3	2	1	0	
BP15	BP14	BP13	BP12	BP11	BP10	BP9	BP8	
Bit Number	Bit Mnemonic	Description						
7-0	BP15:8	Nand Flash Position High Byte Most significant byte of the Byte Position counter.						

Reset Value = 0000 0000b

Table 219. NFBPL Register

NFUDAT (1.95h) - Nand Flash Controller Byte Position (LSB) Register

7	6	5	4	3	2	1	0		
BP7	BP6	BP5	BP4	BP3	BP2	BP1	BP0		
Bit Number	Bit Mnemonic	Description							
7-0	BP7:0	Nand Flash Position Low Byte Least significant byte of the Byte Position counter.							





MMC/SD Controller

The AT85C51SND3B derivatives implement a MMC/SD controller allowing connecting of MMC and SD cards in 1-bit or 4-bit modes. For MMC, 4-bit mode rely on the MMC Specification V4.0.

The MMC/SD controller interfaces to the C51 core through the following special function registers:

MMCON0, MMCON1, MMCON2, the three MMC control registers (see Table 222 to Table 224); MMBLP, the MMC Block Length register (see Table 225); MMSTA, the MMC status register (see Table 226); MMINT, the MMC interrupt register (see Table 227); MMMSK, the MMC interrupt mask register (see Table 228); MMCMD, the MMC command register (see Table 229); and MMDAT, the MMC data register (see Table 230).

As shown in Figure 85, the MMC controller is based on four functional blocks: the clock generator that handles the SDCLK (formally the MMC/SD CLK) output to the card, the command line controller that handles the SDCMD (formally the MMC/SD CMD) line traffic to or from the card, the data line controller that handles the SDDAT (formally the MMC/SD DAT) line traffic to or from the card, and the interrupt controller that handles the MMC controller interrupt sources. These blocks are detailed in the following sections.

Figure 86 shows the external components to add for connecting a MMC or a SD card to the AT85C51SND3B. SDDAT0 and SDCMD signals are connected to pull-up resistors. Value of these resistors is detailed in the Section "DC Characteristics", page 242.





Figure 86. MMC Connection



Clock Generator The MMC clock is generated based on the clock generator as detailed in Section "MMC Clock Generator", page 32. As soon as MMCEN bit in MMCON2 is set, the MMC controller receives its system clock. The MMC command and data clock is generated on SDCLK output and sent to the command line and data line controllers.

Command Line Controller As shown in Figure 87, the command line controller is divided in 2 channels: the command transmitter channel that handles the command transmission to the card through the SDCMD line and the command receiver channel that handles the response reception from the card through the SDCMD line. These channels are detailed in the following sections.



Figure 87. Command Line Controller Block Diagram

Command Transmitter

For sending a command to the card, the command index (1 Byte) and argument (4 Bytes) must be loaded in the command transmit FIFO using the MMCMD register. Before starting transmission by setting the TXCEN bit in MMCON1 register, software must first configure:

- RXCEN bit in MMCON1 register to indicate whether a response is expected or not.
- RFMT bit in MMCON0 register to indicate the response size expected.
- CRCDIS bit in MMCON0 register to indicate whether the CRC7 included in the response will be computed or not. In order to avoid CRC error, CRCDIS may be set for response that do not include CRC7.

Figure 88 summarizes the command transmission flow.

The TXCEN flag is set until the end of transmission. The end of the command transmission is signalled by the EOCI flag in MMINT register becoming set. This flag may generate an interrupt request as detailed in Section "Interrupt". The end of the command transmission also clears the TXCEN flag.

Command loading may be aborted by setting and clearing the CTPTR bit in MMCON0 register which resets the write pointer to the transmit FIFO.





Figure 88. Command Transmission Flow



Command Receiver

The end of the response reception is signalled by the EORI flag in MMINT register. This flag may generate an interrupt request as detailed in Section "Interrupt". When this flag is set, 2 other flags (RXCEN in MMCON1 register and CRC7S in MMSTA register) give a status on the response received. RXCEN is cleared when the response format is correct or not: the size is the one expected (48 bits or 136 bits) and a valid End bit has been received, and CRC7S indicates if the CRC7 computation is correct or not. The Flag CRC7S is cleared when a command is sent to the card and updated when the response has been received.

Response reading may be aborted by setting and clearing the CRPTR bit in MMCON0 register which resets the read pointer to the receive FIFO.

According to the MMC specification delay between a command and a response (formally N_{CR} parameter) can not exceed 64 MMC clock periods. To avoid any locking of the MMC controller when card does not send its response (e.g. physically removed from the bus), a time-out timer must be launched to recover from such situation. In case of time-out the command controller and its internal state machine may be reset by setting and clearing the CCR bit in MMCON2 register.

This time-out may be disarmed when receiving the response.

Data Line Controller

As shown in Figure 89, the data line controller is based on a 16-Byte FIFO used both by the data transmitter channel and by the data receiver channel. Data transfer can be handled in transmission or received by the Data Flow Controller (see Section "Data Flow Controller", page 78) or by the C51 using MMDAT register.





Bus Width Control The data line controller supports the SD card and the new MMC 4.0 4-bit bus mode allowing higher transfer rate. The 4-bit bus width is controlled by software by setting the DBSIZE1:0 bits in MMCON2 register according to Table 220. In case of 1-bit bus width (card default), SDDAT0 is used as SDDAT line and SDDAT3:1 lines are released as I/O port.

Table 220. Data Bus Size

DBSIZE1:0	Bus Size
0	1-bit SDDAT0 data bus.
1	4-bit SDDAT3:0 data bus.
2-3	Reserved for future use, do not program these values.

FIFO Implementation

The 16-Byte FIFO is managed using 1 pointer and four flags indicating the status ready of whole or half FIFO.

Pointer value is not accessible by software but can be reset at any time by setting and clearing DPTRR bit in MMCON0 register. Resetting the pointer is equivalent to abort the writing or reading of data.

FIFO flags indicate when FIFO is ready to be read in receive mode or to be written in transmit mode. WFRI is set when 16 bytes are available in writing or reading. HFRI is set when 8 bytes are available. These flags are cleared when read. These flags may generate an interrupt request as detailed in Section "Interrupt". WFRS and HFRS give the status of the FIFO. They are set when respectively 16 bytes or 8 bytes are ready to be read or written depending on the receive or transmit mode.





Data Configuration

Before sending or receiving any data, the data line controller must be configured according to the type of the data transfer considered. This is achieved using the Data Format bit: DFMT in MMCON0 register. Clearing DFMT bit enables the data stream format while setting DFMT bit enables the data block format. In data block format, the single or multi-block mode must also be configured by clearing or setting the MBLOCK bit in MMCON0 register and the block length in bytes using BLEN11:0⁽¹⁾ bits in MMCON1 and MMBLP according to Table 221. Figure 90 summarizes the data modes configuration flows. BLEN can have any value between 1 to 2048.

IANE ZZI. DIUCK LENGULLI IUGIAIIIIIII	Table 221.	Block	Length	Program	iming
---------------------------------------	------------	-------	--------	---------	-------

Register	Description
MMBLP7:0	Block Size LSB: BLEN11:8
MMCON1.7:4	Block Size MSB (LSN): BLEN7:0

Note: 1. BLEN = 1to 2048

Figure 90. Data Controller Configuration Flows



Data Transmitter

Configuration	For transmitting data to the card the data controller must be configured in transmission mode by setting the DATDIR bit in MMCON1 register.
	Figure 91 summarizes the data stream transmission flows in both polling and interrupt modes while Figure 92 summarizes the data block transmission flows in both polling and interrupt modes, these flows assume that block length is greater than 16 Bytes.
DFC Data Loading	In case the data transfer is handled by the DFC, a DFC channel must be configured with the MMC controller as destination peripheral. The programmed number of data is auton- omously transferred from the source peripheral to the FIFO without any intervention from the firmware. In case both FIFO are empty (e.g. source peripheral busy), card clock is automatically frozen stopping card data transfer thanks to the controller automatic flow control.
C51 Data Loading	In case the data transfer is handled by the C51 ⁽¹⁾ , data is loaded byte by byte in the FIFO by writing to MMDAT register. Number of data loaded may vary from 1 to 16 Bytes. Then if necessary (more than 16 Bytes to send) software must ensure that all FIFO or half FIFO becomes empty (WFRS or HFRS set) before loading 16 or 8 new data. In case both FIFO are empty, card clock is automatically frozen stopping card data transfer thanks to the controller automatic flow control.

Transmission is enabled by setting DATEN bit in MMCON1 register. FIFO must be filled

	after this flag is set. If at least the FIFO is half full, data is transmitted immediately when the response to the write command has already been received, or is delayed after the reception of the response if its status is correct. In both cases transmission is delayed if a card sends a busy state on the data line until the end of this busy condition.
	According to the MMC specification, the data transfer from the host to the card may not start sooner than 2 MMC clock periods after the card response was received (formally N_{WR} parameter). To address all card types, this delay can be programmed using DATD1:0 bits in MMCON2 register from 3 MMC clock periods when DATD1:0 bits are cleared to 9 MMC clock periods when DATD1:0 bits are set, by step of 2 MMC clock periods.
End of Transmission	In data stream mode, the end of a data frame transmission is signalled by the EOFI flag in MMINT register. This flag may generate an interrupt request as detailed in Section "Interrupt". It is set, after reception of the End bit. This assumes that the STOP command has previously been sent to the card, which is the only way to stop stream transfer.
	In data single block mode, the end of a data frame transmission is signalled by the EOFI flag in MMINT register. This flag may generate an interrupt request as detailed in Section "Interrupt". It is set after the end of busy signal on SDDAT0 line. After reception of the CRC status token, two other flags in MMSTA register: DATFS and CRC16S report a status on the frame sent. DATFS indicates if the CRC status token format is correct or not, and CRC16S indicates if the card has found the CRC16 of the block correct or not. CRC16S must by reset by software by setting DCR bit in MMCON2 register.
	interrupt request as detailed in Section "Interrupt"
	In data multi block mode, the end of a data frame transmission is signalled by the EOFI flag in MMINT register. This flag may generate an interrupt request as detailed in Section "Interrupt". It is set after the end of busy signal on SDDAT0 line. This assumes that the STOP command has previously been sent to the card, which is the only way to stop stream transfer
	The end of a block transmission is signalled by the EOBI flag in MMINT register. This flag may generate an interrupt request as detailed in Section "Interrupt". It is set after the end of busy signal on SDDAT0 line
	After reception of the CRC status token of a block, two other flags in MMSTA register: DATFS and CRC16S report a status on the frame sent. DATFS indicates if the CRC sta- tus token format is correct or not, and CRC16S indicates if the card has found the CRC16 of the block correct or not. CRC16S must by reset by software by setting DCR bit in MMCON2 register.
Busy Status	The card uses a busy token during a block write operation. This busy status is reported by the CBUSY flag in MMSTA register. The busy signal is set to 0 by the card after the CRC token. At the end of busy signal, the flag DATEN is cleared and EOFI flag is set.
	Note: some cards do not respect MMC specification, and the busy status is reported too late on the dat0 line, considering the N _{st} parameter. So CBUSY flag is not set. In this case, status of the card must be asked with a card command.



Data Transmission



Figure 91. Data Stream Transmission Flows





a. Polling mode

Figure 92. Data Block Transmission Flows



a. Polling mode

Data Receiver

Configuration

To receive data from the card the data controller must be configured in reception mode by clearing the DATDIR bit in MMCON1 register.

Figure 93 summarizes the data stream reception flows in both polling and interrupt modes while Figure 94 summarizes the data block reception flows in both polling and interrupt modes, these flows assume that block length is greater than 16 Bytes.

Data ReceptionReception is enabled by setting DATEN bit in MMCON1 register. The end of a data
frame (block(s) or stream) reception is signalled by the EOFI flag in MMINT register. In
multiblock mode, OEBI flag signals the reception of one block. These flags may gener-
ate an interrupt request as detailed in Section "Interrupt". When EOFI flag is set, 2 other
flags in MMSTA register: DATFS and CRC16S give a status on the frame received.
DATFS indicates if the frame format is correct or not: a valid End bit has been received,
and CRC16S indicates if the CRC16 computation is correct or not. CRC16S must by
reset by software by setting DCR bit in MMCON2 register. In case of data stream
CRC16S has no meaning and stays cleared. DATEN flag is cleared when EOFI is set.

According to the MMC specification data transmission from the card starts after the access time delay (formally N_{AC} parameter) beginning from the End bit of the read command. To avoid any locking of the MMC controller when card does not send its data (e.g. physically removed from the bus), a time-out timer must be launched to recover



	from such situation. In case of time-out, the data controller and its internal state machine may be reset by setting and clearing the DCR bit in MMCON2 register.
	This time-out may be disarmed after receiving 8 data (HFRS flag set) or after receiving end of frame (EOFI flag set) in case of block length less than 8 data (1, 2 or 4).
DFC Data Reading	In case the data transfer is handled by the DFC, a DFC channel must be configured with the MMC controller as source peripheral. The programmed number of data is autono- mously transferred from the FIFO to the destination peripheral without any intervention from the firmware. In case both FIFO are full (e.g. destination peripheral busy), card clock is automatically frozen stopping card data transfer thanks to the controller automatic flow control.
C51 Data Reading	In case the data transfer is handled by the C51 ⁽¹⁾ , data is read byte by byte from the FIFO by reading MMDAT register. Each time FIFO becomes full or half full (WFRI or HFRI set), software is requested to flush this FIFO by reading 16 or 8data. In case FIFO is full, card clock is automatically frozen stopping card data transfer thanks

to the controller automatic flow control. Note: 1. An enabled DFC transfer always takes precedence on a C51 transfer, it is under soft-

ware responsibility not to read from MMDAT register while a DFC transfer is enabled.





Figure 94. Data Block Reception Flows



Card Management

Card Detect Input

As shown in Figure 95 the $\overline{\text{SDINS}}$ (MMC/SD Card Detect) input implements an internal pull-up, in order to provide static high level when card is not present in the socket.

SDINS level is reported by CDET bit⁽¹⁾ in MMSTA.

As soon as MMC controller is enabled, all level modifications on $\overline{\text{SDINS}}$ input from H to L or from L to H (card insertion or removal) set CDETI, the Card Detect Interrupt flag in MMINT (see Table 227).

Note: 1. CDET bit is not relevant until MMC controller is enabled (MMCEN = 1).





Card Lock Input

As shown in Figure 96 the SDLCK (SD Lock) input implements an internal pull-up, in order to provide static high level when card is not present in the socket.

SDLCK level is reported by SDWP bit⁽¹⁾ in MMSTA register.

Note: 1. SDWP bit is not relevant until MMC controller is enabled (MMCEN = 1) and a card is present in the socket (CDET = 0).





Figure 96. SD Card Write Protection Input Block Diagram



Interrupt

As shown in Figure 97, the MMC controller implements eight interrupt sources reported in CDETI, EORI, EOCI, EOFI, WFRI, HFRI and EOBI flags in MMCINT register. These flags are detailed in the previous sections.

All these sources are maskable separately using CDETM, EORM, EOCM, EOFM, WFRM, HFRM and EOBM mask bits respectively in MMMSK register.

The interrupt request is generated each time an unmasked flag is set, and the global MMC controller interrupt enable bit is set (EMMC in IEN1 register).

Reading the MMINT register automatically clears the interrupt flags (acknowledgment). This implies that register content must be saved, and tested flag by flag to be sure not to forget any interrupts.

Figure 97. MMC Controller Interrupt System



Registers

Table 222. MMCON0 Register

MMCON0 (1.B1h) - MMC Control Register 0

7	6	5	4	3	2	1	0				
-	DPTRR	CRPTR	CTPTR	MBLOCK	DFMT	RFMT	CRCDIS				
Bit Number	Bit Mnemonic	Description									
7	-	Reserved The value rea	ad from this b	it is always 0.	do not set this	s bit					
6	DPTRR	Data Pointer Set to reset t Cleared by h	r Reset Bit he read and v ardware after	vrite pointer of pointer reset i	the data FIF(s achieved.	D.					
5	CRPTR	Command F Set to reset t Cleared by h	Command Receive Pointer Reset Bit Set to reset the read pointer of the receive command FIFO. Cleared by hardware after pointer reset is achieved.								
4	CTPTR	Command T Set to reset t Cleared by h	Command Transmit Pointer Reset Bit Set to reset the write pointer of the transmit command FIFO. Cleared by hardware after pointer reset is achieved.								
3	MBLOCK	Multi-block Enable Bit Set to select multi-block data format. Clear to select single block data format.									
2	DFMT	Data Format Bit Set to select the block-oriented data format. Clear to select the stream data format.									
1	RFMT	Response F Set to select Clear to sele	ormat Bit the 48-bit res ct the 136-bit	ponse format. response form	nat.						
0	CRCDIS	CRC7 Disab Set to disabl Clear to enal	e the CRC7 colored the CRC7 colored the CRC7 colored the CRC7	omputation wh computation v	nen receiving vhen receiving	a response. g a response.	CRC7 Disable Bit Set to disable the CRC7 computation when receiving a response. Clear to enable the CRC7 computation when receiving a response.				

Reset Value = 0000 0010b

Table 223. MMCON1 Register

MMCON1 (1.B2h) – MMC Control Register 1

7	6	5	4	3	2	1	0
BLEN3	BLEN2	BLEN1	BLEN0	DATDIR	DATEN	RESPEN	CMDEN
Bit Number	Bit Mnemonic	Description					
7-4	BLEN11:8	Block Length Bits Refer to Table 221 for bits description.					
3	DATDIR	Data Direction Set to select Clear to select	on Bit data transfer ct data transfe	from host to c er from card to	ard (write mod host (read m	de). ode).	





Bit Number	Bit Mnemonic	Description
2	DATEN	Data Transfer Enable Bit Set to enable data transmission or reception immediately or after response has been received. Cleared by hardware after the CRC reception in reception mode or after the busy status if any in transmission mode.
1	RXCEN	Response Command Enable Bit Set to enable the reception of a response following a command transmission. Cleared by hardware when response is received.
0	TXCEN	Command Transmission Enable Bit Set to enable transmission of the command FIFO to the card. Cleared by hardware when command is transmitted.

Reset Value = 0000 0000b

Table 224. MMCON2 Register

MMCON2 (1.B3h) - MMC Control Register 2

7	6	5	4	3	2	1	0		
FCK	DCR	CCR	DBSIZE1	DBSIZE0	DATD1	DATD0	MMCEN		
Bit Number	Bit Mnemonic	Description							
7	FCK	MMC Force Set to enable Clear to disa	MMC Force Clock Bit Set to enable the MCLK clock out permanently. Clear to disable the MCLK clock and enable flow control.						
6	DCR	Data Contro Set to reset to bit after an e Cleared by h	Data Controller Reset Bit Set to reset the data line controller in case of transfer abort, or to reset CRC16S bit after an error occurs. Cleared by hardware after the data line controller reset is achieved.						
5	CCR	Command C Set to reset t Cleared by h	Command Controller Reset Bit Set to reset the command line controller in case of transfer abort. Cleared by hardware after the command line controller reset is achieved.						
4-3	DBSIZE1:0	Data Bus Size Refer to Table 220 for bits description.							
2-1	DATD1:0	Data Transmission Delay Bits Used to delay the data transmission after a response from 3 MMC clock periods (all bits cleared) to 9 MMC clock periods (all bits set) by step of 2 MMC clock periods.							
0	MMCEN	MMC Clock Enable Bit Set to enable the MMC clocks and activate the MMC controller. Clear to disable the MMC clocks and freeze the MMC controller.							

Reset Value = 0000 0000b

Table 225. MMBLP Register

MMCON2 (1.B4h) – MMC Block Length LSB Register

7	6	5	4	3	2	1	0
BLEN7	BLEN6	BLEN5	BLEN4	BLEN3	BLEN2	BLEN1	BLEN0

Bit Number	Bit Mnemonic	Description
7-0	BLEN7:0	Block Length LSB Refer to Table 221 for byte description

Reset Value = 0000 0000b

Table 226. MMSTA Register

MMSTA (1.B5h Read Only) - MMC Status Register

7	6	5	4	3	2	1	0	
SDWP	CDET	CBUSY	CRC16S	DATFS	CRC7S	WFRS	HFRS	
Bit Number	Bit Mnemonic	Description						
7	SDWP	SD Card Wr Set by hardw Cleared by h	i te Protect Bi vare when the ardware wher	t SD card sock the SD card	et WP switch socket WP sw	is opened. vitch is closed		
6	CDET	Card Detect Set by hardw Cleared by h	ion Bit /are when the ardware wher	SD card sock the SD card	et presence s socket preser	witch is opene ice switch is c	ed. Iosed.	
5	CBUSY	Card Busy F Set by hardw Cleared by h	ilag vare when the ardware wher	card sends a the card no r	busy state on nore sends a l	the data line. busy state on	the data line.	
4	CRC16S	CRC16 State Transmissic Set by hardw Cleared by s Reception n Set by hardw Cleared by s	CRC16 Status Bit Transmission mode Set by hardware when the token response reports a bad CRC. Cleared by software by setting DCR bit in MMCON2. Reception mode Set by hardware when the CRC16 received in the data block is not correct. Cleared by software by setting DCR bit in MMCON2.					
3	DATFS	Data Format Transmissic Set by hardw Cleared by h Reception n Set by hardw Cleared by h	Status Bit on mode vare when the ardware wher node vare when the ardware wher	format of the n the format of format of the n the format of	token respons the token res frame is corre the frame is i	se is correct. ponse is not c ect. not correct.	correct.	
2	CRC7S	CRC7 Status Bit Set by hardware when the CRC7 computed in the response is correct. Cleared by hardware when the CRC7 computed in the response is not correct. This bit is not relevant when CRCDIS is set.						
1	WFRS	Whole FIFO Set by hard transmit moc Cleared by h	Whole FIFO Ready Status Bit Set by hardware when 16 bytes can be read in receive mode or written in transmit mode. Cleared by hardware when FIFO is not ready.					
0	HFRS	Half FIFO Re Set by hardw mode. Cleared by h	ady Status E vare when 8 b ardware wher	Bit ytes can be re n FIFO is not r	ad in receive eady.	mode or writte	ən in transmit	

Reset Value = XX00 0000b, depends wether a card is present in the socket or not and if it is locked or not.





Table 227. MMINT Register

MMINT (1.BEh Read Only) - MMC Interrupt Register

7	6	5	4	3	2	1	0		
CDETI	EORI	EOCI	EOFI	WFRI	HFRI	EOBI	-		
Bit Number	Bit Mnemonic	Description							
7	CDETI	Card Detect Set by hardw Cleared whe	Card Detection Interrupt Flag Set by hardware every time CDET bit in MMSTA is toggling. Cleared when reading MMINT.						
6	EORI	End of Resp Set by hardw Cleared whe	oonse Interru vare at the en n reading MM	pt Flag d of response IINT.	reception.				
5	EOCI	End of Com Set by hardw Cleared whe	End of Command Interrupt Flag Set by hardware at the end of command transmission. Cleared when reading MMINT.						
4	EOFI	End of Fram Set by hardw Clear when r	the Interrupt F ware at the end reading MMIN	f lag d of frame (stro T.	eam, single bl	ock or multi bl	ock) transfer.		
3	WFRI	Whole FIFO Set by hard transmit mod Cleared whe	Ready Intern ware when 1 le. n reading MM	r upt Flag 6 bytes can IINT.	be read in r	eceive mode	or written in		
2	HFRI	Half FIFO Ready Interrupt Flag Set by hardware when 8 bytes can be read in receive mode or written in transmit mode. Cleared when reading MMINT.							
1	EOBI	End of Bloc Set by hardw Cleared whe	End of Block Interrupt Flag Set by hardware at the end of block (single block or multi block) transfer. Cleared when reading MMINT.						
0	-	Reserved The value re	ad from this b	it is always 0.	Do not set thi	s bit.			

Reset Value = 0000 0000b

Table 228. MMMSK Register

MMMSK (1.BFh) - MMC Interrupt Mask Register

7	6	5	4	3	2	1	0		
МСВМ	EORM	EOCM	EOFM	WFRM	HFRM	EOBM	-		
Bit Number	Bit Mnemonic	Description	Description						
7	CDETM	Card Detect Set to prever Clear to allow	i on Interrupt nt CDETI flag v CDETI flag t	Mask Bit from generation to generate ar	ng an interrup n interrupt.	t.			

Bit Number	Bit Mnemonic	Description
6	EORM	End Of Response Interrupt Mask Bit Set to prevent EORI flag from generating an interrupt. Clear to allow EORI flag to generate an interrupt.
5	EOCM	End Of Command Interrupt Mask Bit Set to prevent EOCI flag from generating an interrupt. Clear to allow EOCI flag to generate an interrupt.
4	EOFM	End Of Frame Interrupt Mask Bit Set to prevent EOFI flag from generating an interrupt. Clear to allow EOFI flag to generate an interrupt.
3	WFRM	Whole FIFO Ready Interrupt Mask Bit Set to prevent WFRI flag from generating an interrupt. Clear to allow WFRI flag to generate an interrupt.
2	HFRM	Half FIFO Ready Full Interrupt Mask Bit Set to prevent HFRI flag from generating an interrupt. Clear to allow HFRI flag to generate an interrupt.
1	EOBM	End Of Block Interrupt Mask Bit Set to prevent EOBI flag from generating an interrupt. Clear to allow EOBI flag to generate an interrupt.
0	-	Reserved The value read from this bit is always 0. Do not set this bit.

Reset Value = 1111 1110b

Table 229. MMCMD Register

MMCMD (1.B7h) – MMC Command Register

7	6	5	4	3	2	1	0
MC7	MC6	MC5	MC4	MC3	MC2	MC1	MC0
Bit Number	Bit Mnemonic	Description					
7-0	MC7:0	MMC Comm Output (read MMC Comm Input (write)	and Receive) register of th and Transmi register of the	e Byte ne response F i t Byte e command FI	IFO. FO.		

Reset Value = 1111 1111b

Table 230. MMDAT Register

MMDAT (1.B6h) - MMC Data Register

7	6	5	4	3	2	1	0
MD7	MD6	MD5	MD4	MD3	MD2	MD1	MD0
Bit Number	Bit Mnemonic	Description					
7-0	MD7:0	MMC Data B Input (write)	o yte or output (read	d) register of t	he data FIFO.		

Reset Value = 1111 1111b





Parallel Slave Interface

The AT85C51SND3B derivatives implement a Parallel Slave Interface (PSI) allowing parallel connection with a host for remote control and data transfer. By using this interface, the AT85C51SND3B can be seen as a multimedia co-processor and be remotely controlled by the host.

The main features of the PSI Interface are:

- ARM / I80 glueless interface capability
- 8-bit parallel data bus
- 1-bit address bus
- 16-byte FIFO with MCU interrupt capability
- · Bi-directional multimedia bus connection through one DFC Channel

Figure 98 shows a typical PSI host connection. Interface consists in a 8-bit data bus, a 1-bit address bus and read and write signals along with a chip select.

Figure 98. Typical PSI Host Connection



Note: 1. Optional signal for slave to host signaling.

Description

The C51 core interfaces with the PSI using the following Special Function Registers: PSICON (see Table 232) the control register, PSISTA (see Table 233) the status register, PSIDAT (see Table 234) the data register and PSISTH (see Table 235) the host status register.

The PSI is enabled by setting the PSEN bit in PSICON.

As soon as the PSI is enabled, I/O ports are programmed in input and I/O pull-ups are disabled.





PSI Addressing

The AT85C51SND3B are accessible by a host in read or write at two different address locations by setting or clearing the SA0 address signal. The data management is

detailed in following sections and differs depending on SA0 level. Table 235 shows the addressing truth table. Figure 100 and Figure 101 show the read and write host cycles.

 Table 231.
 PSI Addressing Truth Table

SA0	SRD / SWR	Selection
1	Read	Host reads the PSISTH register to get PSI status from both hardware and software.
1	Write	Host writes in the FIFO.
0	Read	DFC transfer (PSI is destination) Host reads data from the source peripheral through the FIFO. CPU transfer Host reads data from the FIFO.
0	Write	DFC transfer (PSI is source) Host writes data to the destination peripheral through the FIFO. CPU transfer Host writes data in the FIFO.

Figure 100. Host Read Waveforms



Figure 101. Host Write Waveforms



Write Data Sampling

In order to be compliant with hosts depending on write cycle timing, a delay from SRW signal assertion can be programmed for sampling data written by the host. This delay is programmable from 0 to 7 peripheral clock periods using PSWS2:0 bits in PSICON. Figure 102 shows the write sampling delay waveform.

Depending on the system clock frequency, host may need to add wait states inside read or write cycles.









"SA0= H" Mode

The "SA0= H" mode is particularly fitting control management over a protocol. Figure 103 shows a data cycle from host to device. Prior to send any data bytes, the host must take care of the PSI state by reading the AT85C51SND3B with SA0 signal set. This returns PSISTH: the host status register content. While PSHBSY bit in PSISTH is set, the host must not start sending data.

As soon as PSHBSY bit is released, the host can send up to 16 bytes of data.

First data writing automatically sets PSBSY flag in PSISTA and consequently PSHBSY bit so that host knows that system is now busy and processing. An interrupt can be generated when PSBSY flag is set by enabling PSBSYE bit in PSICON while global PSI interrupt is enabled in IEN1 (see Figure 104).

The software can start reading and process the data after first byte reception. As soon as data processing is done, PSBSY flag is cleared and consequently PSHBSY bit so that host knows that system has finished processing. A software status can have been previously written to PSISTH for reporting to the host.

Note: If software reading is quicker than host writing, PSEMPTY bit must be polled before reading new data byte.

Figure 103. Data Management (SA0 = H)



"SA0= L" Mode	The "SA0= L" mode is particularly fitting data transfer with huge amount of data. Trans-
	fer can be done in read and write using the DFC for high throughput or the CPU. After
	control processing (PSBSY cleared) and relying to the protocol, the host starts transfer-
	ring data. In all cases the host which is the master controls the data transfer by reading from or writing to the slave.

CPU Transfer In case of transfer handled by the CPU, the data transfer is done byte by byte. As the host runs usually quicker than the slave, a software handshake must be established to avoid underrun or overrun condition.

DFC Transfer

In case of transfer handled by the DFC, the slave can acknowledge its control processing (PSBSY cleared) as soon as destination (host write) or source (host read) is ready.

Host can then read or write by burst an amount of data defined by the protocol (see Section "Data Flow Controller", page 78).

In order to avoid any underrun or overrun condition during burst transfer, host must be slower than the DFC destination peripheral (host write) or the DFC source peripheral (host read).

Overrun - Underrun Conditions An overrun condition occurs when the hosts writes data quicker than the slave can consume it.

An underrun condition occurs when the host read data quicker than the slave can deliver it.

As soon as one of these two conditions is triggered, the PSRUN flag in PSISTA is set. An interrupt can be generated when PSRUN bit is set by enabling PSRUNE bit in PSI-CON while global PSI interrupt is enabled in IEN1 (see Figure 104).

- Notes: 1. Overrun and underrun conditions may appear in both transfer modes (CPU or DFC).2. In overrun condition, the data written by the host is discarded.
 - 3. In underrun condition, the data read by the host is the same as the previous one.

Interrupts As shown in Figure 104, the PSI implements two interrupt sources reported in PSBSY and PSRUN flags in PSISTA. These flags are detailed in the previous sections.

These sources are enabled separately using PSBSYE, and PSRUNE enable bits respectively in PSICON.

The interrupt request is generated each time an enabled flag is set, and the global PSI interrupt enable bit is set (EPSI in IEN1 register).

Figure 104. PSI Controller Interrupt System







Registers

Table 232. PSICON Register

PSICON (1.ADh) - PSI Control Register

7	6	5	4	3	2	1	0		
PSEN	PSBSYE	PSRUNE	PSWS2	PSWS1	PSWS0	-	-		
Bit Number	Bit Mnemonic	Description	escription						
7	PSEN	Interface En Set to enable Clear to disa	erface Enable Bit t to enable the PSI controller. ear to disable the PSI controller.						
6	PSBSYE	Busy Interru Set to enable Clear to disa	3usy Interrupt Enable Bit Set to enable the busy interrupt. Clear to disable the busy interrupt.						
5	PSRUNE	Overrun/Un Set to enable Clear to disa	derrun Interr e the overrun i ble the overru	upt Enable Bi interrupt. in interrupt.	it				
4-2	PSWS2:0	Write Samp Data write sa clock periods	Write Sampling Bits Data write sampling wait states after $\overline{\text{WR}}$ signal assertion from 1 clock up to 7 clock periods						
1-0	-	Reserved The value re	ad from these	bits is always	0. Do not set	these bits.			

Reset Value = 0000 0000b

Table 233. PSISTA Register

PSISTA (1.AEh) – PSI Status Register

7	6	5	4	3	2	1	0			
PSEMPTY	PSBSY	PSOVR	PSRDY	-	-	-	-			
Bit Number	Bit Mnemonic	Description	Description							
7	PSEMPTY	FIFO Empty Set by hardw Cleared by h	FO Empty Flag et by hardware when the FIFO is empty. eared by hardware when at least one data byte is present in the FIFO.							
6	PSBSY	Busy Flag Set by hardv SA0 = H). Can be set o	Busy Flag Set by hardware when the FIFO becomes not empty (host has sent data with SA0 = H). Can be set or cleared by software.							
5	PSRUN	Overrun/Un Overrun Set by hardw Clear by soft Underrun Set by hardw Clear by soft	Overrun/Underrun Flag Overrun Set by hardware when the host sends a data and the FIFO is full. Clear by software to acknowledge the overrun condition. Underrun Set by hardware when the host reads a data and the FIFO is empty. Clear by software to acknowledge the underrun condition.							
4	PSRDY	Ready Flag Set by hardw Cleared by h	Clear by software to acknowledge the underrun condition. Ready Flag Set by hardware when a data is ready to be sent to the host. Cleared by hardware at the end of a host read cycle.							

Bit Number	Bit Mnemonic	Description
3-0	-	Reserved The value read from these bits is always 0. Do not set these bits.

Reset Value = 1000 0000b

Table 234. PSISTH Register

PSISTH (1.ACh) – PSI Host Status Register

7	6	5	4	3	2	1	0
PSHBSY	PSSTH6	PSSTH5	PSSTH4	PSSTH3	PSSTH2	PSSTH1	PSSTH0
Bit Number	Bit Mnemonic	Description					
7	PSHBSY	Interface Bu Host Access Copy of the F Software Ac Always return Can not be w	sy Flag s (Read with PSBSY flag. cess ned as logic 0 vritten by softw	SA0 = H) vare.			
6-0	PSSTH6:0	7-bit Host St Set by softwa	t atus Data are to report s	tatus to the ho	ost.		

Reset Value = 0000 0000b

Table 235. PSIDAT Register

PSIDAT (1.AFh) - PSI Data Register

7	6	5	4	3	2	1	0
PSD7	PSD6	PSD5	PSD4	PSD3	PSD2	PSD1	PSD0
Bit Number	Bit Mnemonic	Description					
7-0	PSD7:0	Data Bits Reading this register returns the data written by the host in the FIFO. Writing this register set data in the FIFO read later by the host.					





Serial I/O Port

The AT85C51SND3B derivatives implement a Serial Input/Output Port (SIO) allowing serial communication. By using this interface, the AT85C51SND3B can be seen as a multimedia co-processor and be remotely controlled by the host.

The main features of the SIO Interface are:

- Asynchronous mode (UART: Rx, Tx)
- Hardware flow control (CTS, RTS)
- High speed baud rate generator
- 16-byte input buffer with MCU interrupt capability
- · Bi-directional multimedia bus connection through one DFC Channel

Figure 105 shows a typical SIO host connection. Interface consists in a 2-bit receive/transmit bus and a 2-bit flow control bus.

Figure 105. Typical SIO Host Connection



DescriptionThe C51 core interfaces with the SIO using the following Special Function Registers: SCON, the SIO Control register (see Table 243); SFCON, the SIO Flow Control register (see Table 244); SINT, the SIO Interrupt Source register (see Table 245); SIEN, the SIO Interrupt Enable register (see Table 246); SBUF, the SIO Buffer register (see Table 247); SBRG0, SBRG1 and SBRG2, the SIO Baud Rate Generator registers (see Table 248 to Table 250). As shown in Figure 106 the SIO is based on three main functional blocks detailed in the following sections: the baud rate generator that generates an oversampling clock for both receiver and transmitter, the receiver that handles the characters reception and the transmitter that handles the characters transmission.

Data Transfer

The data transfers can be handled completely by the C51 in full duplex, i.e. C51 manages character transmission by writing data to SBUF register and character reception by reading data from SBUF. It is obvious that using C51 for data transfer leads to low throughput. In order to increase throughput and take advantage of high bit rates up to 8Mbit/s, a DFC channel can be associated to the SIO in read or write (see Section "Data Flow Controller", page 78). DFC can be used used for data reception (SIO considered as source) or data transmission (SIO considered as destination). In both cases, the data transfer is still full duplex since C51 continues to handle transmission or reception but at lower throughput.

Table 236 summarizes the data transfer modes association. DFC usage is enabled as soon as a DFC transfer is enabled by selecting SIO as source or destination.

Table 236. Data Transfer Mod

Transfer Modes	Reception Handling	Transmission Handling	
High Throughput Reception	DFC (SIO is source)	C51	
High Throughput Transmission	C51	DFC (SIO is destination)	
Low Throughput Transfer (default)	C51	C51	

Figure 106. SIO Block Diagram



Character Format

The character consists of five fields: start, data, parity, stop and guard fields. Figure 107 shows a character example with 8 data bits, 1 parity bit, 2 stop bits and 2 guard bits.

Figure 107. Character Format Example



Start Field The start field is fixed and composed of 1 bit transmitted or received at low level.

Data Field

The data field is composed of 7 or 8 bits by programming DLEN bit in SCON according

to Table 237. The least significant bit is always first transmitted.

Table 237. Data Bit Number Selection

DLEN	Description
0	7-bit Data Length.
1	8-bit Data Length.

Parity Field

The parity field is optional and enabled by PBEN bit in SCON. This field is composed of 1 bit and its mode is programmable by PMOD1:0 bits in SCON according to Table 238.

Table 238. Parity Mode Selection

PMOD1	PMOD0	Description
0	0	MARK: high Level
0	1	SPACE: Low Level
1	0	EVEN: High Level if the number of bits at high level in the data field is even.
1	1	ODD: Low Level if the number of bits at high level in the data field is odd.

Stop Field

The stop field is composed of 1 or 2 bits transmitted or received at high level by programming STOP bit in SCON according to Table 239.





Table 239. Stop Bit Number Selection

STOP	Description
0	1 Stop Bit.
1	2 Stop Bits.

Guard Field

The guard field is not part of a character and is an optional inter-character spacing composed of 0 to 3 bits transmitted at high level by programming GBIT1:0 bits in SCON according to Table 240. The guard field allows transmitter to be compliant with connected host (overrun avoiding) and is emitted after the last stop bit of a character.

Table 240. Guard Field Size Selection

GBIT1	GBIT0	Description
0	0	0 guard bit inserted (default).
0	1	1 guard bit inserted.
1	0	2 guard bits inserted.
1	1	3 guard bits inserted.

Baud Rate Generator The Baud Rate Generator is fed by the SIO clock as detailed in Section "SIO Clock Generator", page 33. The maximum baud rate can be achieved by selecting the high frequency issued by a division of the PLL clock. The clock generated is an oversampling clock. The oversampling factor is programmable using OVRSF3:0 bits in SFCON with oversampling factor equal to OVRSF3:0 + 1 (e.g.: OVRSF3:0= 11 for a 12x oversampling).

Baud Rate Calculation As shown in Figure 109, the baud rate generator is composed of an integer divider followed by a fractional divider. The baud rate formula is given by Figure 108. In this formula, variables must be chosen as followed:

– OVRSF

The oversampling factor depends mainly on the frequency and the quality of the medium transporting the data. In any case, OVSF3:0 must not be less than 4 for proper majority vote in bit reception.

ADIV Must be greater than BDIV and less than (K \cdot OVRSF). K being the number of bit in a character (from 9 to 11).

- BDIV

_

Must be greater than $1/\epsilon$ according to the tolerance on the real baud rate BR_R compare to the theoretical baud rate BR_T. ϵ being the error: $\epsilon = K \cdot |1/BB_T - 1/BR_R|$.

Table 241 shows some programming values depending on the SIO frequency and considering an oversampling factor of 12 (OVERSF3:0= 11).

Figure 108. Baud Rate Formula

 $Baud_Rate = \frac{F_{SIO} \cdot BDIV}{ADIV \cdot CDIV \cdot OVRSF}$




Table 241. Baud Rate Generator Value (12x oversampling)

Baud	F _{SIO} = 12 MHz			F _{SIO} = 16 MHz			F _{SIO} = 20 MHz			F _{SIO} = 24 MHz			ΛHz	F_{SIO} = 120 MHz ⁽¹⁾						
Rate	A	в	С	8 %	A	в	С	8 %	A	в	С	8 %	A	в	С	8 %	Α	В	С	8 %
9600	125	6	5	0	110	99	125	0	124	5	7	0.007	125	3	5	0	110	15	142	0.033
19200	125	12	5	0	125	9	5	0	124	10	7	0.007	125	6	5	0	110	49	232	0.004
38400	125	24	5	0	125	18	5	0	124	20	7	0.007	125	12	5	0	110	49	116	0.004
57600	125	36	5	0	125	27	5	0	124	30	7	0.007	125	18	5	0	124	5	7	0.007
115200	125	72	5	0	125	54	5	0	124	60	7	0.007	125	36	5	0	124	10	7	0.007
230400	115	53	2	0.016	125	108	5	0	120	83	5	0.067	125	72	5	0	217	5	1	0.007
460800	115	53	1	0.016	120	83	2	0.067	112	31	1	0.111	115	53	2	0.016	217	10	1	0.007
921600	115	106	1	0.016	120	83	1	0.067	112	62	1	0.111	115	53	1	0.016	118	87	8	0.002
1M	1	1	1	0	112	84	1	0	115	69	1	0	110	55	1	0	120	12	1	0
1.5M	-	-	-	-	-	-	-	-	110	99	1	0	112	84	1	0	120	18	1	0
2M	-	-	-	-	-	-	-	-	-	-	-	-	1	1	1	0	115	23	1	0
4M	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	115	46	1	0
8M	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	115	92	1	0

Note: 1. This high frequency available through the clock generator requires PLL usage. It is recommended to use it only for high baud rate that can not be achieved using oscillator frequency.





Receiver

As shown in Figure 110, the receiver is based on a character handler taking care of character integrity check and feeding the reception shift register filling itself a 16-byte data FIFO managed by the FIFO and flow controller.

Figure 110. Receiver Block Diagram



Flow Control

The reception flow can be controlled by hardware using the RTS pin. The goal of the flow control is to inform the external transmitter when the Rx FIFO is full of a certain amount of data. Thus the transmitter can stop sending characters. RTS usage and so associated flow control is enabled using RTSEN bit in SFCON.

To support transmitter that has stop latency, a threshold can be programmed to allow characters reception after RTS has been deasserted. The threshold can be programmed using RTSTH1:0 in SFCON according to Table 242. As soon as enough data has been read from the Rx FIFO, RTS is asserted again to allow transmitter to continue transmission. To avoid any glitch on RTS signal, an hysteresis on 1 data is implemented.

Figure 111 shows a reception example using a threshold of 4 data and a host transmitter latency of 3 characters.

Figure 111. Reception Flow Control Waveform Example



Table 242. RTS Deassertion Threshold

RTSTH1	RTSTH0	Description
0	0	RTS deasserted when Rx FIFO is full.
0	1	RTS deasserted when 2 data can still be loaded in Rx FIFO.
1	0	RTS deasserted when 4 data can still be loaded in Rx FIFO.
1	1	RTS deasserted when 8 data can still be loaded in Rx FIFO.

Receiver Errors	There are three kinds of errors that can be set during character reception: the framing error, the parity error, and the overrun error detailed in the following sections.					
Framing Error	A framing error occurs when the stop field of a received character is not at high level. Framing error is reported in FEI flag in SINT. Framing error condition is acknowledged by clearing the FEI flag.					
Parity Error	A parity error occurs when the parity field of a received character does not matches the programmed one in PMOD1:0 bits. Parity error is reported in PEI flag in SINT. Parity error condition is acknowledged by clearing the PEI flag.					
Overrun Error	An overrun error occurs when a character is received while the Rx shift register is full (Rx FIFO full). In this case, received character is discarded. Overrun error is reported in OEI flag in SINT. Overrun error condition is acknowledged by clearing the OEI flag.					
	Note: In case of data burst reception, the error flags report an error within the data burst. It is obvious to discard the whole data burst and to handle the errors by the protocol (retry).					
Transmitter	As shown in Figure 112, the transmitter is based on a character handler taking care of character transmission and fed by the transmission shift register filled itself by a 1-byte					

data FIFO managed by the FIFO and flow controller.

Figure 112. Transmitter Block Diagram



Flow Control	The transmission flow can be controlled by hardware using the $\overline{\text{CTS}}$ pin controlled by the external receiver. The goal of the flow control is to stop transmission when the receiver is full of data. $\overline{\text{CTS}}$ usage and so associated flow control is enabled using CTSEN bit in SFCON. The transmitter stop latency may vary from 0 to a maximum of 1 character, meaning that transmission always stops at the end of the character under transmission if any.
Interrupts	As shown in Figure 113, the SIO implements five interrupt sources reported in RI, TI, FEI, PEI, OEI and EOTI flags in SINT. These flags are detailed in the previous sections.
	These sources are enabled separately using RIE, TIE, FEIE, PEIE, OEIE and EOTIE enable bits respectively in SIEN.
	The interrupt request is generated each time an enabled source flag is set, and the glo- bal SIO interrupt enable bit is set (ES in IEN0 register).





Figure 113. SIO Controller Interrupt System



Registers

Table 243. SCON Register

SCON (0.91h) - SIO Control Register

7	6	5	4	3	2	1	0			
SIOEN	PMOD1	PMOD0	PBEN	STOP	DLEN	GBIT1	GBIT0			
Bit Number	Bit Mnemonic	Description								
7	SIOEN	SIO Enable Set to enable Clear to disa	SIO Enable Bit Set to enable the Serial Input/Output port. Clear to disable the Serial Input/Output port.							
6-5	PMOD1:0	Parity Mode Bits Refer to Table 238 for information on parity mode								
4	PBEN	Parity Bit Enable Bit Set to enable parity generation according to PMOD1:0 bits. Clear to disable parity generation.								
3	STOP	Stop Bit Number Set to enable generation of 2 stop bits. Clear to enable generation of 1 stop bit.								
2	DLEN	Data Length Bit Set to enable generation of 7 data bits. Clear to enable generation of 8 data bits.								
1-0	GBIT1:0	Guard Bit N Number of transmission	umber guard bits (f mode.	rom 0 to 3)	transmitted	after the las	t stop bit in			

Reset Value = 0000 0000b

Table 244. SFCON Register

SFCON (0.95h) - SIO Flow Control Register

7	6	5	4	3	2	1	0				
OVRSF3	OVRSF2	OVRSF1	OVRSF0	CTSEN	RTSEN	RTSTH1	RTSTH0				
Bit Number	Bit Mnemonic	Description	Description								
7-4	OVRSF3:0	Over Sampling Factor Bits Number of time a data bit is sampled for level determination. Oversampling factor = OVRSF3:0 + 1.									
3	CTSEN	Clear To ser Set to enable Clear to disa	Clear To send Enable Bit Set to enable transmission hardware flow control using CTS signal. Clear to disable transmission hardware flow control.								
2	RTSEN	Request To Set to enable Clear to disa	Request To send Enable Bit Set to enable reception hardware flow control using $\overline{\text{RTS}}$ signal. Clear to disable reception hardware flow control.								
1-0	RTSTH1:0	Request To Refer to Tabl	Request To send Assertion Threshold Refer to Table 242 for information on threshold values.								

Reset Value = 0000 0000b

Table 245. SINT Register

SINT (1.A8h) – SIO Interrupt Source Register

7	6	5	4	3	2	1	0				
-	-	EOTI	OEI	PEI	FEI	TI	RI				
Bit Number	Bit Mnemonic	Description	Description								
7	-	Reserved The value re	Reserved The value read from this bit is always 0. Do not set this bit.								
6	-	Reserved The value re	Reserved The value read from this bit is indeterminate. Do not set this bit.								
5	EOTI	End Of Transmission Interrupt Flag Set by hardware when both Tx FIFO and Tx shift register are empty: actual end of transmission. Cleared by hardware when the Tx FIFO or Tx shift register are not empty.									
4	OEI	Overrun Ree Set by hardw (Rx FIFO full Clear by soft	Overrun Reception Error Interrupt Flag Set by hardware when a character is received while the Rx shift register is full (Rx FIFO full). Clear by software to acknowledge interrupt.								
3	PEI	Parity Reception Error Interrupt Flag Set by hardware when a parity error occurs in a received character. Clear by software to acknowledge interrupt.									
2	FEI	Framing Re Set by hardw Clear by soft	ception Error vare when a fr ware to ackno	r Interrupt Fla raming error o owledge interro	ig ccurs in a rec upt.	eived characte	∋r.				





Bit Number	Bit Mnemonic	Description
1	ті	Transmission Interrupt Flag Set by hardware when the Tx FIFO is not full: a character can be loaded through SBUF. Cleared by hardware when the Tx FIFO becomes full: no more character can be loaded.
0	RI	Reception Interrupt Flag Set by hardware when the Rx FIFO is not empty: character ready to be read through SBUF. Cleared by hardware when the Rx FIFO becomes empty: no more character to be read.

Reset Value = 0X10 0010b

Table 246. SIEN Register

SIEN (1.A9h) – SIO Interrupt Enable Register

7	6	5	4	3	2	1	0				
-	-	EOTIE	OEIE	PEIE	FEIE	TIE	RIE				
Bit Number	Bit Mnemonic	Description	Description								
7-6	-	Reserved The value re	ad from these	bits is always	: 0. Do not set	these bits.					
5	EOTIE	End Of Tran Set to enable Clear to disa	nd Of Transmission Interrupt Enable Bit iet to enable end of transmission interrupt generation. Clear to disable end of transmission interrupt generation.								
4	OEIE	Overrun Err Set to enable Clear to disa	Overrun Error Interrupt Enable Bit Set to enable overrun error interrupt generation. Clear to disable overrun error interrupt generation.								
3	PEIE	Parity Error Set to enable Clear to disa	Parity Error Interrupt Enable Bit Set to enable parity error interrupt generation. Clear to disable parity error interrupt generation.								
2	FEIE	Framing Err Set to enable Clear to disa	Framing Error Interrupt Enable Bit Set to enable framing error interrupt generation. Clear to disable framing error interrupt generation.								
1	TIE	Transmissic Set to enable Clear to disa	Transmission Interrupt Enable Bit Set to enable transmission interrupt generation. Clear to disable transmission interrupt generation.								
0	RIE	Reception In Set to enable Clear to disa	Reception Interrupt Enable Bit Set to enable reception interrupt generation. Clear to disable reception interrupt generation.								

Reset Value = 0000 0000b

Table 247. SBUF Register

SBUF (1.AAh) – SIO Data Buffer Register

7	6	5	4	3	2	1	0
SIOD7	SIOD6	SIOD5	SIOD4	SIOD3	SIOD2	SIOD1	SIOD0
Bit Number	Bit Mnemonic	Description					

Reset Value = XXXX XXXXb

Table 248. SBRG0 Register

SBRG0 (0.92h) - SIO Baud Rate Generator Register 0

7	6	5	4	3	2	1	0	
CDIV7	CDIV6	CDIV5	CDIV4	CDIV3	CDIV2	CDIV1	CDIV0	
Bit Number	Bit Mnemonic	Description						
7-0	CDIV7:0	Baud Rate Generator 8-bit C divider.						

Reset Value = 0000 0000b

Table 249. SBRG1 Register

SBRG1 (0.93h) - SIO Baud Rate Generator Register 1

7	6	5	4	3	2	1	0				
ADIV7	ADIV6	ADIV5	ADIV4	ADIV3	ADIV2	ADIV1	ADIV0				
Bit Number	Bit Mnemonic	Description	Description								
7-0	ADIV7:0	Baud Rate Generator 8-bit A divider.									

Reset Value = 0000 0000b

Table 250. SBRG2 Register

SBRG2 (0.94h) – SIO Baud Rate Generator Register 2

7	6	5	4	3	2	1	0	
BDIV7	BDIV6	BDIV5	BDIV4	BDIV3	BDIV2	BDIV1	BDIV0	
Di+	Di+	Ì						
Number	Mnemonic	Description						
7-0	BDIV7:0	Baud Rate Generator 8-bit B divider.						

Reset Value = 0000 0000b



AMEL

Serial Peripheral Interface

The AT85C51SND3B derivatives implement a Synchronous Peripheral Interface (SPI) allowing full-duplex, synchronous, serial communication between the MCU and peripheral devices, including other MCUs.

Features of the SPI module include the following:

- Full-duplex, three-wire synchronous transfers
- Master or Slave operation
- Programmable Master clock rates in master mode
- · Serial clock with programmable polarity and phase
- · Master Mode fault error flag with MCU interrupt capability

Figure 114 shows a SPI bus configuration using the AT85C51SND3B as master connected to slave peripherals while Figure 115 shows a SPI bus configuration using the AT85C51SND3B as slave of an other master.

The bus is made of three wires connecting all the devices together:

 Master Output Slave Input (MOSI): it is used to transfer data in series from the master to a slave.

It is driven by the master.

 Master Input Slave Output (MISO): it is used to transfer data in series from a slave to the master.

It is driven by the selected slave.

• Serial Clock (SCK): it is used to synchronize the data transmission both in and out the devices through their MOSI and MISO lines. It is driven by the master for eight clock cycles which allows to exchange one byte on the serial lines.

Each slave peripheral is selected by one Slave Select pin (\overline{SS}). If there is only one slave, it may be continuously selected with \overline{SS} tied to a low level. Otherwise, the AT85C51SND3B may select each device by software through port pins (Pn.x). Special care should be taken not to select 2 slaves at the same time to avoid bus conflicts.







Figure 115. Typical Slave SPI Bus Configuration

Description

The SPI controller interfaces with the C51 core through three special function registers: SPCON, the SPI control register (see Table 252); SPSCR, the SPI status and control register (see Table 253); and SPDAT, the SPI data register (see Table 254). Data flow transfer can be fully handled by the C51 by writing and reading SPDAT or partially by the C51 and the DFC. The SPI controller implements only one DFC channel, meaning only reception flow or transmission flow can be handled by the DFC at a time. The Figure 116 summarizes the different data flow configuration allowed.

Figure 116. SPI Data Flow Configurations

- Data flow is fully handled by the CPU.
- Peripheral X is configured as source and SPI as destination of a DFC channel. CPU is still able to read incoming data (usually status) at its own rate.
- Peripheral X is configured as destination and SPI as source of a DFC channel. CPU is still able to output data (usually status) at its own rate.



Master Mode

The SPI operates in master mode when the MSTR bit in SPCON is set.

Note: The SPI Module should be configured as a master before it is enabled (SPEN set). In a system, the master SPI should be configured before the slave SPI device.

Figure 117 shows the SPI block diagram in master mode. Only a master SPI module can initiate transmissions.





The transmission begins by writing to SPDAT through CPU or DFC. Writing to SPDAT writes to an intermediate register which is automatically loaded to the shift register if no transmission is in progress. Reading SPDAT through CPU or DFC reads an intermediate register updated at the end of each transfer.

The byte begins shifting out on the MOSI pin under the control of the bit rate generator. This generator also controls the shift register of the slave peripheral through the SCK output pin. As the byte shifts out, another byte shifts in from the slave peripheral on the MISO pin. The byte is transmitted most significant bit (MSB) first when UARTM bit in SPCR is cleared or least significant bit (LSB) first when UARTM bit in SPCR is set. The end of transfer is signaled by SPIF being set.

In case SPI is the source of a DFC channel (slave device data read), SPDAT is first loaded with a dummy byte (FFh value) to initiate the transfer. Then transfer continues by transmitting the shift register content which is the last data received.

When the AT85C51SND3B is the only master on the bus, it can be useful not to use \overline{SS} pin and get it back to I/O functionality. This is achieved by setting SSDIS bit in SPCON.



Figure 117. SPI Master Mode Block Diagram

Note: MSTR bit in SPCON is set to select master mode.

Slave Mode

The SPI operates in slave mode when the MSTR bit in SPCON is cleared and data has been loaded in SPDAT.

Note: The SPI Module should be configured as a slave before it is enabled (SPEN set).

Figure 118 shows the SPI block diagram in slave mode. In slave mode, before a data transmission occurs, the SS pin of the slave SPI must be asserted to low level. SS must remain low until the transmission of the byte is complete. In the slave SPI module, data enters the shift register through the MOSI pin under the control of the serial clock provided by the master SPI module on the SCK input pin. When the master starts a transmission, the data in the shift register begins shifting out on the MISO pin. The end of transfer is signaled by SPIF being set.

When the AT85C51SND3B is the only slave on the bus, it can be useful not to use \overline{SS} pin and get it back to I/O functionality. This is achieved by setting SSDIS bit in SPCON. This bit has no effect when CPHA is cleared (see Section "SS Management", page 228).





Note: MSTR bit in SPCON is cleared to select slave mode.

In master mode, the bit rate can be selected from seven predefined bit rates using the SPR2, SPR1 and SPR0 control bits in SPCON according to Table 251. These bit rates are derived from the peripheral clock (F_{PER}) issued from the Clock Controller block as detailed in Section "Clock Controller", page 28.

In slave mode, the maximum baud rate allowed on the SCK input is limited to FOSC ÷ 4.

Table 251.	Serial Bit	Rates
------------	------------	-------

				Bit Rate (kHz) Vs F _{PER} (MHz)						
SPR2	SPR1	SPR0	6 ⁽¹⁾	8 ⁽¹⁾	10 ⁽¹⁾	12 ⁽¹⁾⁽²⁾	16 ⁽²⁾	20 ⁽²⁾	24 ⁽²⁾	F _{PER} Divider
0	0	0	3000	4000	5000	6000	8000	10000	12000	2
0	0	1	1500	2000	2500	3000	4000	5000	6000	4
0	1	0	750	1000	1250	1500	2000	2500	3000	8
0	1	1	375	500	625	750	1000	1250	1500	16
1	0	0	187.5	250	312.5	375	500	625	750	32
1	0	1	93.75	125	156.25	187.5	250	312.5	375	64
1	1	0	46.875	62.5	78.125	93.75	125	156.25	187.5	128
1	1	1	-	-	-	-	-	-	-	Reserved

Notes: 1. These frequencies are achieved in X1 mode, $F_{PER} = F_{OSC} \div 2$.

2. These frequencies are achieved in X2 mode, $F_{PER} = F_{OSC}$.



Bit Rate



Data Transfer

The Clock Polarity bit (CPOL in SPCON) defines the default SCK line level in idle state⁽¹⁾ while the Clock Phase bit (CPHA in SPCON) defines the edges on which the input data are sampled and the edges on which the output data are shifted (see Figure 119 and Figure 120).

For simplicity, Figure 119 and Figure 120 depict the SPI waveforms in idealized form and do not provide precise timing information. For timing parameters refer to the Section "AC Characteristics", page 247.

Note: 1. When the peripheral is disabled (SPEN = 0), default SCK line is high level.

Figure 119. Data Transmission Format (CPHA = 0, UARTM = 0)







SS Management

Figure 119 shows a SPI transmission with CPHA = 0, where the first SCK edge is the MSB capture point. Therefore the slave starts to output its MSB as soon as it is selected: SS asserted to low level. SS must then be de-asserted between each byte transmission (see Figure 121). SPDAT must be loaded with a data before SS is asserted again.

Note: In master mode, SPI transmission with CPHA = 0 is not allowed in case of DFC transfer.

Figure 120 shows a SPI transmission with CPHA = 1, where the first SCK edge is used by the slave as a start of transmission signal. Therefore, \overline{SS} may remain asserted between each byte transmission (see Figure 121). This format may be preferred in systems having only one master and only one slave driving the MISO data line.

Figure 121. SS Timing Diagram



Queuing Transmission For a SPI configured in master or slave mode, a queued data byte must be transmitted/received immediately after the previous transmission has completed.

When a transmission is in progress a new data can be queued and sent as soon as transmission has been completed. So it is possible to transmit bytes without latency, useful in some applications.

The SPTE bit in SPSCR is set as long as the transmission buffer is free. It means that the user application can write SPDAT with the next data to be transmitted until the SPTE becomes cleared.

Figure 122 shows a queuing transmission in master mode. Once the Byte 1 is ready, it is immediately sent on the bus. Meanwhile an other byte is prepared (and the SPTE is cleared), it will be sent at the end of the current transmission. The next data must be ready before the end of the current transmission.





In slave mode it is almost the same except it is the external master that starts the transmission. Also, in slave mode, if no new data is ready, the last value received will be the next data byte transmitted.

Error Conditions

The following flags in SPSCR register signal the SPI error conditions:

- MODF signals a mode fault condition.
- OVR signals an overrun condition.

Mode Fault in Master Mode

MODF is set to warn that there may be a multi-master conflict for system control. In this case, the SPI controller is affected in the following ways:

- a SPI receiver/error CPU interrupt request is generated
- the SPEN bit in SPCON is cleared. This disables the SPI





the MSTR bit in SPCON is cleared

Clearing the MODF bit is accomplished by reading SPSCR with MODF bit set, followed by a write to SPCON. SPI controller may be re-enabled (SPEN = 1) after the MODF bit is cleared.





Note: When \overline{SS} is disabled (SSDIS set) it is not possible to detect a MODF error in master mode because the SPI is internally unselected and the SS pin is a general purpose I/O.

Mode Fault in Slave ModeMODF error is detected when SS goes high during a transmission.A transmission begins when SS goes low and ends once the incoming SCK goes back
to its idle level following the shift of the eighth data bit.

A MODF error occurs if a slave is selected (\overline{SS} is low) and later unselected (\overline{SS} is high) even if no SCK is sent to that slave.

At any time, a '1' on the \overline{SS} pin of a slave SPI puts the MISO pin in a high impedance state and internal state counter is cleared. Also, the slave SPI ignores all incoming SCK clocks, even if it was already in the middle of a transmission. A new transmission will be performed as soon as SS pin returns low.

Figure 124. Mode Fault Conditions in Slave Mode



Note:

e: when \overline{SS} is disabled (SSDIS set) it is not possible to detect a MODF error in slave mode because the SPI is internally selected. Also the \overline{SS} pin becomes a general purpose I/O.

OverRun Condition	This error means that the speed is not adapted for the running application. An OverRun condition occurs when a byte has been received whereas the previous one has not been read by the application yet. The last byte (which generate the overrun error) does not overwrite the unread data so that it can still be read. Therefore, an overrun error always indicates the loss of data.
Interrupt	The SPI handles 3 interrupt sources that are the "end of transfer", the "mode fault" and the "transmit register empty" flags.
	As shown in Figure 125, these flags are combined together to appear as a single inter-

rupt source for the C51 core. The SPIF flag is set at the end of an 8-bit shift in and out and is cleared by reading SPSCR and then reading from or writing to SPDAT.

The MODF flag is set in case of mode fault error and is cleared by reading SPSCR and then writing to SPCON.

The SPTE flag is set when the transmit register is empty and ready to receive new data. When SPTE interrupt source is enabled, SPIF flag does not generate any interrupt.

The SPI interrupt is enabled by setting ESPI bit in IEN1 register. This assumes interrupts are globally enabled by setting EA bit in IEN0 register.

Figure 125. SPI Interrupt System



Registers

Table 252. SPCON Register

SPCON (1:91h) - SPI Control Register

7	6	5	4	3	2	1	0			
SPR2	SPEN	SSDIS	MSTR	CPOL	СРНА	SPR1	SPR0			
Bit Number	Bit Mnemonic	Description	Description							
7	SPR2	SPI Rate Bit Refer to Tabl	SPI Rate Bit 2 Refer to Table 251 for bit rate description.							
6	SPEN	SPI Enable I Set to enable Clear to disa	SPI Enable Bit Set to enable the SPI interface. Clear to disable the SPI interface.							
5	SSDIS	Slave Select Input Disable Bit Set to disable \overline{SS} in both master and slave modes. In slave mode this bit has n effect if CPHA = 0. Clear to enable \overline{SS} in both master and slave modes.								





Bit Number	Bit Mnemonic	Description
4	MSTR	Master Mode Select Set to select the master mode. Clear to select the slave mode.
3	CPOL	SPI Clock Polarity Bit Set to have the clock output set to high level in idle state. Clear to have the clock output set to low level in idle state.
2	СРНА	SPI Clock Phase Bit Set to have the data sampled when the clock returns to idle state (see CPOL). Clear to have the data sampled when the clock leaves the idle state (see CPOL).
1-0	SPR1:0	SPI Rate Bits 0 and 1 Refer to Table 251 for bit rate description.

Reset Value = 0001 0100b

Table 253. SPSCR Register

 $\label{eq:spscr} SPSCR \; (1.92h) - SPI \; Status \; and \; Control \; Register$

7	6	5	4	3	2	1	0		
SPIF	-	OVR	MODF	SPTE	UARTM	SPTEIE	MODFIE		
Bit Number	Bit Mnemonic	Description							
7	SPIF	SPI Interrup Set by hardw Cleared by acknowledge SPSCR.	SPI Interrupt Flag Set by hardware when an 8-bit shift is completed. Cleared by hardware to indicate data transfer is in progress or has been acknowledged by a clearing sequence: reading or writing SPDAT after reading SPSCR.						
6	-	Reserved The value re	Reserved The value read from this bit is indeterminate. Do not set this bit.						
5	OVR	Overrun Err Set by hard received dat Cleared by h	Overrun Error Flag Set by hardware when a byte is received whereas SPIF is set (the previous received data is not overwritten). Cleared by hardware when reading SPSCR.						
4	MODF	Mode Fault Set by hardw Cleared by h When MODF - In slave mo A new transr - In master r bit in SPCOI	Mode Fault Interrupt Flag Set by hardware to indicate that the SS pin is in inappropriate logic level. Cleared by hardware when reading SPSCR When MODF error occurred: - In slave mode: SPI interface ignores all transmitted data while SS remains high. A new transmission is perform as soon as SS returns low. - In master mode: SPI interface is disabled (SPEN=0, see description for SPEN bit in SPCON register)						
3	SPTE	Serial Perip Set by hard loaded with a Cleared by loaded in SP	Serial Peripheral Transmit register Empty Interrupt Flag Set by hardware when transmit register is empty (if needed, SPDAT can be loaded with another data). Cleared by hardware when transmit register is full (no more data should be loaded in SPDAT).						
2	UARTM	Serial Perip Set to select Clear to sele	ierial Peripheral UART mode ierial Peripheral UART mode iet to select UART mode: data is transmitted LSB first. Clear to select SPI mode: data is transmitted MSB first.						

Bit Number	Bit Mnemonic	Description
1	SPTEIE	SPTE Interrupt Enable Bit Set to enable SPTE interrupt generation. Clear to disable SPTE interrupt generation.
0 MODFIE		MODF Interrupt Enable Bit Set and cleared by software: - Set to enable MODF interrupt generation - Clear to disable MODF interrupt generation

Reset Value = 0000 1000b

Table 254. SPDAT Register

SPDAT (1:93h) – Synchronous Serial Data Register

7	6	5	4	3	2	1	0
SPD7	SPD6	SPD5	SPD4	SPD3	SPD2	SPD1	SPD0
Bit Number	Bit Mnemonic	Description					
7-0	SPD7:0	Synchronou	is Serial Data	ı.			

Reset Value = XXXX XXXXb





Display Interface

The AT85C51SND3B derivatives implement a display interface allowing glueless direct interfacing (thanks to its highly configurable capability) to almost all of the LCD controllers found in either graphic or text LCD display.

These LCD controllers interface is from either 6800 or 8080 compatible type with some variant in the implementation.

The display interfaces to the C51 core through the following special function registers: LCDCON0, LCDCON1, the LCD control registers (see Table 256 and Table 257); LCD-STA, the LCD status register (see Table 258); LCDBUM, the LCD busy mask register (see Table 259); and LCDDAT, the LCD data register (see Table 260).

As shown in Figure 126, the Display Interface is divided in two major blocks: the Access Cycle Generator which generates read or write cycles to the LCD controller, and the Busy Check Processor which enables automatic busy checking after any read or write cycles.





Configuration

Interface Enable

Interface Selection

Setting LCEN bit in LCDCON1 enables the display interface. When this bit is cleared, all signals to the controller are switch back to I/O port alternate function. Thus after reset, all signals are set to high level.

The display interface is programmed in 6800 type or 8080 type by setting or clearing the LCIFS bit LCDCON0. Table 255 shows the pin configuration depending on the interface selected.

Table 255. Pin Configuration vs. LCD Controller Interface Type (6800/8080)

Pin Name	8080 Type Controller	6800 Type Controller
LWR/LRW	WR	RW
LRD/LDE	RD	E
LA0/LRS	A0	RS
LCS	CS	CS
LD7:0	D7:0	D7:0

Access Cycles

The AT85C51SND3B enables connection of LCD controller with normalized 6800 and 8080 interface as shown in Figure 127 and Figure 128, but also enables connection of LCD controller with non normalized 6800 and 8080 interface as shown in Figure 129 and Figure 130.

This is achieved by setting or clearing CYCT bit in LCDCON1 for selecting non normalized or normalized access type.









Figure 129. 6800 Special Type Access Cycle



Figure 130. 8080 Special Type Access Cycle



Timings Configuration As detailed in Figure 131, access cycle timing can be configured to comply with the LCD controller specification. These timing parameters are:

- Address set-up time
- Access width time
- Address hold time
- Sleep Wait time

Address Set-Up and Hold Time The address set-up and hold time can be programmed by ADSUH1:0 bits in LCDCON0 from 1 oscillator clock period up to 4 oscillator clock periods. These timing are not dissociated and must be programmed to the highest time value of the set-up and hold time parameters.

Access Width Time The access width time can be programmed by ACCW3:0 bits in LCDCON0 from 1 oscillator clock period up to 16 oscillator clock period.





Sleep Wait Time	The sleep wait time is the time between two consecutive access cycle. It can be pro- grammed by SLW1:0 bits in LCDCON1 from 1 oscillator clock period up to 4 oscillator clock periods
Full Access Cycle Time	The full access cycle time can be computed by adding the address set-up time, the access width time, the address hold time and the sleep wait time. However, some LCD controller may require that the inactive state of the selection signal being equal to the access width time. In such case, LCYCW bit in LCDCON1 must be set.
	Figure 131. Full Access Cycle Timing
	Address Select
Automatic Busy Process	An automatic busy check process can be enabled after any read or write access to the LCD controller to verify this one is ready to execute next instruction.
	Busy check configuration uses BUINV bit in LCDCON0, BUM7:0 data in LCDBUM and RSCMD bit in LCDCON1. RSCMD is used to program the address of the status register (L or H depending on the LCD controller) during the status read cycle.
	The busy process performs reads of the LCD controller status register until all relevant busy bits are deasserted (i.e. controller ready). Relevant bits are selected by the BUM7:0 bits set. And busy asserted level is programmed by BUINV, set this bit when busy bit(s) are asserted low, clear it otherwise. When LCDBUM is reset (i.e. all bits cleared), no busy check is performed.
Busy Report	The busy state report is done by the LCBUSY flag in LCDSTA. LCBUSY is set at the beginning of any read or write cycles and cleared at the end of any access cycle (after the sleep wait time) when the automatic busy check process is disabled or at the end of the first LCD controller ready status read cycle (after the sleep wait time) when the automatic busy check process is enabled. LCBUSY flag must be checked before performing any read or write cycle to the LCD controller.
Read / Write Operation	LCD controllers have two registers, the display data register and instruction/status register. To determine which register will be accessed, LCRS bit in LCDCON1 must be configured according to the LCD controller.
Write Access	While the display interface is enabled, writing a data to LCDDAT launches a write cycle to the LCD controller according to the programmed configuration.
Read Access	While the display interface is enabled, setting LCRD bit in LCDCON1 launches a read cycle to the LCD controller according to the programmed configuration. At the end of the read cycle, including busy time, data can be retrieved by reading LCDAT. Reading LCDAT automatically relaunches a new read cycle to the LCD controller allowing continuous read of data.

Registers

Table 256. LCDCON0 Register

LCDCON0 (1.96h) - LCD Control Register 0

7	6	5	4	3	2	1	0		
BUINV	LCIFS	ADSUH1	ADSUH0	ACCW3	ACCW2	ACCW1	ACCW0		
Bit Number	Bit Mnemonic	Description							
7	BUINV	Busy Invert Set to check Clear to chec	Busy Invert Active Set to check busy bits selected in LCDBUM as active low. Clear to check busy bits selected in LCDBUM as active high.						
6	LCIFS	Interface Se Set to select Clear to sele	Interface Select Bit Set to select 6800 interface type. Clear to select 8080 interface type.						
5-4	ADSUH1:0	Address Set Address Set	Address Setup/Hold Address Setup and hold length in clock periods (from 1 to 4 clock periods).						
3-0	ACCW3:0	Access Cyc Access width In 8080 mod In 6800 mod	Access Cycle Width Access width in clock periods (from 1 to 16 clock periods). In 8080 mode, corresponds to WR or RD low state. In 6800 mode, corresponds to E high state.						

Reset Value= 0000 0000b

Table 257. LCDCON1 Register

LCDCON1 (1.8Eh) - LCD Control Register 1

7	6	5	4	3	2	1	0
SLW1	SLW0	RSCMD	LCYCW	LCYCT	LCEN	LCRD	LCRS
Bit Number	Bit Mnemonic	Description					
7-6	SLW1:0	Sleep Wait S Busy check Number of w. (from 1 to 4 c Busy check Number of w periods).	bitates process ena ait states betw clock periods) process disa rait states be	bled ween a read o a bled tween two rea	r write access ad or write ac	and a busy cl	heck process 1 to 4 clock
5	RSCMD	RS Commar Set to output Clear to outp This value de	nd/Status high level on ut low level o epends on the	LA0/LRS pin n LA0/LRS pir e LCD controlle	during busy c a during busy er.	heck process. check process	3.
4	LCYCW	Deassertion Set to progra in ACCW3:0 Clear to let E ADSUH1:0 +	Cycle Width m E or RD/W bits. or RD/WR s SLW1:0.	IR signals dea Signals deasse	assertion time ertion time to	to the numbe the number o	r of clock set f clock set in





Bit Number	Bit Mnemonic	Description
3	LCYCT	Cycle Type Selection Set to select non normalized access cycles (6800 or 8080 interface). Clear to select normalized access cycles (6800 or 8080 interface).
2	LCEN	LCD Interface Enable Set to enable the LCD Interface. Clear to disable the LCD Interface.
1	LCRD	LCD Read Command Set to initiate a read data or status register from LCD controller. Cleared by hardware at the end of read.
0	LCRS	LCD Register Select Set to output high level on LA0/LRS pin during next read or write access. Clear to output low level on LA0/LRS pin during next read or write access. This value depends on the LCD controller.

Reset Value= 0000 0000b

Table 258. LCDSTA Register

LCDSTA (1.8Fh) – LCD Status Register

7	6	5	4	3	2	1	0
-	-	-	-	-	-	-	LCBUSY
Bit Number	Bit Mnemonic	Description					
7:1	-	Reserved The value rea	ad from these	bits is always	0. Do not set	these bits.	
0	LCBUSY	Busy Flag Set by hard controller is b	ware during busy if busy cl	any access neck process i	to the LCD is enabled.	controller and	d while LCD

Reset Value= 0000 0000b

Table 259. LCDBUM Register

LCDBUM (1.8Dh) - LCD Busy Mask Register

7	6	5	4	3	2	1	0
BUM7	BUM6	BUM5	BUM4	BUM3	BUM2	BUM1	BUM0
Bit Number	Bit Mnemonic	Description					
7:0	BUM7:0	Busy Mask Set bits to be check proces Clear all bits	e checked dur s. to disable the	ing the busy o busy check p	check process process.	and thus ena	able the busy

Reset Value= 0000 0000b

Table 260. LCDDAT Register

LCDDAT (1.97h) - LCD Data Register

7	6	5	4	3	2	1	0
LD7	LD6	LD5	LD4	LD3	LD2	LD1	LD0
Bit Number	Bit Mnemonic	Description					
7:0	LD7:0	LCD Data By Reading a da	/te ata automatica	ally initiates a r	new read cycl	e to the LCD o	controller.

Reset Value= 0000 0000b





Keyboard Interface

The AT85C51SND3B derivatives implement a keyboard interface allowing the connection of a 4 x n matrix keyboard. It is based on 4 inputs with programmable interrupt capability on both high or low level. These inputs are available as alternate function of P1.3:0 and allow exit from idle and power down modes.

Description The keyboard interfaces with the C51 core through 2 special function registers: KBCON, the keyboard control register (see Table 261); and KBSTA, the keyboard control and status register (see Table 262).

The keyboard inputs are considered as 4 independent interrupt sources sharing the same interrupt vector. An interrupt enable bit (EKB in IEN1 register) allows global enable or disable of the keyboard interrupt (see Figure 132). As detailed in Figure 133 each keyboard input has the capability to detect a programmable level according to KINL3:0 bit value in KBCON register. Level detection is then reported in interrupt flags KINF3:0 in KBSTA register.

A keyboard interrupt is requested each time one of the four flags is set, i.e. the input level matches the programmed one. Each of these four flags can be masked by software using KINM3:0 bits in KBCON register and is cleared by reading KBSTA register. This structure allows keyboard arrangement from 1 by n to 4 by n matrix and allows usage of KIN inputs for any other purposes.









Power Reduction Modes

KIN3:0 inputs allow exit from idle and power-down modes as detailed in Section "Power Reduction Mode", page 21. To enable power-down mode exit, KPDE bit in KBSTA register must be set.

Due to the asynchronous keypad detection in power down mode (all clocks are stopped), exit may happen on parasitic key press. In this case, no key is detected and software returns to power down again.

Registers

Table 261. KBCON Register

KBCON (0.A3h) – Keyboard Control Register

7	6	5	4	3	2	1	0
KINL3	KINL2	KINL1	KINL0	KINM3	KINM2	KINM1	KINMO
Bit Number	Bit Mnemonic	Description					
7-4	KINL3:0	Keyboard Input Level Bit Set to enable a high level detection on the respective KIN3:0 input. Clear to enable a low level detection on the respective KIN3:0 input.					
3-0	KINM3:0	Keyboard In Set to prever Clear to allow	put Mask Bit Int the respection In the respection	t ve KINF3:0 fla ve KINF3:0 fla	ag from genera Ig to generate	ating a keyboa a keyboard in	ard interrupt. Iterrupt.

Reset Value = 0000 1111b

Table 262. KBSTA Register

KBSTA (0.A4h) - Keyboard Control and Status Register

7	6	5	4	3	2	1	0
KPDE	KDCPE	KDCPL	-	KINF3	KINF2	KINF1	KINF0
Bit Number	Bit Mnemonic	Description					
7	KPDE	Keyboard Po Set to enable Clear to disa	ower Down E e exit of power ble exit of pow	Enable Bit r down mode l ver down mod	by the keyboa e by the keyb	rd interrupt. oard interrupt.	
6	KDCPE	Keyboard D Set to conne Clear to isola	CPWR Pin En ct DCPWR pi tte DCPWR p	nable n on KIN0 inpu in from KIN0 in	ut. nput.		
5	KDCPL	Keyboard D Set by hardw	CPWR Pin Li	i ne esent the level	on DCPWR i	nput.	
4	-	Reserved The value rea	ad from this b	it is always 0.	Do not set thi	s bit.	
3-0	KINF3:0	Keyboard In Set by hardw Cleared whe	put Interrupt vare when the n reading KB	t Flag respective KI STA.	N3:0 input det	tects a progra	mmed level.

Reset Value = 0010 0000b





Electrical Characteristics

Absolute Maximum Rating

Storage Temperature65 to +150 °C	*NOTICE: Stressing the device beyond the "Absolute Maxi-
Voltage on any other Pin to V_{SS}	These are stress ratings only. Operation beyond
I _{OL} per I/O Pin 5 mA	the "operating conditions" is not recommended and extended exposure beyond the "Operating
Power Dissipation 1 W	Conditions" may affect device reliability.
Operating Conditions	
Ambient Temperature Under Bias40 to +85°C	
V _{DD} TBD V	

DC Characteristics

Digital Logic

Table 263. Digital DC Characteristics

IOV_{DD} = 1.65 to 3.6	V; T _A = -40 to +85 ℃
--------------------------	----------------------------------

Symbol	Parameter	Min	Typ ⁽¹⁾	Мах	Units	Test Conditions
VIL	Input Low Voltage	-0.5		0.25·IOV _{DD}	V	
V _{IH1}	Input High Voltage (except X1)	0.65·IOV _{DD}		IOV _{DD} +0.5	V	
V _{IH2}	Input High Voltage (X1)	0.7·IOV _{DD}		IOV _{DD} +0.5	V	
V _{OL}	Output Low Voltage			0.4	V	I _{OL} = 3 mA
V _{OH1}	Output High Voltage (P0, P1, P2, P3, P4, P5)	IOV _{DD} -0.7			V	Ι _{ΟΗ} = -30 μΑ
V _{OH2}	Output High Voltage (NFD7:0, NFALE, NFCLE, NFRE, NFWE, NFCE3:0, LD7:0, SDCMD, SDLCK, SDDAT3:0, RXD, TXD, MISO, MOSI, RTS, LCS, LA0/LRS, LRD/LDE, LWR/LRW, SCS, SRD, SWR, SA0, OCLK, DCLK, DDAT, DSEL)	IOV _{DD} -0.7			>	I _{OH} = -3 mA
I _{IL}	Logical 0 Input Current (P0, P1, P2, P3, P4, P5)			-50	μA	V _{IN} = 0.4 V
I _{LI}	Input Leakage Current (NFD7:0, NFALE, NFCLE, NFRE, NFWE, NFCE0)			10	μΑ	$0 < V_{IN} < V_{DD}$
I _{TL}	Logical 1 to 0 Transition Current (P0, P1, P2, P3, P4 and P5)			-650	μA	V _{IN} = 1.0 V V _{IN} = 2.0 V
R _{RST}	RST Pull-Up Resistor	10	16	21	kΩ	
C _{IO}	Pin Capacitance		10		pF	T _A = 25°C

Notes: 1. Typical values are obtained at T_A = 25°C. They are not tested and there is no guarantee on these values.

Oscillator & Crystal

Schematic

Figure 134. Crystal Connection



Note: For operation with most standard crystals, no external components are needed on X1 and X2. It may be necessary to add external capacitors on X1 and X2 to ground in special cases (max 10 pF).

Parameters

Table 264. Oscillator & Crystal Characteristics

V_{DD} = 1.65 to 3.6 V; T_A = -40 to +85 ℃

Symbol	Parameter	Min	Тур	Max	Unit
C _{X1}	Internal Capacitance (X1 - VSS)		10		pF
C _{X2}	Internal Capacitance (X2 - VSS)		10		pF
CL	Equivalent Load Capacitance (X1 - X2)		5		pF
DL	Drive Level			50	μW
F	Crystal Frequency ⁽¹⁾	12		24	MHz
RS	Crystal Series Resistance			40	Ω
CS	Crystal Shunt Capacitance			6	pF

Notes: 1. Authorized crystal frequencies are 12, 16, 20 and 24 MHz

2. Authorised input frequencies are 12, 13, 16, 19.2, 19.5, 20, 24 and 26MHz

DC to DC Convertor

Schematic

Figure 135. Battery DC-DC Connection





- Notes: 1. Mandatory connection if DC-DC is used.
 - 2. Depending on power supply scheme, $\rm C_{\rm DC1}$ may replace $\rm C_{\rm LV}$ capacitor (see Figure 136).





Parameters

Table 265. DC-DC Filter Characteristics

T_A = -40 to +85 ℃

Symbol	Parameter	Min	Тур	Max	Unit
L _{DC}	DC-DC Inductance		10		μH
C _{DC1}	Low ESR Decoupling Capacitor		20		μF
C _{DC2}	Low ESR Decoupling Capacitor		100		nF

Table 266. DC-DC Power Characteristics

$V_{BAT} = 0.9$ to 3.6 V; $T_A = -40$ to +85 °C

Symbol	Parameter	Min	Тур	Max	Unit	Test Conditions
V _{BAT}	DC-DC Input Voltage	0.9		3.6	V	$I_{DC} = 40 \text{ mA}$
V _{DC}	DC-DC Output Voltage	1.6	1.75	1.9	V	$I_{DC} = 40 \text{ mA}$
I _{DC}	DC-DC Output Current			40	mA	$V_{BAT} = 1.0 V$
H _{MAX}	Maximum Efficiency	92			%	$V_{BAT} = 1.5 V$
F _{SWITCH}	Switching Frequency	0.5	1.5	3	MHz	
R _{DCP}	DCPWR Input Pull-Up Resistor		30		KΩ	

Regulators

Schematic

Figure 136. Regulator Connection





Note: Depending on power supply scheme, C_{LV} may replace C_{DC1} capacitor (see Figure 135).

Parameters

Table 267. Regulator Filter Characteristics $T_A = -40$ to $+85^{\circ}C$

Symbol	Parameter	Min	Тур	Max	Unit
C _{HV}	Decoupling Capacitor		10		μF
C_{LV}	Decoupling Capacitor		20		μF

Table 268. High Voltage Regulator Power Characteristics

UV_{CC} = 4.4 to 5.5 V; T_A = -40 to +85 °C

Symbol	Parameter	Min	Тур	Max	Unit	Test Conditions
V_{HV}	High Voltage Regulator Output Voltage	3.1	3.3	3.5	V	I _{DC} = 50 mA
I _{HV}	High Voltage Regulator Output Current			50	mA	

Table 269. Low Voltage Regulator Power Characteristics

HV_{DD} = 3 to 3.6 V; T_A = -40 to +85 °C

Symbol	Parameter	Min	Тур	Max	Unit	Test Conditions
V_{LV}	Low Voltage Regulator Output Voltage	1.7	1.8	1.9	V	I _{DC} = 50 mA
I_{LV}	Low Voltage Regulator Output Current			50	mA	

USB

Schematic

Figure 137. USB Connection





Parameters

Table 270. USB Component Characteristics

T_A = -40 to +85°C

Symbol	Parameter	Min	Тур	Max	Unit
R _{UFT}	USB Full Speed Termination Resistor		39		Ω
R_{UB}	USB Bias Filter Resistor		6810		Ω
C _{UB}	USB Bias Filter Capacitor		10		pF

Audio Codec

Schematic

Figure 138. Audio Codec Connection









Parameters

Table 271. Audio Codec Components Characteristics

T_A = -40 to +85 ℃

Symbol	Parameter	Min	Тур	Max	Unit
C _{OUT}	OUTR/OUTL DC-Decoupling Capacitor		100 ⁽¹⁾ 0.1 ⁽²⁾		μF
C _{INL}	LINR/LINL DC-Decoupling Capacitor		1		μF
C _{INM}	MICIN DC-Decoupling Capacitor		1		μF
C _{VCM}	AVCM Filter Capacitor		100		nF
CAREF	AREF Filter Capacitor		1		μF
C _{MB}	MICBIAS Filter Capacitor		10		nF

Notes: 1. Value in low impedance mode (Headphone mode when AODRV = 1)
2. Value in high impedance mode (Line out mode when AODRV = 0)

MMC Controller

Schematic

Figure 139. MMC Connection



Parameters

Table 272. MMC Components Characteristics

T_A = -40 to +85℃

Symbol	Parameter	Min	Тур	Max	Unit
R _{CMD}	MMC/SD Command Line Pull-Up Resistor		10		KΩ
R _{DAT}	MMC/SD Data Line Pull-Up Resistor		100		KΩ

AC Characteristics

NFC Interface

Definition of Symbols

Table 273. NFC Interface Timing Symbol Definitions

Signals				
D	NFD7:0 In			
Q	NFD7:0 Out			
R	NFRE			
W	NFWE			
E	NFCEn			
А	NFALE			
С	NFCLE			

Conditions				
Н	High			
L	Low			
V	Valid			
х	No Longer Valid			
Z	Floating			

Timings

Table 274. NFC Command Latch Cycle AC timings

V_{DD} = 1.65 to 3.6 V; T_A = -40 to +85 °C, CL \leq 40pF (4 NF)

Symbol	Parameter	Min	Max	Unit
t _{ELWH}	NFCEn Write Setup Time	3·T _{NFC} -??		ns
t _{when}	NFCEn Write Hold Time	1·T _{NFC} -??		ns
t _{CHWH}	NFCLE Setup Time	3·T _{NFC} -??		ns
t _{WHCL}	NFCLE Hold Time	1·T _{NFC} -??		ns
t _{wLWH}	NFWE Pulse Width	2·T _{NFC} -??		ns
t _{QVWH}	Data Setup Time	2·T _{NFC} -??		ns
t _{WHQX}	Data Hold Time	1·T _{NFC} -??		ns

Table 275. NFC Address Latch Cycle AC timings

V_{DD} = 1.65 to 3.6 V; T_{A} = -40 to +85 °C, CL \leq 40pF (4 NF)

Symbol	Parameter	Min	Max	Unit
t _{ELWH}	NFCEn Write Setup Time	3·T _{NFC} -??		ns
t _{WHEH}	NFCEn Write Hold Time	1·T _{NFC} -??		ns
t _{AHWH}	NFALE Setup Time	3·T _{NFC} -??		ns
t _{WHAL}	NFALE Hold Time	1·T _{NFC} -??		ns
t _{wLWH}	NFWE Pulse Width	2·T _{NFC} -??		ns
t _{QVWH}	Data Setup Time	2·T _{NFC} -??		ns
t _{whqx}	Data Hold Time	1·T _{NFC} -??		ns





Table 276. NFC Interface Write Cycle AC timings

V_{DD} = 1.65 to 3.6 V; T_A = -40 to +85 °C, CL \leq 40pF (4 NF)

Symbol	Parameter	Min	Max	Unit
t _{ELWH}	NFCEn Write Setup Time	3·T _{NFC} -??		ns
t _{whEH}	NFCEn Write Hold Time	1·T _{NFC} -??		ns
t _{wLWH}	NFWE Pulse Width	2·T _{NFC} -??		ns
t _{QVWH}	Data Setup Time	2·T _{NFC} -??		ns
t _{WHQX}	Data Hold Time	1·T _{NFC} -??		ns

Table 277. NFC Interface Read Cycle AC timings

V_{DD} = 1.65 to 3.6 V; T_{A} = -40 to +85 °C, CL \leq 40pF (4 NF)

Symbol	Parameter	Min	Max	Unit
t _{RLRH}	NFRE Pulse Width	2·T _{NFC} -?? 3·T _{NFC} -??		ns ⁽¹⁾
t _{ELDV}	NFCEn Access Time		??	ns
t _{RLDV}	NFRE Access Time		??	ns
t _{RHDX}	Data Hold Time	??		ns
t _{RHDZ}	Data Float after NFRE High		??	ns
t _{EHDZ}	Data Float after NFCEn High		??	ns

Note: 1. Refer to TRS bit in NFCON register.

Waveforms

Figure 140. NFC Command Latch Cycle Waveforms





Figure 141. NFC Address Latch Cycle Waveforms













MMC Interface

Definition of symbols

Table 278. MMC Interface Timing Symbol Definitions

Signals	
С	Clock
D	Data In
0	Data Out

Conditions			
Н	High		
L	Low		
V	Valid		
Х	No Longer Valid		

Timings

Table 279. MMC Interface AC timings

V_{DD} = 1.65 to 3.6 V; T_{A} = -40 to +85 °C, CL \leq 40pF (4 cards)

Symbol	Parameter	Min	Max	Unit
t _{CHCH}	Clock Period	40		ns
t _{CHCX}	Clock High Time	10		ns
t _{CLCX}	Clock Low Time	10		ns
t _{CLCH}	Clock Rise Time		10	ns
t _{CHCL}	Clock Fall Time		10	ns
t _{DVCH}	Input Data Valid to Clock High	3		ns
t _{CHDX}	Input Data Hold after Clock High	3		ns
t _{CHOX}	Output Data Hold after Clock High	5		ns
t _{ovch}	Output Data Valid to Clock High	5		ns

Waveforms

Figure 144. MMC Input-Output Waveforms



LCD Interface

Definition of Symbols

Table 280. LCD Interface Timing Symbol Definitions

	Signals		Cond	itions
ſ	D	LCD7:0 In	н	High
Ī	Q	LCD7:0 Out	L	Low

Signals		
А	LA0/LRS	
R	LRD	
W	LWR	
S	LCS	
E	LDE	

Conditions			
V	Valid		
x	No Longer Valid		
Z	Floating		

Timings

Table 281. LCD 8080 Write Cycle AC timings

V_{DD} = 1.65 to 3.6 V; T_A = -40 to +85 °C, CL \leq 50pF

Symbol	Parameter	Min	Max	Unit
t _{SLWH}	LCS Write Setup Time	??		ns
t _{whsh}	LCS Write Hold Time	??		ns
t _{QVWH}	Data Setup Time	??		ns
t _{WHQX}	Data Hold Time	??		ns
t _{wLWH}	LWR/LRW Pulse Width	??		ns

Table 282. LCD 8080 Read Cycle AC timings

V_{DD} = 1.65 to 3.6 V; T_A = -40 to +85 °C, CL \leq 50pF

Symbol	Parameter	Min	Max	Unit
t _{SLDV}	LCS Access Time		??	ns
t _{RLDV}	TRD/LDE Access Time		??	ns
t _{RHDX}	Data Hold Time After LRD/LDE High	??		ns
t _{RHDZ}	Data Float Time After TRD/LDE High	??		ns
t _{RLRH}	LRD/LDE Pulse Width	??		ns

Table 283. LCD 6800 Write Cycle AC timings

V_{DD} = 1.65 to 3.6 V; T_A = -40 to +85 °C, CL \leq 50pF

Symbol	Parameter	Min	Max	Unit
t _{SLEL}	LCS Write Setup Time	??		ns
t _{ELSH}	LCS Write Hold Time	??		ns
t _{AVEH}	Address Setup Time	??		ns
t _{ELAX}	Address Hold Time	??		ns
t _{QVEL}	Data Setup Time	??		ns
t _{ELQX}	Data Hold Time	??		ns
t _{EHEL}	LRD/LDE Pulse Width	??		ns





Table 284. LCD 6800 Read Cycle AC timings

V_{DD} = 1.65 to 3.6 V; T_A = -40 to +85 °C, CL \leq 50pF

Symbol	Parameter	Min	Max	Unit
t _{SLDV}	LCS Access Time		??	ns
t _{EHDV}	TRD/LDE Access Time		??	ns
t _{AVDV}	Address Access Time		??	ns
t _{AVEH}	Address Setup Time	??		ns
t _{AVEH}	Address Access Time		??	ns
t _{ELDX}	Data Hold Time After TRD/LDE Low	??		ns
t _{ELDZ}	Data Float Time After TRD/LDE Low	??		ns
t _{ELEH}	LRD/LDE Pulse Width	??		ns

Waveforms

Figure 145. LCD 8080 Write Cycle Waveform














PSI Interface

Definition of Symbols

Table 285. PSI Interface Timing Symbol Definitions

Signals		
D	SD7:0 In	
Q	SD7:0 Out	
А	SA0	
R	SRD	
w	SWR	
E	SCS	

Conditions		
н	High	
L	Low	
V	Valid	
х	No Longer Valid	
Z	Floating	





Timings

Table 286. PSI Write Cycle AC timings

V_{DD} = 1.65 to 3.6 V; T_A = -40 to +85 °C, CL \leq 50pF

Symbol	Parameter	Min	Max	Unit
t _{AVAV}	Write Cycle Time	4		T _{osc}
t _{WLWH}	SWR Pulse Width	3+PSWS ⁽¹⁾		T _{osc}
t _{AVEL}	Address Setup Time	0		ns
t _{WHAX}	Address Hold Time	0		ns
t _{WLDV}	SWR to Data Valid Time		3+PSWS ⁽¹⁾	T _{osc}
t _{WHDX}	Data Hold Time	0		ns
t _{ELWH}	SCS Setup Time	4+PSWS ⁽¹⁾		T _{osc}
t _{when}	SCS Hold Time	0		ns

Note: 1. PSWS2:0 value in PSICON register

Table 287. PSI Read Cycle AC timings

V_{DD} = 1.65 to 3.6 V; T_A = -40 to +85 °C, CL \leq 50pF

Symbol	Parameter	Min	Max	Unit
t _{AVAV}	Read Cycle Time	4		T _{OSC}
t _{RLRH}	SRD Pulse Width	2		T _{OSC}
t _{ELQV}	SCS Access Time		3.5	T _{OSC}
t _{AVQV}	Address Access Time		3.5	T _{OSC}
t _{RLQV}	SRD Access Time		1.5	T _{OSC}
t _{EHQZ}	Data Float after SCS High		1.5	T _{OSC}
t _{RHQZ}	Data Float after SRD High		1.5	T _{OSC}

Waveforms

Figure 149. PSI Write Cycle Waveform



Figure 150. PSI Read Cycle Waveform



SPI Interface

Definition of Symbols

Table 288. SPI Interface Timing Symbol Definitions

Signals	
С	Clock
I	Data In
0	Data Out

Conditions		
H High		
L	Low	
V	Valid	
х	No Longer Valid	
Z	Floating	

Timings

Test conditions: capacitive load on all pins= 50 pF.





Table 289. SPI Interface Master AC Timing

V_{DD} = 1.65 to 3.6 V; T_A = -40 to +85 °C

Symbol	Parameter	Min	Max	Unit
	Slave Mode			•
t _{CHCH}	Clock Period	2		T _{PER}
t _{CHCX}	Clock High Time	0.8		T _{PER}
t _{CLCX}	Clock Low Time	0.8		T _{PER}
t _{SLCH} , t _{SLCL}	SS Low to Clock edge	100		ns
t _{IVCL} , t _{IVCH}	Input Data Valid to Clock Edge	40		ns
t _{CLIX} , t _{CHIX}	Input Data Hold after Clock Edge	40		ns
t _{CLOV,} t _{CHOV}	Output Data Valid after Clock Edge		40	ns
t _{CLOX} , t _{CHOX}	Output Data Hold Time after Clock Edge	0		ns
t _{CLSH} , t _{CHSH}	SS High after Clock Edge	0		ns
t _{SLOV}	SS Low to Output Data Valid		50	ns
t _{sHOX}	Output Data Hold after SS High		50	ns
t _{SHSL}	SS High to SS Low	(1)		
t _{ILIH}	Input Rise Time		2	μs
t _{IHIL}	Input Fall Time		2	μs
t _{oloh}	Output Rise time		100	ns
t _{OHOL}	Output Fall Time		100	ns
	Master Mode			
t _{CHCH}	Clock Period	2		T _{PER}
t _{CHCX}	Clock High Time	0.8		T _{PER}
t _{CLCX}	Clock Low Time	0.8		T _{PER}
t _{IVCL} , t _{IVCH}	Input Data Valid to Clock Edge	20		ns
t _{CLIX} , t _{CHIX}	Input Data Hold after Clock Edge	20		ns
t _{CLOV,} t _{CHOV}	Output Data Valid after Clock Edge		40	ns
t _{CLOX} , t _{CHOX}	Output Data Hold Time after Clock Edge	0		ns
t _{ILIH}	Input Data Rise Time		2	μs
t _{IHIL}	Input Data Fall Time		2	μs
t _{oloh}	Output Data Rise time		50	ns
t _{OHOL}	Output Data Fall Time		50	ns

Note: 1. Value of this parameter depends on software.

Waveforms

Figure 151. SPI Slave Waveforms (SSCPHA= 0)



Note: 1. Not Defined but generally the MSB of the character which has just been received.





Note: 1. Not Defined but generally the LSB of the character which has just been received.









Note: SS handled by software using general purpose port pin.





Note: SS handled by software using general purpose port pin.

Audio DAC Interface

Definition of symbols

Table 290. Audio DAC Interface Timing Symbol Definitions

Signals	
С	Clock
0	Data Out
S	Data Select

Conditions			
Н	High		
L	Low		
V	Valid		
х	No Longer Valid		

Timings

Table 291. Audio Interface AC timings

V_{DD} = 1.65 to 3.6 V; T_A = -40 to +85 °C, CL \leq 30pF

Symbol	Parameter	Min	Мах	Unit
t _{CHCH}	Clock Period		325.5 ⁽¹⁾	ns
t _{CHCX}	Clock High Time	30		ns
t _{CLCX}	Clock Low Time	30		ns
t _{CLCH}	Clock Rise Time		10	ns
t _{CHCL}	Clock Fall Time		10	ns
t _{CLSV}	Clock Low to Select Valid		10	ns
t _{CLOV}	Clock Low to Data Valid		10	ns

Note: 1. 32-bit format with Fs= 48 KHz.

Waveforms

Figure 155. Audio Interface Waveforms



External Clock Interface

Definition of symbols

Table 292. External Clock Timing Symbol Definitions

Signals		nals
	С	Clock

Conditions		
н	High	
L	Low	
х	No Longer Valid	





Timings

Table 293. External Clock AC Timings

V_{DD} = 1.65 to 3.6 V; T_A = -40 to +85 °C

Symbol	Parameter	Min	Max	Unit
t _{CLCL}	Clock Period	38		ns
t _{CHCX}	High Time	10		ns
t _{CLCX}	Low Time	10		ns
t _{CLCH}	Rise Time	3		ns
t _{CHCL}	Fall Time	3		ns
t _{CR}	Cyclic Ratio in X2 mode	40	60	%

Waveforms

Figure 156. External Clock Waveform



Ordering Information

Part Number	Temp. Range	Package	Packing	Product Marking	MP3 Royalties
AT85SND3B1N-RTTUL	Industrial & Green	LQFP100	Tray	85C51SND3B1N-UL	No
AT85SND3B1N-7FTUL	Industrial & Green	CTBGA100	Tray	85C51SND3B1N-UL	No
AT85SND3B1-RTTUL	Industrial & Green	LQFP100	Tray	85C51SND3B1-UL	Yes
AT85SND3B1-7FTUL	Industrial & Green	CTBGA100	Tray	85C51SND3B1-UL	Yes

Table 294. Ordering Information

Table 295. Part Number Information

Part Number	1.8V DC-DC	Stereo DAC
85SND3B0	No	No
85SND3B1	No	Yes
85SND3B2	Yes	Yes





Package Information

LQFP 100



T	0.080
LEAD	COPLANARIT

	мм		INCH	
	Min	Max	Min	Max
А	1.40	1.60	. 055	. 063
A1	1.35	1.45	. 053	. 057
С	0.1	7 BSC	. 007 BSC	
D	15.80	16.20	. 622	. 638
D 1	13.90	14.10	. 547	. 555
E	15.80	16.20	. 622	. 638
E 1	13.90	14.10	. 547	. 555
J	0. 05	0.15	. 002	. 006
L	0.45	0.75	. 018	. 030
e	0. 50 BSC		. 01	97 BSC
f	0. 22 BSC		. 00	9 BSC





CTBGA 100



Document Revision History

Chang	ges from	
Rev. A	- 03/06	to
Rev. E	8 - 04/06	

Changes from Rev. B - 04/06 to Rev. C - 10/06 1. Added BGA pinout drawing on page 7.

2. Update to product features on page 1.

1. Update to "Electrical Characteristics" on page 242.

- 2. PSI Timings updated.
- 3. Part numbers changed.

Changes from Rev. C - 10/06 to Rev. D - 01/07

1. Correction to ordering information.





Table of Contents

Description 2 Key Features 3 Block Diagram 4 Application Information 5 Pin Description 6 Signals Description 8 Internal Pin Structure 16 Power Management 19 Power Supply 19 Power Reduction Mode 21 Reset 24 Registers 26 Clock Controller 28 Oscillator 28 Oscillator 28 Olock Generator 29 System Clock Generator 30 DFC/NFC Clock Generator 32 SIO Clock Generator 32 SIO Clock Generator 33 Registers 34 Special Function Registers 37 SFR Pagination 37 SFR Registers 38 Memory Segments 50 Memory Softiguration 51 Registers 52 Interrupt System Priorities 55	Features	1
Key Features 3 Block Diagram 4 Application Information 5 Pin Description 6 Pinouts 6 Signals Description 8 Internal Pin Structure 16 Power Management 19 Power Reduction Mode 21 Reset 24 Registers 26 Clock Controller 28 Oscillator 28 Clock Generator 29 System Clock Generator 30 DFC/NFC Clock Generator 32 SIO Clock Generator 32 SIO Clock Generator 32 SIO Clock Generator 31 MMC Clock Generator 32 SIO Clock Generator 33 Registers 34 Special Function Registers 37 SFR Pagination 37 SFR Registers 36 Memory Space 50 Memory Segments 50 Memory System Priorities 55 Interrupt System 55 Interrupt Sys	Description	2
Block Diagram 4 Application Information 5 Pin Description 6 Signals Description 8 Internal Pin Structure 16 Power Management 19 Power Reduction Mode 21 Reset 24 Registers 26 Clock Controller 28 Oscillator 29 System Clock Generator 30 DFC/NFC Clock Generator 31 MMC Clock Generator 32 SIO Clock Generator 33 Registers 34 Special Function Registers 37 SFR Pagination 37 SFR Registers 38 Memory Space 50 Memory Configuration 51 Registers 52 Interrupt System Priorities 55 External Interrupts 58 Registers 59	Key Features	. 3
Application Information 5 Pin Description 6 Pinouts 6 Signals Description 8 Internal Pin Structure 16 Power Management 19 Power Supply 19 Power Reduction Mode 21 Reset 24 Registers 26 Clock Controller 28 Oscillator 28 Clock Generator 29 System Clock Generator 30 DFC/NFC Clock Generator 31 MMC Clock Generator 32 SIO Clock Generator 33 Registers 38	Block Diagram	. 4
Pin Description 6 Signals Description 8 Internal Pin Structure 16 Power Management 19 Power Supply 19 Power Reduction Mode 21 Reset 24 Registers 26 Clock Controller 28 Oscillator 28 Oscillator 28 Oscillator 29 System Clock Generator 29 System Clock Generator 30 DFC/NFC Clock Generator 31 MMC Clock Generator 32 SIO Clock Generator 33 Registers 34 Special Function Registers 37 SFR Pagination 37 SFR Pagination 37 SFR Registers 38 Memory Space 50 Memory Configuration 51 Registers 52 Interrupt System Priorities 55 Interrupt System Priorities 55 External Interrupts 58 Registers 59	Application Information	5
Pinouts 6 Signals Description 8 Internal Pin Structure 16 Power Management 19 Power Supply 19 Power Reduction Mode 21 Reset 24 Registers 26 Clock Controller 28 Oscillator 28 Clock Generator 29 System Clock Generator 29 System Clock Generator 30 DFC/NFC Clock Generator 31 MMC Clock Generator 32 SIO Clock Generator 33 Registers 34 Special Function Registers 37 SFR Pagination 37 SFR Pagination 37 SFR Registers 38 Memory Space 50 Memory Segments 50 Memory Segments 50 Memory System Priorities 52 Interrupt System 55 Interrupt System Priorities 55 External Interrupts 58 Registers 59	Pin Description	6
Signals Description 8 Internal Pin Structure 16 Power Management 19 Power Reduction Mode 21 Reset 24 Registers 26 Clock Controller 28 Oscillator 28 Clock Generator 29 System Clock Generator 30 DFC/NFC Clock Generator 31 MMC Clock Generator 32 SIO Clock Generator 33 Registers 34 Special Function Registers 37 SFR Pagination 37 SFR Registers 38 Memory Segments 50 Memory Segments 50 Memory Segments 50 Memory Segments 52 Interrupt System 55 Interrupt System Priorities 55 External Interrupts 58 Registers 59	Pinouts	6
Internal Pin Structure 16 Power Management 19 Power Supply. 19 Power Reduction Mode 21 Reset 24 Registers 26 Clock Controller 28 Oscillator 28 Clock Generator 29 System Clock Generator 30 DFC/NFC Clock Generator 31 MMC Clock Generator 32 SIO Clock Generator 33 Registers 34 Special Function Registers 37 SFR Pagination 37 SFR Registers 38 Memory Space 50 Memory Segments 50 Memory Segments 50 Interrupt System 55 Interrupt System Priorities 55 External Interrupts 58 Registers 59	Signals Description	8
Power Management 19 Power Supply 19 Power Reduction Mode 21 Reset 24 Registers 26 Clock Controller 28 Oscillator 28 Clock Generator 29 System Clock Generator 30 DFC/NFC Clock Generator 31 MMC Clock Generator 32 SIO Clock Generator 32 SIO Clock Generator 33 Registers 34 Special Function Registers 37 SFR Pagination 37 SFR Registers 38 Memory Space 50 Memory Segments 50 Memory Configuration 51 Registers 52 Interrupt System 55 Interrupt System Priorities 55 External Interrupts 58 Registers 59	Internal Pin Structure	16
Power Supply	Power Management	. 19
Power Reduction Mode 21 Reset 24 Registers 26 Clock Controller 28 Oscillator 28 Clock Generator 29 System Clock Generator 30 DFC/NFC Clock Generator 31 MMC Clock Generator 32 SIO Clock Generator 32 SIO Clock Generator 33 Registers 34 Special Function Registers 37 SFR Pagination 37 SFR Registers 38 Memory Space 50 Memory Configuration 51 Registers 52 Interrupt System 55 Interrupt System Priorities 55 External Interrupts 58 Registers 59	Power Supply	. 19
Reset 24 Registers 26 Clock Controller 28 Oscillator 28 Clock Generator 29 System Clock Generator 30 DFC/NFC Clock Generator 31 MMC Clock Generator 32 SIO Clock Generator 33 Registers 34 Special Function Registers 37 SFR Pagination 37 SFR Registers 38 Memory Space 50 Memory Segments 50 Memory Configuration 51 Registers 52 Interrupt System 55 Interrupt System Priorities 55 External Interrupts 58 Registers 58	Power Reduction Mode	. 21
Registers. 26 Clock Controller 28 Oscillator. 28 Clock Generator. 29 System Clock Generator. 30 DFC/NFC Clock Generator. 31 MMC Clock Generator. 32 SIO Clock Generator. 33 Registers. 34 Special Function Registers 37 SFR Pagination. 37 SFR Registers 38 Memory Space 50 Memory Configuration 51 Registers. 52 Interrupt System Priorities 55 External Interrupts 58 Registers. 58 Registers. 59	Reset	. 24
Clock Controller 28 Oscillator. 28 Clock Generator. 29 System Clock Generator. 30 DFC/NFC Clock Generator. 31 MMC Clock Generator. 32 SIO Clock Generator. 32 SIO Clock Generator. 32 SIO Clock Generator. 33 Registers. 34 Special Function Registers 37 SFR Pagination. 37 SFR Registers 38 Memory Space 50 Memory Configuration 51 Registers. 52 Interrupt System 55 Interrupt System Priorities 55 External Interrupts 58 Registers. 59	Registers	26
Oscillator 28 Clock Generator 29 System Clock Generator 30 DFC/NFC Clock Generator 31 MMC Clock Generator 32 SIO Clock Generator 33 Registers 34 Special Function Registers 37 SFR Pagination 37 SFR Registers 38 Memory Space 50 Memory Segments 50 Memory Configuration 51 Registers 52 Interrupt System 55 Interrupt System Priorities 55 External Interrupts 58 Registers 58	Clock Controller	. 28
Clock Generator. 29 System Clock Generator. 30 DFC/NFC Clock Generator. 31 MMC Clock Generator. 32 SIO Clock Generator 33 Registers. 34 Special Function Registers 37 SFR Pagination. 37 SFR Registers 38 Memory Space 50 Memory Segments. 50 Memory Configuration 51 Registers. 52 Interrupt System 55 Interrupt System Priorities 55 External Interrupts 58 Registers. 59	Oscillator	. 28
System Clock Generator. 30 DFC/NFC Clock Generator. 31 MMC Clock Generator. 32 SIO Clock Generator. 33 Registers. 34 Special Function Registers 37 SFR Pagination. 37 SFR Registers 38 Memory Space 50 Memory Segments. 50 Memory Configuration 51 Registers. 52 Interrupt System 55 Interrupt System Priorities 55 External Interrupts 58 Registers. 59	Clock Generator	. 29
DFC/NFC Clock Generator31MMC Clock Generator32SIO Clock Generator33Registers34Special Function Registers37SFR Pagination37SFR Registers38Memory Space50Memory Segments50Memory Configuration51Registers52Interrupt System55Interrupt System Priorities55External Interrupts58Registers59	System Clock Generator	. 30
MMC Clock Generator 32 SIO Clock Generator 33 Registers 34 Special Function Registers 37 SFR Pagination 37 SFR Registers 38 Memory Space 50 Memory Configuration 51 Registers 52 Interrupt System 55 Interrupt System Priorities 55 External Interrupts 58 Registers 59	DFC/NFC Clock Generator	. 31
SIO Clock Generator33Registers34Special Function Registers37SFR Pagination37SFR Registers38Memory Space50Memory Segments50Memory Configuration51Registers52Interrupt System55Interrupt System Priorities55External Interrupts58Registers59	MMC Clock Generator	. 32
Registers34Special Function Registers37SFR Pagination37SFR Registers38Memory Space50Memory Segments50Memory Configuration51Registers52Interrupt System55Interrupt System Priorities55External Interrupts58Registers59	SIO Clock Generator	. 33
Special Function Registers37SFR Pagination37SFR Registers38Memory Space50Memory Segments50Memory Configuration51Registers52Interrupt System55Interrupt System Priorities55External Interrupts58Registers59	Registers	. 34
SFR Pagination	Special Function Registers	. 37
SFR Registers38Memory Space50Memory Segments50Memory Configuration51Registers52Interrupt System55Interrupt System Priorities55External Interrupts58Registers59	SFR Pagination	. 37
Memory Space50Memory Segments50Memory Configuration51Registers52Interrupt System55Interrupt System Priorities55External Interrupts58Registers59	SFR Registers	. 38
Memory Segments 50 Memory Configuration 51 Registers 52 Interrupt System 55 Interrupt System Priorities 55 External Interrupts 58 Registers 59	Memory Space	. 50
Memory Configuration 51 Registers 52 Interrupt System 55 Interrupt System Priorities 55 External Interrupts 58 Registers 59	Memory Segments	. 50
Registers 52 Interrupt System 55 Interrupt System Priorities 55 External Interrupts 58 Registers 59	Memory Configuration	. 51
Interrupt System55Interrupt System Priorities55External Interrupts58Registers59	Registers	. 52
Interrupt System Priorities	Interrupt System	. 55
External Interrupts	Interrupt System Priorities	. 55
Registers	External Interrupts	. 58
	Registers	59

i

Timers/Counters	65
Timer/Counter Operations	65
Timer Clock Controller	65
Timer 0	66
Timer 1	69
Interrupt	70
Registers	.71
Watchdog Timer	75
Description	75
Clock Controller	75
Operation	76
Registers	.77
Data Flow Controller	78
CPU Interface	78
Clock Unit	78
Data Flow Descriptor	78
CRC Processor	79
Null Device	79
Channel Priority	80
Data Flow Status	80
Data Flow Abort	80
Data Flow Configuration	81
Interrupts	81
Registers	82
USB Controller	85
Description	85
General Operating Modes	86
Interrupts.	87
Power modes	88
Speed Control	89
Memory Access Capability	89
Memory Management	90
PAD suspend	91
OTG Timers Customizing	92
Plug-in detection	92
ID Detection	94
Registers	94
USB Software Operating modes 1	100
USB Device Operating modes	01
Introduction	101
Power-On and Reset	101
Speed Identification	101





Endp	oint Reset	102
USB	Reset	102
Endp	oint Selection	102
Endp	oint Activation	103
Addre	ess Setup	103
Suspe	end, Wake-Up and Resume	104
Detac	ch	104
Remo	ote Wake-Up	105
STAL	L Request	105
CON	TROL Endpoint Management	106
OUT	Endpoint Management	107
IN En	dpoint Management	109
lsoch	ronous Mode	112
Overf	low	112
Interr	upts	113
Regis	sters	115
USB Hos	t Operating Modes 1	127
Pipe I	Description	127
Detac	h	127
Powe	r-on and Reset	127
Devic	e Detection	128
Pipe	Selection	128
Pipe	Configuration	129
USB	Reset	130
Addre	ess Setup	130
Remo	ote Wake-Up Detection	130
USB	Pipe Reset	130
Pipe I	Data Access	130
Contr	ol Pipe Management	130
OUT	Pipe Management	131
IN Pip	be management	133
Interr	upt	134
Regis	sters	136
Audia Ca	ant rollor	110
AUGIO CO		149
Clock		149
Audio		149
Audio		154
Audio) DAG INTERTACE	156
Regis	sters	158
Nand Fla	sh Controller	169
Funct	tional overview	169
Clock	(Unit	170
Contr	rol I Init	170
Conti		.,0

	Data Unit	177
	End of Data Transfer	180
	Security Unit	180
	Card Unit	183
	Interrupt Unit	184
	Registers	185
ММ	C/SD Controller	192
	Clock Generator	192
	Command Line Controller	192
	Data Line Controller	195
	Card Management	201
	Interrupt	202
	Registers	203
Para	allel Slave Interface	208
	Description	208
	Interrupts	211
	Registers	212
Seri	al I/O Port	214
	Description	214
	Baud Rate Generator	216
	Receiver	218
	Transmitter	219
	Interrupts	219
	Registers	220
Seri	al Peripheral Interface	224
	Description	225
	Interrupt	231
	Registers	231
Disr	play Interface	234
	Configuration	234
	Bogietore	237
		237
Key	board Interface	240
	Description	240
	Registers	241
	-	
Elec	trical Characteristics	242
	Absolute Maximum Rating	242
	DC Characteristics	242
	AC Characteristics	247





Ordering Information	262
Package Information	263
LQFP 100	263
CTBGA 100	264
Document Revision History	265
Changes from	
Rev. A - 03/06 to	
Rev. B - 04/06	265
Changes from	
Rev. B - 04/06 to	005
Rev. C - 10/06	265
Changes from	
Rev. C - 10/06 to	
Rev. D - 01/07	265
	265
Table of Contents	i



Atmel Corporation

2325 Orchard Parkway San Jose, CA 95131, USA Tel: 1(408) 441-0311 Fax: 1(408) 487-2600

Regional Headquarters

Europe

Atmel Sarl Route des Arsenaux 41 Case Postale 80 CH-1705 Fribourg Switzerland Tel: (41) 26-426-5555 Fax: (41) 26-426-5500

Asia

Room 1219 Chinachem Golden Plaza 77 Mody Road Tsimshatsui East Kowloon Hong Kong Tel: (852) 2721-9778 Fax: (852) 2722-1369

Japan

9F, Tonetsu Shinkawa Bldg. 1-24-8 Shinkawa Chuo-ku, Tokyo 104-0033 Japan Tel: (81) 3-3523-3551 Fax: (81) 3-3523-7581

Atmel Operations

Memory

2325 Orchard Parkway San Jose, CA 95131, USA Tel: 1(408) 441-0311 Fax: 1(408) 436-4314

Microcontrollers

2325 Orchard Parkway San Jose, CA 95131, USA Tel: 1(408) 441-0311 Fax: 1(408) 436-4314

La Chantrerie BP 70602 44306 Nantes Cedex 3, France Tel: (33) 2-40-18-18-18 Fax: (33) 2-40-18-19-60

ASIC/ASSP/Smart Cards

Zone Industrielle 13106 Rousset Cedex, France Tel: (33) 4-42-53-60-00 Fax: (33) 4-42-53-60-01

1150 East Cheyenne Mtn. Blvd. Colorado Springs, CO 80906, USA Tel: 1(719) 576-3300 Fax: 1(719) 540-1759

Scottish Enterprise Technology Park Maxwell Building East Kilbride G75 0QR, Scotland Tel: (44) 1355-803-000 Fax: (44) 1355-242-743

RF/Automotive

Theresienstrasse 2 Postfach 3535 74025 Heilbronn, Germany Tel: (49) 71-31-67-0 Fax: (49) 71-31-67-2340

1150 East Cheyenne Mtn. Blvd. Colorado Springs, CO 80906, USA Tel: 1(719) 576-3300 Fax: 1(719) 540-1759

Biometrics/Imaging/Hi-Rel MPU/

High Speed Converters/RF Datacom Avenue de Rochepleine BP 123 38521 Saint-Egreve Cedex, France Tel: (33) 4-76-58-30-00 Fax: (33) 4-76-58-34-80

Literature Requests www.atmel.com/literature

Disclaimer: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. EXCEPT AS SET FORTH IN ATMEL'S TERMS AND CONDI-TIONS OF SALE LOCATED ON ATMEL'S WEB SITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITVE, SPECIAL OR INCIDEN-TAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and product descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically providedotherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel's products are not intended, or warranted for use as components in applications intended to support or sustain life.

©2007 Atmel Corporation. All rights reserved. Atmel[®], logo and combinations thereof, are registered trademarks, or are the trademarks of Atmel Corporation or its subsidiaries. Other terms and product names may be trademarks of others.

