


FLASH MEMORY CONTROLLER

—TOP VIEW—



PIN NO.	I/O	SIGNAL	PIN NO.	I/O	SIGNAL	PIN NO.	I/O	SIGNAL	PIN NO.	I/O	SIGNAL
1	I	ATTR3	17	I	WP	33	I	XMM	49	O	XFRE
2	I	TCLE	18	O	TRXB	34	I	XTWE	50	O	XFWE
3	I	BS	19	I	FSEL1	35	I	SPARE1	51	O	FALE
4	I	TALE	20	I	FSEL0	36	I	FRXB3	52	O	FCLE
5	I	XTCEN	21	I	XRST	37	I	FRXB2	53	I/O	FIO3
6	I/O	DIO	22	—	NC	38	I	FRXB1	54	I/O	FIO2
7	I	XTREN	23	I	X0	39	I	FRXB0	55	I/O	FIO1
8	I	XTWEN	24	I/O	X1	40	I/O	FIO7	56	I/O	FIO0
9	I	SCLK	25	—	GND	41	I/O	FIO6	57	—	GND
10	—	GND	26	—	Vcc	42	—	GND	58	—	Vcc
11	I/O	TIO7	27	I	XSM	43	I/O	FIO5	59	—	VPDIN
12	I/O	TIO6	28	I	XTST	44	I/O	FIO4	60	I	ATTR4
13	I/O	TIO5	29	I	XFTST	45	O	XFCE3	61	I	XTCK
14	I/O	TIO4	30	O	XMCKSTP	46	O	XFCE2	62	I	ATTR0
15	I/O	TIO3	31	I/O	TIO1	47	O	XFCE1	63	I	ATTR1
16	I/O	TIO2	32	I/O	TIO0	48	O	XFCE0	64	I	ATTR2