

Features

- DC input range: 36 75V
- DC outputs: 1.5 to 12V
- Low profile: 0.350" above board height
- Multiple fin configurations
- Effective power density: Up to 188W/in³
- Parallelable, with N+M fault tolerance
- Low noise ZCS/ZVS architecture
- Input surge withstand: 100V for 100ms

Typical Applications

Typical applications include communications, data processing, test equipment, industrial applications and distributed power systems.

Product Overview

PowerStick features an above board height of only 0.35" and a footprint as small as 2.28"L x 0.5"W. PowerStick converters deliver up to 75 Watts per module and up to 900 Watts in fault-tolerant arrays.

Vicor's innovative through-the-board mounting results in an effective power conversion density of 188W/in³. A wraparound aluminum body, available in a variety of options, provides integral cooling in a broad range of applications and thermal environments, allowing customers to achieve peak power density within the 0.35" low profile.


All members of the PowerStick family maintain the complete feature set of Vicor 2nd Generation converters. And, because PowerSticks are environmentally sealed and encased in aluminum, they offer superior ruggedness, reliability, electrical shielding and noise performance.

> 0.35" Above Board Height

Low voltage models incorporate Vicor's innovative Smart Rectification[™] for high efficiency.

Data Sheet**PRELIMINARY** $PowerStick^{TM}$ DC-DCC-DCC-nverters


Low Profile, Integral Cooling Up to 75W



Absolute Maximum Ratings

Parameter	Rating	Unit	Notes
+In to -In voltage	-0.5 to +75	Vdc	
+In to -In voltage	100	Vdc	<100ms
PC to -In voltage	-0.5 to +7.0	Vdc	
PR to -In voltage	-0.5 to +7.0	Vdc	
SC to -Out voltage	-0.5 to +1.5	Vdc	
-Sense to -Out voltage	1.0	Vdc	
Isolation voltage (in to out)	1500	Vdc	
Isolation voltage (in to case)	1500	Vdc	
Isolation voltage (out to case)	1500	Vdc	
Storage temperature (C-Grade)	-40 to +125	°C	
Operating temperature (C-Grade)	-20 to +100	°C	Case Temp.

Part Numbering



Vicor Corporation Tel: 800-735-6200 • 978-470-2900 • Fax: 978-475-6715

ELECTRICAL CHARACTERISTICS

Electrical characteristics apply over the full operating range of input voltage, output load (resistive) and case temperature, unless otherwise specified. All temperatures refer to the operating temperature at the top center of the case.

MODULE OPERATING SPECIFICATIONS

Parameter	Min	Тур	Мах	Unit	Notes	
Operating input voltage	36	48	75	Vdc		
Input surge withstand			100	Vdc	<100ms	

MODULE OUTPUT VOLTAGE RELATED SPECIFICATIONS

Parameter	1.5 to 3.3V	5V	12V	Unit	Notes
Output Voltage Setpoint	±1%	±1%	±1%	Vout nom.	Nominal Input, 75% load, 25°C
Ripple and noise, p-p (typ.)	180	250	160	mV	Nominal Input; full load; 25°C, 20MHz BW
Output Power (max.)		60	75	Watts	At 100°C Case Temperature
Output Current (max.)	10 or 15			Amps	At 100°C Case Temperature
Output OVP setpoint (nom.)	115% Vnom +0.5	6.3	14.3	Volts	
Dissipation, standby (typ.)	1.8	1.9	1.9	Watts	No load; nominal input
Load regulation (max.)	0.3	0.3	0.2	±% Vout	No load to full load; nominal input
Current limit (typ.)	115	115	115	% lout	Output voltage 95% of nominal
Short circuit current (typ.)	115	115	115	% lout	Output voltage <250mV

MODULE INPUT SPECIFICATIONS

Parameter	Min	Тур	Мах	Unit	Notes
Undervoltage turn-on		34.9	35.7	Vdc	
Undervoltage turn-off	29.4	30.5		Vdc	
Overvoltage turn-off/on	75.7	78.8	82.5	Vdc	

MODULE OUTPUT SPECIFICATIONS

Parameter	Min	Тур	Max	Unit	Notes
Line regulation		±0.02	±0.2	%	Low line to high line; full load
Temperature regulation		±0.002	±0.005	% / °C	-20 to 100°C
Power sharing accuracy		±2	±5	%	10 to 100% of full load
Programming range	10		110	%	Of nominal output voltage. For trim below 90% of nominal, a minimum load of 10% of maximum rated power may be required.

Note: For important information relative to applications where the converters are subject to continuous dynamic loading, contact Vicor Applications Engineering at 800-927-9474 or your local Vicor office.

Vicor Corporation Tel: 800-735-6200 • 978-470-2900 • Fax: 978-475-6715

MODULE CONTROL SPECIFICATIONS

Parameter	Min	Тур	Max	Unit	Notes	
PRIMARY SIDE (PC = Primar	y Control; PR =	Parallel)				
PC bias voltage						
current limit	1.5	2.1	3.0	mA	PC voltage = 5.5V	
PC module disable	2.5	2.5	2.6	Vdc	Must be able to sink ≥ 4 mA. See Fig. 1	
PC module enable delay		4	7	ms		
PC module alarm			0.5	Vavg	UV, OV, module fault. See Figs. 2, 4	
PR emitter amplitude	5.7	5.9	6.1	Volts	PR load >30 ohms, < 30 pF	
PR emitter current	150			mA		
PR receiver impedance	375	500	625	ohms	25°C	
PR receiver threshold	2.4	2.5	2.6	Volts	Minimum pulse width: 20ns	
PR drive capability			12	Modules	Without PR buffer amplifier	
SECONDARY SIDE (SC = Se	condary Control)				
SC bandgap voltage	1.22	1.23	1.24	Vdc	Referenced to -Sense	
SC resistance	990	1000	1010	ohms		
SC capacitance		0.033		μF		
SC module alarm		0		Vdc	With open trim; referenced to -Sense. See Fig	

MODULE GENERAL SPECIFICATIONS

Parameter	Min	Тур	Мах	Unit	Notes
Remote sense (total drop)			0.5	Vdc	0.25V per leg (senses must be closed)
Isolation voltage (in to out)	1500			Vdc	
Isolation voltage (in to case)	1500			Vdc	
Isolation voltage (out to case)	1500			Vdc	
Isolation resistance (in to out)		10		Megohms	
Weight		0.9 (26)		Ounces (grams)	S Case
Agency Approvals	UL, CS	A, TÜV, BABT,	CE, VDE		UL1950, CSA950, EN60950, VDE0805, BS7002
					IEC 60950. With a fuse in a series with the +Inpu

■ TYPICAL PERFORMANCE 45°C, 400LFM, 100% Duty Cycle

Case Configuration	S	F1	F2	F3	F4
Max. Power @ 12Vout	32W	37W	45W	55W	71W
Max. Current @ 3.3Vout	6.4A	7.5A	9A	11A	14A

For complete thermal design support, and the complete list of package options, see our web site at vicr.com/powerstick.

Vicor Corporation Tel: 800-735-6200 • 978-470-2900 • Fax: 978-475-6715

PRELIMINARY

Module Enable/Disable

The module may be disabled by pulling PC below 2.3V with respect to the –Input. This may be done with an open collector transistor, relay, or optocoupler. Multiple converters may be disabled with a single transistor or relay either directly or via "OR'ing" diodes. See Figure 1.

Primary Auxiliary Supply

At 5.7V, PC can source up to 1.5mA. In the example shown in Figure 3, PC powers a Module Enabled LED.




Figure 1—Module enable/disable.




Figure 3—LED on-state indicator.




Figure 5—Isolated on-state indicator.

Vicor Corporation Tel: 800-735-6200 • 978-470-2900 • Fax: 978-475-6715

Module Alarm

The module contains "watchdog" circuitry which monitors input voltage, and internal operating parameters. In the event that any of these parameters are outside of their allowable operating range, the module will shut down and PC will go low. PC will periodically go high and the module will check to see if the fault has cleared. If the fault has not been cleared, PC will go low again and the cycle will restart. The SC pin will go low in the event of a fault and return to its normal state after the fault has been cleared. See Figures 2, 4.




Figure 2—PC/SC module alarm logic.




Figure 4—PC/SC module alarm timing.




Figure 6—Secondary side on-state indicator.

Output Voltage Programming

The output voltage of the converter can be adjusted or programmed via fixed resistors, potentiometers or voltage DACs. See Figures 7 & 8.




Figure 7—Output voltage trim down circuit.

Trim Down

- This converter is <u>not</u> a constant power device it has a constant current limit. Hence, available output power is reduced by the same percentage that output voltage is trimmed down. Do not exceed maximum rated output current.
- 2. The trim down resistor must be connected to the –Sense pin.






Figure 8—Output voltage trim up circuit.

Trim Up

- 1. As output voltage is increased, reduce output current maximum to insure that maximum rated power is not exceeded.
- 2. The trim up resistor must be connected to the +Sense pin.
- 3. Do not trim the converter above maximum trim range (typically +10%) or the output over voltage protection circuitry may be activated.





Vicor Corporation Tel: 800-735-6200 • 978-470-2900 • Fax: 978-475-6715

PRELIMINARY

Parallel Operation

The PR pin supports paralleling for increased power with N+1 (N+M) redundancy and phased array capability (see Phased Array Control Chip at vicr.com). Modules of the same input voltage, output voltage, and power level will current share if all PR pins are suitably interfaced.




Figure 9—DC coupled single-wire interface.

Compatible interface architectures include the following:

DC coupled single-wire interface. All PR pins are directly connected to one another. This interface supports current sharing but is not fault tolerant. Minus In pins must be tied to the same electric potential. See Figure 9.

AC coupled single-wire interface. All PR pins are connected to a single communication bus through .001 μ F (500V) capacitors. This interface supports current sharing and is fault tolerant except for the communication bus. See Figure 10.






Figure 10—AC coupled single-wire interface.









Figure 12—OR'ing diodes connections.




PRELIMINARY



2.45

Щ

Typical Case Configurations For comprehensive thermal management information, visit vicr.com/powerstick



Shock and Vibration rating for standard mounting: 5grms vibration, 500g shock

Vicor Corporation Tel: 800-735-6200 • 978-470-2900 • Fax: 978-475-6715

Page 7

Vicor's comprehensive line of power solutions includes modular, high density DC-DC converters and accessory components, configurable power supplies, and custom power systems.

Information furnished by Vicor is believed to be accurate and reliable. However, no responsibility is assumed by Vicor for its use. No license is granted by implication or otherwise under any patent or patent rights of Vicor. Vicor components are not designed to be used in applications, such as life support systems, wherein a failure or malfunction could result in injury or death. All sales are subject to Vicor's Terms and Conditions of Sale, which are available upon request.

Specifications are subject to change without notice.

The latest data is available on the Vicor web site at vicr.com.



Component Solutions for Your Power System

Vicor Corporation

25 Frontage Road Andover, MA, USA 01810 Tel: 800-735-6200 978-470-2900 Fax: 978-475-6715

Email

Vicor Express: vicorexp@vicr.com Technical Support: apps@vicr.com