




VIM-878



PIN	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36
COM0	1D	1L	2D	2L	3D	3L	4D	4L	5D	5L	6D	6L	7D	7L	8D	8L	COM0	---	---	---	DP8	8M	DP7	7M	DP6	6M	DP5	5M	DP4	4M	DP3	3M	DP2	2M	DP1	1M
COM1	1E	1K	2E	2K	3E	3K	4E	4K	5E	5K	6E	6K	7E	7K	8E	8K	---	---	---	---	8C	8N	7C	7N	6C	6N	5C	5N	4C	4N	3C	3N	2C	2N	1C	1N
COM2	1F	1J	2F	2J	3F	3J	4F	4J	5F	5J	6F	6J	7F	7J	8F	8J	---	---	---	---	8B	8G	7B	7G	6B	6G	5B	5G	4B	4G	3B	3G	2B	2G	1B	1G
COM3	CA1	1I	CA2	2I	CA3	3I	CA4	4I	CA5	5I	CA6	6I	CA7	7I	CA8	8I	---	---	---	---	8A	8H	7A	7H	6A	6H	5A	5H	4A	4H	3A	3H	2A	2H	1A	1H

PIN VERSION

ZEBRA VERSION