Schematic Diagram of MC-019A

NOTICE

Since this is basic circuit diagram, the value of components and some partial connection are subject to be changed for improvement without notice.

The components marked ⚠ conform to VDE or IEC guide-lines and are essential for safe operation of the TV receiver. While those marked ⚠ are required for correct operation. Use specified parts only when replacing.

Value of resistor, capacitor and inductor

1. Resistances are shown in ohm. K=1-000. M=1-000-000.
2. Unless otherwise noted in schematic, all capacitor values less than 1 are expressed in mfd and the values more than 1 in pF.
3. Unless otherwise noted in schematic, all inductor values more than 1 are expressed in uH and the values less than 1 in Henry(nH).

Observation of voltages and waveforms

1. Voltages read with VTVM from point to chassis ground. line voltage is 230V/-20% volts. signal pattern is colour-bar.
2. The schematic shown is representative only.
3. All waveforms are taken using a wide band oscilloscope and a low capacity probe.
4. Check FINE TUNING, AGC, CONTRAST, BRIGHTNESS and COLOUR controls for best picture. Make sure that COLOUR and BRIGHTNESS are in mid-point and CONTRAST is in 75%.
5. Waveforms are taken using a standard colour signal.

<SYSTEM OPTION>

1 RF STEREO

2 AV STEREO

COMPONENT	CL	CE	CT	CF	REMARKS

3 MONO

COMPONENT	CL	CE	CT	CF	REMARKS

P/NO:3854VA0083A-S
2001.04.20

www.DataSheet4U.com