User's Manual



IE-V850E1-CD-NW

PCMCIA Card Type On-Chip Debug Emulator

Document No. U16647EJ1V0UM00 (1st edition) Date Published June 2003 N CP(K)

© NEC Electronics Corporation 2003 Printed in Japan [MEMO]

Windows and Windows NT are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

PC/AT is a trademark of International Business Machines Corporation.

- The information in this document is current as of March, 2003. The information is subject to change without notice. For actual design-in, refer to the latest publications of NEC Electronics data sheets or data books, etc., for the most up-to-date specifications of NEC Electronics products. Not all products and/or types are available in every country. Please check with an NEC Electronics sales representative for availability and additional information.
- No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Electronics. NEC Electronics assumes no responsibility for any errors that may appear in this document.
- NEC Electronics does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from the use of NEC Electronics products listed in this document or any other liability arising from the use of such products. No license, express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Electronics or others.
- Descriptions of circuits, software and other related information in this document are provided for illustrative purposes in semiconductor product operation and application examples. The incorporation of these circuits, software and information in the design of a customer's equipment shall be done under the full responsibility of the customer. NEC Electronics assumes no responsibility for any losses incurred by customers or third parties arising from the use of these circuits, software and information.
- While NEC Electronics endeavors to enhance the quality, reliability and safety of NEC Electronics products, customers agree and acknowledge that the possibility of defects thereof cannot be eliminated entirely. To minimize risks of damage to property or injury (including death) to persons arising from defects in NEC Electronics products, customers must incorporate sufficient safety measures in their design, such as redundancy, fire-containment and anti-failure features.
- NEC Electronics products are classified into the following three quality grades: "Standard", "Special" and "Specific".

The "Specific" quality grade applies only to NEC Electronics products developed based on a customerdesignated "quality assurance program" for a specific application. The recommended applications of an NEC Electronics product depend on its quality grade, as indicated below. Customers must check the quality grade of each NEC Electronics product before using it in a particular application.

- "Standard": Computers, office equipment, communications equipment, test and measurement equipment, audio and visual equipment, home electronic appliances, machine tools, personal electronic equipment and industrial robots.
- "Special": Transportation equipment (automobiles, trains, ships, etc.), traffic control systems, anti-disaster systems, anti-crime systems, safety equipment and medical equipment (not specifically designed for life support).
- "Specific": Aircraft, aerospace equipment, submersible repeaters, nuclear reactor control systems, life support systems and medical equipment for life support, etc.

The quality grade of NEC Electronics products is "Standard" unless otherwise expressly specified in NEC Electronics data sheets or data books, etc. If customers wish to use NEC Electronics products in applications not intended by NEC Electronics, they must contact an NEC Electronics sales representative in advance to determine NEC Electronics' willingness to support a given application.

(Note)

- (1) "NEC Electronics" as used in this statement means NEC Electronics Corporation and also includes its majority-owned subsidiaries.
- (2) "NEC Electronics products" means any product developed or manufactured by or for NEC Electronics (as defined above).

Regional Information

Some information contained in this document may vary from country to country. Before using any NEC Electronics product in your application, please contact the NEC Electronics office in your country to obtain a list of authorized representatives and distributors. They will verify:

- Device availability
- Ordering information
- Product release schedule
- · Availability of related technical literature
- Development environment specifications (for example, specifications for third-party tools and components, host computers, power plugs, AC supply voltages, and so forth)
- Network requirements

In addition, trademarks, registered trademarks, export restrictions, and other legal issues may also vary from country to country.

[GLOBAL SUPPORT] http://www.necel.com/en/support/support.html

NEC Electronics America, Inc. (U.S.) Santa Clara, California	NEC Electronics (Europe) GmbH Duesseldorf, Germany	NEC Electronics Hong Kong Ltd. Hong Kong
Tel: 408-588-6000 800-366-9782	Tel: 0211-65 03 01	Tel: 2886-9318
	 Sucursal en España Madrid Spain 	NEC Electronics Hong Kong Ltd. Seoul Branch
	Tel: 091-504 27 87	Seoul, Korea
	Succursale Française	Tel: 02-558-3737
	Vélizy-Villacoublay, France Tel: 01-30-67 58 00	NEC Electronics Shanghai, Ltd. Shanghai, P.R. China
	• Filiale Italiana Milano, Italy Tel: 02-66 75 41	NEC Electronics Taiwan Ltd. Taipei, Taiwan
	• Branch The Netherlands Eindhoven, The Netherlands Tel: 040-2445845	Tel: 02-2719-2377 NEC Electronics Singapore Pte. Ltd. Novena Square, Singapore
	• Tyskland Filial Taeby, Sweden Tel: 08-63 80 820	Tel: 6253-8311

• United Kingdom Branch Milton Keynes, UK Tel: 01908-691-133

INTRODUCTION

Target Readers	This manual is intended the IE-V850E1-CD-NW functions and usage me	d for users who . It is assumed ethods of the de	design and develop application systems using d that the target readers are familiar with the vices and have knowledge of debuggers.
Purpose	The purpose of this ma NW and its basic specif	nual is to descri fications.	be the proper operation of the IE-V850E1-CD-
Organization	 This manual is divided i Overview Names and functions Cautions on designin Cautions on use 	into the following s of components ng target system	g parts.
How to Read This Manual	It is assumed that the electrical engineering, I This manual explains th To learn about the basi → Read this manual	reader of this n ogic circuits, an ne basic setup p c specifications in the order of t	nanual has general knowledge in the fields of d microcontrollers. rocedure and switch settings. and operation methods he CONTENTS .
	To learn the operation NW → Read the user's n	methods and co nanual of the de	bommand functions, etc., of the IE-V850E1-CD- bugger (included) that is used.
Conventions	Note: Caution: Remark: Numeral representation Prefix indicating the por	Footnote for it Information re- Supplementar Binary ··· xxxx Decimal ··· xx: Hexadecimal ·· wer of 2 (address K (kilo):	em marked with Note in the text quiring particular attention y information c or xxxxB xx ·· xxxxH s space, memory capacity): 2 ¹⁰ = 1024
		M (mega):	$2^{20} = 1024^{2}$

Terminology

The meanings of terms used in this manual are listed below.

Target device	The device that is targeted for emulation.
Target system	The system (user-built system) that is targeted for debugging. This includes the target program and user-configured hardware.
On-chip debug unit	Generic term of macros indicating RCU (run control unit), TEU (trigger event unit), and TRCU (trace control unit). It may be referred to as DCU (debug control unit).
KEL connector	The following products provided by KEL Corporation. 8830E-026-170S (26-pin straight type) 8830E-026-170L (26-pin right-angle type)
MICTOR connector	The following products provided by Tyco Electronic AMP K.K. 2-7670074-2 (38-pin straight type)

Related Documents

When using this manual, refer to the following manuals.

The related documents indicated in this publication may include preliminary versions. However, preliminary versions are not marked as such.

O Documents related to development tools (user's manuals)

Document Name	Document Number	
IE-V850E1-CD-NW PCMCIA Card Type On-	This manual	
CA850 Ver. 2.40 C Compiler Package Operation		U16053E
	C Language	U16054E
	Assembly Language	U16042E
PM Plus Ver. 5.10		U16559E
ID850NWC Ver. 2.51 Integrated Debugger	Operation	To be prepared

Caution The documents listed above are subject to change without notice. Be sure to use the latest documents when designing.

CONTENTS

CHAP	TER 1	OVERVIEW	10
1.1	Featur	es	
1.2	Functi	on Specifications	
1.3	System	n Configuration	13
1.4	Conter	nts in Carton	
CHAP	TER 2	NAMES AND FUNCTIONS OF COMPONENTS	17
2.1	Names	and Functions of Components	
2.2	Conne	ction	
2.3	Startu	p/Termination	21
СНАР	TER 3	NOTES ON TARGET SYSTEM DESIGN	22
3.1	Conne	ction Circuit Example	23
3.2	Interfa	ce Signals	24
	3.2.1	DRST	24
	3.2.2	DCK	24
	3.2.3	DMS	
	3.2.4	DDI	
	3.2.5	DDO	
	3.2.6	VDD	
	3.2.7	FLMD0	
	3.2.8	RESET	27
3.3	IE Con	nection Connector	
	3.3.1	KEL connector	
	3.3.2	MICTOR connector	
	3.3.3	2.54 mm pitch 20-pin general-purpose connector	
СНАР	TER 4	CAUTIONS ON USE	32
APPE	NDIX A	INSTALLATION OF DRIVER	
A.1	Installi	ng in Windows 98	34
A.2	Installi	ng in Windows 2000	
APPE	NDIX B	PACKAGE DIMENSIONS	45
APPE	NDIX C	INTERNAL ROM/FLASH MEMORY SECURITY FUNCTION	48

LIST OF FIGURES

Figure	No. Title	Page
1-1	System Configuration 1 (Recommended)	
1-2	System Configuration 2	14
1-3	System Configuration 3	15
1-4	Contents in Carton	16
2-1	Names of Components	17
2-2	Connecting IE Connection Cable	
2-3	Installing IE-V850E1-CD-NW	
2-4	Connecting to Target System (1)	
2-5	Connecting to Target System (2)	
2-6	Connecting to Target System (3)	
3-1	Connection Circuit Example	
3-2	DRST Pin Connection Example	
3-3	DCK Pin Connection Example	
3-4	DDO Pin Connection Example	
3-5	VDD Pin Connection Example	
3-6	FLMD0 Pin Connection Example <1>	
3-7	FLMD0 Pin Connection Example <2>	
3-8	RESET Pin Connection Example	
3-9	KEL Connector Pin Configuration	
3-10	MICTOR Connector Pin Configuration	
3-11	2.54 mm Pitch Connector Pin Configuration	

Table	No.	Title	
1-1	Function Specifications		
1-2	On-Chip Debug Unit and Debug Function		
3-1	KEL Connector Pin Functions		
3-2	MICTOR Connector Pin Functions		
3-3	2.54 mm Pitch Connector Pin Functions		
A-1	Operating Environment		

LIST OF TABLES

CHAPTER 1 OVERVIEW

The IE-V850E1-CD-NW is an emulator to be connected to a target device with an on-chip debug unit to efficiently debug hardware and software.

1.1 Features

- O General-purpose usage available in microcontrollers with a V850E1 or V850ES Series on-chip debug unit
- O N-Wire interface is adopted for connection between microcontroller and this emulator
- O Debugging is possible with microcontroller mounted in the system to be developed
- O Small PC card type emulator requiring no power supply unit ideal for debugging in the field
- O Downloading program into the flash memory possible using flash self-programming function
- O Usage as a flash programmer possible using flash programmer software (under development)
- O The following shows the dimensions and weight of the IE-V850E1-CD-NW.

Parameter		Value
External dimensions	Height	5.0 mm
(refer to APPENDIX B PACKAGE DRAWINGS)	Width	54.0 mm
	Depth	85.6 mm
Weight		Approximately 32 g

1.2 Function Specifications

Table 1-1.	Function	Specifications
------------	----------	----------------

Parameter	Specification	
Target device	Microcontroller with V850E1, V850ES Series on-chip debug unit Microcontroller with Nx85ET core	
Target voltage	2.0 to 5.0 V	
Target OS	Windows TM 98, Windows Me, Windows 2000, Windows NT TM 4.0, Windows XP	
Target host machine	PC-9821 series, PC-98NX series, IBM PC/AT [™] compatibles with PC card slot conforming to PCMCIA2.1/JEIDA standard Ver. 4.2	
Hardware resources used by host machine	I/O address: 100 H to 3FFH (only 20H bytes are available, specifying either 220H, 260H, 2E0H, 320H, or 3E0H as the base address) Interrupts, others: Not used	
N-Wire interface (on-chip debug unit execution control block)	Number of interface signal pins: 5 Function of interface signal pins (in and out below indicates the direction when seen from the target device) • DCK (in): Clock input • DMS (in): Mode select input • DI (in): Data input • DDO (out): Data output • DRST (in): On-chip debug unit reset input	
Flash writing interface	 Required when the target device includes flash memory. Number of interface signal pins: 1 Function of interface signal pins (in and out below indicates the direction when seen from the target device) FLMD0 (in): Used when writing to the flash memory from the integrated debugger 	
Reset interface	May be required when DRST of the target device is an alternate-function pin and the initial value of the OCDM0 bit in the device changes according to the reset source (refer to 3.2.8 RESET) Number of interface signal pins: 1 Function of interface signal pins (in and out below indicates the direction when seen from the target device) • RESET (in): System reset	
Interface for target power supply detection	Monitors the power supply of the target system Supply V _{DD} for on-chip debugging • V _{DD} (in): V _{DD} for on-chip debugging	
On-chip debug function	Depends on the type of the on-chip debug unit in the target system (refer to Table 1-2)	
Connectors for IE connection (connectors for mounting target system)	 KEL connector (product of KEL Corporation) 8830E-026-170S (26-pin straight type) 8830E-026-170L (26-pin right-angle type) MICTOR connector (product of Tyco Electronic AMP K.K.) 2-7670074-2 (36-pin straight type) 2.54 mm pitch general-purpose connector 	
IE connection cable	500 mm	
Operating environment	Temperature: +0 to +40°C, humidity: 10 to 80%RH (no condensation)	
Storage environment	Temperature: -15 to +60°C, humidity: 10 to 80%RH (no condensation)	

Debug Function	On-Chip Debug Unit Name			
	RCU0 (NB85E901)	RCU1	RCU2 (Under Development)	Nx85ET Core (RCU0 + TEU + TRCU) ^{Note 1}
Internal ROM/flash memory security function	10-byte ID code authentication			
Event detection break function	Break before execution or Access break × 2 (selectable) Break before execution × 2, Break after execution × 2, Access break × 4			
Software break function	2000 points 0 to 8 points can be assigned to the internal ROM/flash memory area at one time ^{Note 2}			
Forced break function	Provided			
Execution function	Go (free-run), execution from cursor position, restart, step execution			
RM, DMM function ^{№ote 3}	Provided			
Register manipulation function	Provided			
Mask function	Not provided	Resolution: 100 ns, Maximum measurement time: 3 min. 30 sec.		Not provided
Trace function	Not provided		Provided ^{Note 4}	Not provided ^{Note 5}

Table 1-2. On-Chip Debug Unit and Debug Function

Notes 1. The Nx85ET core is a CPU core in which RCU, TEU, and TRCU macros are incorporated.

2. The number of points depends on the device. This function cannot be used when the flash selfprogramming function is used.

- RM (RAM Monitor): Function that read the contents of the memory during program execution DMM (Dynamic Memory Modification): Function that rewrites the contents of the RAM during program execution
- 4. The latest 8 trace conditions are traced.

The trace conditions (branch source, branch destination, write access) can be set.

5. The trace function of the Nx85ET core is realized by using the trace interface. This emulator does not feature a trace interface, so the trace function cannot be used.

1.3 System Configuration

The following shows the system configuration when connecting the IE-V850E1-CD-NW.



Figure 1-1. System Configuration 1 (Recommended)









1.4 Contents in Carton

The carton of the IE-V850E1-CD-NW contains the following. Check for any missing items. If there are missing or damaged items, please contact an NEC Electronics sales representative or an NEC Electronics distributor. Return the guarantee card included in the carton after filling in all the items.



Figure 1-4. Contents in Carton

CHAPTER 2 NAMES AND FUNCTIONS OF COMPONENTS

This chapter describes the names and functions of components, and connections with related devices of the IE-V850E1-CD-NW.

2.1 Names and Functions of Components



Figure 2-1. Names of Components

- <1> IE-V850E1-CD-NW
- <2> IE connection cable (included) <2>-1: HIF3BA-20-20D-2, 54C (product of Hirose Electric Co., Ltd.)
- <3> Connector conversion board (KEL adapter) (included) <3>-1: HIF3FC-20PA-2, 54DS (product of Hirose Electric Co., Ltd.) <3>-2: 8802-026-170L (product of KEL Corporation)

2.2 Connection

The following describes the connection between the IE-V850E1-CD-NW and related devices.

(1) Connecting the IE connection cable

Connect the IE connection cable to the IE-V850E1-CD-NW before connecting the IE-V850E1-CD-NW to the host machine.

At this time, do not connect the IE connection cable and the IE connector on the target.

Connect the IE connection cable to the IE-V850E1-CD-NW pressing the portions indicated by *, as shown in Figure 2-1.

The portions indicated by * must also be pressed when disconnecting the IE connection cable.

Figure 2-2. Connecting IE Connection Cable



(2) Inserting the IE-V850E1-CD-NW

Insert the IE-V850-CD-NW in the PC card slot on the host machine.





(3) How to connect to the target system differs depending on the IE connector type.

Caution Be sure to turn off the power to the target system before connecting to or disconnecting from the target system.

<1> When the 8830E-026-170S (included) is used as the IE connector

Connect the IE connection cable to the connector conversion board (included) and connect it to the target system. At this time, align the position of pin 1 (mark \triangle) of both sides.



Figure 2-4. Connecting to Target System (1)

<2> When the 8830E-026-170L (sold separately) is used as the IE connector Connect the IE connection cable to the connector conversion board (included) and connect it to the target system. At this time, align the position of pin 1 (mark △) of both sides.





<3> When the 2.54 mm pitch general-purpose connector (sold separately) is used as the IE connector Connect the IE connection cable to the target system. At this time, align the position of pin 1 (mark ▲) of both sides.



Figure 2-6. Connecting to Target System (3)



2.3 Startup/Termination

The following describes the procedures for startup and termination.

To operate the IE-70000-MC-NW-A, a dedicated debugger is required. For details, refer to the ID850NWC Integrated Debugger Ver.2.51 or Later Operation (Windows Based) User's Manual (U16525E).

(1) Startup procedure

<1> Apply power to the host machine and start the OS.

Install the integrated debugger, device file, and driver, if they have not been installed. (See **APPENDIX A** for the installation procedure of the driver, and the **ID850NWC Integrated Debugger Ver. 2.51 or Later Operation (Windows Based) User's Manual (U16525E)** for the installation procedure of the integrated debugger and device file.)

- <2> Apply power to the target system.
- <3> Start the integrated debugger.
- <4> If the target device includes internal ROM/flash memory, flash security ID code authentication must be performed in the integrated debugger. (See **APPENDIX C** for details of the ID code.)

(2) Termination procedure

- <1> Terminate the debugger.
- <2> Shutdown the power to the target system.
- <3> Shutdown the OS in the host machine and shutdown the power to the host machine.

CHAPTER 3 NOTES ON TARGET SYSTEM DESIGN

To debug the target system with the IE-V850E1-CD-NW connected, a circuit to connect the IE-V850E1-CD-NW is required on the target system.

For details, refer to the user's manual of the target device.

3.1 Connection Circuit Example

The following shows a connection circuit example of the target system required when connecting the IE-V850E1-CD-NW. For details, refer to the user's manual of the target device.



Figure 3-1. Connection Circuit Example

- Cautions 1. Keep the pattern length as short as possible. (Do not exceed 100 mm.)
 - 2. VDD of the IE connector is used for detecting whether the target board is powered on.
 - 3. The DCK, DMS, DDI, DDO, and DRST pins may function alternately as general-purpose ports. Therefore handle these pins in accordance with the specifications of each target device.
 - 4. Make sure that the signals driven from the IE-V850E1-CD-NW and the signals generated on the target system do not conflict.
 - 5. FLMD0 is connected only when the target device incorporates flash memory.
 - 6. **RESET** may be required when both of the following conditions are satisfied.
 - DRST of the target device has an alternate function
 - The IE-V850E1-CD-NW is connected to a target system that only uses the POC reset function, without using the RESET pin function
 - 7. Supply the on-chip debug power supply for VDD.

3.2 Interface Signals

This section describes the interface signals.

3.2.1 DRST

This is the reset input signal for the on-chip debug unit. This is a negative logic signal for initializing the debug control unit asynchronously. Barring a problem arising from the specifications of the target device, <u>pull down this signal to low level</u>.



Figure 3-2. DRST Pin Connection Example

Upon detection of V_{DD} of the target system following integrated debugger startup by the IE-V850E1-CD-NW, the DRST signal changes from low level to high level to start the on-chip debug unit of the target device.

The change of the DRST signal from low level to high level also resets the CPU.

When debugging is started by starting up the integrated debugger, CPU reset always occurs.

3.2.2 DCK

This is the clock input signal. This signal supplies a 20 MHz clock from the IE-V850E1-CD-NW. The DMS and DDI signals are sampled in synchronization with the rising edge of the DCK signal in the on-chip debug unit, and the data DDO signal is output in synchronization with the falling edge of the DCK signal. Barring a problem arising from the specifications of the target device, <u>pull up this signal to high level</u>.



Figure 3-3. DCK Pin Connection Example

3.2.3 DMS

This is the transfer mode selection signal. The state machine in the debug unit changes according to the level of the DMS signal. This signal is sampled in synchronization with the rising edge of the DCK signal in the on-chip debug unit.

Barring a problem arising from the specifications of the target device, <u>pull up this signal to high level</u>. The connection example for this signal is the same as that shown in **Figure 3-3 DCK Pin Connection Example**.

3.2.4 DDI

This is the data input signal. This signal is sampled in synchronization with the rising edge of the DCK signal in the on-chip debug unit.

Barring a problem arising from the specifications of the target device, <u>pull up this signal to high level</u>. The connection example for this signal is the same as that shown in **Figure 3-3 DCK Pin Connection Example**.

3.2.5 DDO

This is the data output signal. This signal is output in synchronization with the falling edge of the DCK signal from the on-chip debug unit.

Barring a problem arising from the specifications of the target device, pull up this signal to high level.



Figure 3-4. DDO Pin Connection Example

3.2.6 VDD

This signal is used for detection of V_{DD} of the target system. The interface with the target system (detection range) is 2.0 V to 5.0 V. If V_{DD} from the target system is not detected, the DRST, DCK, DMS, DDI, FLMDO, and RESET pins go to a high-impedance state.





3.2.7 FLMD0

This is the flash mode signal. It is used only when the target device incorporates flash memory.

The flash self-programming function is used for the download function for downloading to the flash memory using the integrated debugger. The FLMD0 pin must be made high level during flash self-programming.

There are two methods for controlling the FLMD0 pin from the IE-V850E1-CD-NW. Either one can be selected for use.

<1> Control from IE-V850E1-CD-NW

Connect the FLMD0 pin from the IE-V850E1-CD-NW to the FLMD0 pin of the target device.

In the normal mode, nothing is driven from the IE-V850E1-CD-NW.

When, during a break, the download function, etc., of the integrated debugger is executed, the FLMD0 pin from the IE-V850E1-CD-NW is controlled to be high level. Barring a problem arising from the specifications, pull down the FLMD0 pin to low level.





<2> Control from port

Connect an unused port of the target device to the FLMD0 pin.

The same port pin (PORT in Figure 3-7) can be used with no problem to realize the flash self-programming function in the user program using a similar method. Barring a problem arising from the specifications, <u>pull</u> <u>down this pin to low level</u>.

Perform settings to make the port pin high level prior to executing the download function and make the port pin low level or high impedance after executing the download function, through the integrated debugger console. (For details, refer to the **ID850NWC Integrated Debugger Ver. 2.51 or Later Operation** (Windows Based) User's Manual (U16525E).)

Figure 3-7. FLMD0 Pin Connection Example <2>



3.2.8 **RESET**

This is the system reset input signal. If the \overline{DRST} pin of target device is an alternate-function pin, \overline{DRST} can be enabled/disabled by the value of the OCDM0 bit in the device. Some devices have specifications such that the initial status of the alternate-function pin varies according to the reset source, so that in the case of reset via the RESET pin, \overline{DRST} is enabled when OCDM0 = 1, and in the case of reset via POC (Power-On Clear function), \overline{DRST} is disabled when OCDM0 = 0.

In the case of a target system where only reset via POC is used in such a device, $\overline{\text{DRST}}$ cannot be enabled, and therefore on-chip debugging cannot be performed. In such a case, the $\overline{\text{DRST}}$ pin is enabled by performing the connection shown in Figure 3-8 and applying reset via the $\overline{\text{RESET}}$ pin from the IE-V850E1-CD-NW.



Figure 3-8. RESET Pin Connection Example

3.3 IE Connection Connector

For connection to the IE-V850E1-CD-NW, an IE connection connector must be mounted on the target system. The IE connection connector can be selected from among the following.

- KEL connector (recommended)
- MICTOR connector^{Note 1}
- 2.54 mm pitch 20-pin general-purpose connector^{Note 2}
- **Notes 1.** The MICTOR connector is conventionally supported as an IE connection connector that supports the high-speed trace interface. As this product does not support the high-speed trace interface, the MICTOR connector cannot be selected for this product.

To connect this product using the MICTOR connector, a MICTOR adapter (sold separately), which is a connector conversion board, is required. Either the B-137 (right-angle version) or the B-137A (straight version), both made by Lightwell Co., Ltd., can be used as the MICTOR adapter.

2. If the 2.54 mm pitch 20-pin general-purpose connector (sold separately) is selected, note that connection to the on-chip debug emulators of some third-party manufacturers is not possible.

3.3.1 KEL connector

If using the KEL connector as the IE connection connector, mount one of the following connectors on the target system.

- 8830E-026-170S: 26-pin straight type (included)
- 8830E-026-170L: 26-pin right-angle type (sold separately)

Remark The 8830E-026-170S and 8830E-026-170L are products of KEL Corporation.

Figure 3-9 and Table 3-1 show the IE connection connector pin configuration and the pin functions, respectively. Input/output is indicated as seen from the target device.

Figure 3-9. KEL Connector Pin Configuration



Pin No.	Signal Name	I/O	Description
A1 to A6	GND	-	Connect to GND
A7	DDI	IN	Data input
A8	DCK	IN	Clock input
A9	DMS	IN	Transfer mode selection input
A10	DDO	OUT	Data output
A11	DRST	IN	Reset input to on-chip debug unit
A12	RESET	IN	System reset input (leave open when not used) ^{Note 1}
A13	FLMD0	IN	Flash mode input (leave open when not used)Note 2
B1 to B10	GND	-	Connect to GND
B11	PORT0_IN	-	Connect to GND
B12	PORT1_IN	-	Connect to GND
B13	Vdd	_	Connect to V _{DD} for on-chip debugging (for target system power ON monitoring)

Table 3-1. KEL Connector Pin Functions

Notes 1. This may be required if DRST of the target device is an alternate-function pin and the initial value of the OCMD0 bit changes according to the reset source. (Refer to section **3.2.8** RESET.)

2. This is required when the target device incorporates flash memory.

3.3.2 MICTOR connector

When using the MICTOR connector as the IE connection connector, mount the following connector on the target system.

2-767004-2: 38-pin type (sold separately)

Remark The 2-767004-2 is a product of Tyco Electronics AMP K.K.

Figure 3-10 and Table 3-2 show the IE connector pin configuration and the pin functions, respectively. Input/output is indicated as seen from the target device.



Figure 3-10. MICTOR Connector Pin Configuration

Pin No.	Signal Name	I/O	Description	
1 and 2	GND	-	Connect to GND	
3	DCK	IN	Clock input	
4	Vdd	_	Connect to V _{DD} for on-chip debugging (for target system power ON monitoring)	
5	DMS	IN	Transfer mode selection input	
6	DRST	IN	Reset input to on-chip debug unit	
7	DDI	IN	Data input	
8	RESET	IN	System reset input (leave open when not used) ^{Note 1}	
9	DDO	OUT	Data output	
10	FLMD0	IN	Flash mode input (leave open when not used)Note 2	
11	N.C	-	Open (not connected)	
12	RESERVE	-	Open	
13	N.C	_	Open (not connected)	
14	PORT0_IN	-	Connect to GND	
15	N.C	-	Open (not connected)	
16	PORT1_IN	-	Connect to GND	
17	GND	-	Connect to GND	
18	PORT2_IN	-	Connect to GND	
19	GND	-	Connect to GND	
20	RESERVE	-	Open	
21 to 38	GND	-	Connect to GND	

 Table 3-2.
 MICTOR Connector Pin Functions

Notes 1. This may be required if DRST of the target device is an alternate-function pin and the initial value of the OCMD0 bit changes according to the reset source. (Refer to section 3.2.8 RESET.)
 2. This is required when the target device incorporates flash memory.

3.3.3 2.54 mm pitch 20-pin general-purpose connector

If using a 2.54 mm pitch general-purpose connector as the IE connector, mount a connector that can be connected to the IE connection cable on the target system.

Figure 3-11 and Table 3-3 show the IE connector pin configuration and the pin functions, respectively.





Pin No.	Signal Name	I/O	Description	
1	GND	-	Connect to GND	
2	DCK	IN	Clock input	
3	GND	-	Connect to GND	
4	DMS	IN	Transfer mode selection input	
5	GND	-	GND	
6	DDI	IN	Data input	
7	GND	-	Connect to GND	
8	DRST	IN	Reset input to on-chip debug unit	
9	GND	-	Connect to GND	
10	RESERVE	-	Open	
11	GND	-	Connect to GND	
12	RESET	IN	System reset input (leave open when not used)Note 1	
13	GND	-	Connect to GND	
14	FLMD0	IN	Flash mode input (leave open when not used)Note 2	
15	GND	-	Connect to GND	
16	RESERVE	-	Open	
17	GND	_	Connect to GND	
18	DDO	OUT	Data output	
19	GND	-	Connect to GND	
20	Vdd	-	Connect to V_{DD} for on-chip debugging (for target system power ON monitoring)	

Notes 1. This may be required if DRST of the target device is an alternate-function pin and the initial value of the OCMD0 bit changes according to the reset source. (Refer to section **3.2.8** RESET.)

2. This is required when the target device incorporates flash memory.

CHAPTER 4 CAUTIONS ON USE

Observe the following cautions on use to avoid damaging the IE-V850E1-CD-NW.

- O Do not place heavy objects on the IE-V850E1-CD-NW, or apply pressure to it.
- O Do not drop the IE-V850E1-CD-NW, or subject it to physical shock or vibration.
- O Do not use the IE-V850E1-CD-NW in a hot, humid or dusty environment. Avoid using or storing the IE-V850E1-CD-NW in a location where it is exposed to direct sunlight.
- O Avoid subjecting the IE-V850E1-CD-NW to sudden environmental changes (in temperature or humidity).
- O Do not spill liquids on the IE-V850E1-CD-NW.
- O Do not use the connectors or cables of a different product.

APPENDIX A INSTALLATION OF DRIVER

The IE-V850E1-CD-NW is used inserted in the PC card slot on the host machine. The driver must be installed before using the IE-V850E1-CD-NW. The driver is included in the CD-ROM supplied with the IE-V850E1-CD-NW. It can also be downloaded from the website of NEC Electronics (http://www.necel.com/micro/).

The driver is common to the NEC Electronics PC interface card (IE-70000-CD-IF-A).

Refer to "\ID850NWC\DRIVER\README_E.TXT" on the CD-ROM for how to install the driver.

A.1 explains the procedure to install the IE-V850E1-CD-NW driver in Windows 98, and A.2 explains the procedure in Windows 2000.

Target OS	Windows 98, Windows Me, Windows 2000, Windows NT 4.0, Windows XP
Target host machine	PC-9821 series, PC98-NX series, IBM PC/AT compatible machine with PCMCIA2.1/JEIDA standard Ver4.2-compliant PC card slot
Hardware resources used by the host machine	 I/O address: 100H to 3FFH (Only 20H bytes are available, specifying either 220H, 260H, 2E0H, 320H, or 3E0H as the base address.) Interrupts: Not used

Table A-1. Operating Environment

A.1 Installing in Windows 98

This section explains the procedure to install the driver when using Windows 98.

Installation method

The following describes the step-by-step installation procedure. The CD-ROM drive is assumed as E: in the explanation below.

- Step 1Shutdown Windows 98 and turn off the power of the host machine.Shutdown Windows 98 and turn off the power of the host machine.
- Step 2 Insert the IE-V850E1-CD-NW in an open PC card slot. Insert the IE-V850E1-CD-NW in the PC card slot on the host machine in the direction of the arrow on the surface (refer to Figure 2-3 Installing IE-V850-CD-NW).
- Step 3 Turn on the power to the host machine and activate Windows 98. Apply the power to the host machine and activate Windows 98.

Step 4 Install the driver by Plug&Play of Windows 98.

(1) While Windows 98 is being activated, the [Add New Hardware Wizard] window appears. Click [Next].



(2) Select "Search for the best driver for your device. (Recommended)" and click [Next].

Add New Hardware Wiz	ard
	 What do you want Windows to do? Search for the best driver for your device. [Recommended]. Display a list of all the drivers in a specific location, so you can select the driver you want.
	< <u>B</u> ack Next > Cancel

(3) Insert the attached CD-ROM in the CD-ROM drive.

(4) Select "Specify a location:", input "E:\ID850NWC\DRIVER\WIN9X\CD-IF", and then click [Next]. Alternately, click [Browse], select "E:\ID850NWC\DRIVER\WIN9X\CD-IF" from the drop-down list, click [OK], and then click [Next].



Browse for Folder	<
Select the folder that contains driver information (.INF file) for this device.	
Driver Win2000 Win9x Win9x Winnt Winnt Winnt Ontrol Panel Dial-Up Networking Scheduled Tasks My Documents Wy Documents Wew Folder	
OK Cancel	

(5) "NEC IE-PC Interface Card [PCMCIA IF Card]" is displayed. Click [Next]. The necessary files are then automatically copied.



Copying Files			
Source : E:¥ID850NWC¥DRIVER¥WIN9X¥CD-IF¥NECPCIF.VXD			
Destination : C:¥WINDOWS¥SYSTEM¥NECPCIF.VXD			
100%			
[Cancel]			

(6) Installation is complete. Click [Finish]. Activation of Windows 98 then continues.



A.2 Installing in Windows 2000

This section explains the procedure to install the driver when using Windows 2000.

Installation method

The following describes the step-by-step installation procedure. The CD-ROM drive is assumed as E: in the explanation below.

- Step 1 Shutdown Windows 2000 and turn off the power of the host machine. Shutdown Windows 2000 and turn off the power of the host machine.
- Step 2 Insert the IE-V850E1-CD-NW in an open PC card slot. Insert the IE-V850E1-CD-NW in the PC card slot on the host machine in the direction of the arrow on the surface (refer to Figure 2-3 Installing IE-V850-CD-NW).

Step 3 Turn on the power to the host machine and activate Windows 2000.

Apply the power to the host machine and activate Windows 2000.

Step 4 Install the driver by Plug&Play of Windows 2000.

(1) While Windows 2000 is being activated, the [Found New Hardware Wizard] window appears. Click [Next].

Found New Hardware Wizard			
	Welcome to the Found New Hardware Wizard This wizard helps you install a device driver for a hardware device.		
	< Back (Next >	Cancel	

(2) Select "Search for a suitable driver for my device (recommended)" and click [Next].

Found New Hardware Wizard
Install Hardware Device Drivers A device driver is a software program that enables a hardware device to work with an operating system.
This wizard will complete the installation for this device:
Lightwell/ZAX PC_CardI/F32
A device driver is a software program that makes a hardware device work. Windows needs driver files for your new device. To locate driver files and complete the installation click Next.
What do you want the wizard to do?
 Search for a suitable driver for my device (recommended)
Display a list of the known drivers for this device so that I can choose a specific driver
< <u>B</u> ack <u>N</u> ext > Cancel

(3) Select "Specify a location" and click [Next].

Found New Hardware Wizard	
Locate Driver Files Where do you want Windows to search for driver files?	
Search for driver files for the following hardware device:	
Lightwell/ZAX PC_Cardl/F32	
The wizard searches for suitable drivers in its driver database on your computer and in any of the following optional search locations that you specify.	
To start the search, click Next. If you are searching on a floppy disk or CD-ROM drive, insert the floppy disk or CD before clicking Next.	
Optional search locations:	
Floppy disk drives	
CD-ROM drives	
Specify a location	
Microsoft Windows Update	
< <u>B</u> ack <u>N</u> ext > Cance	el

(4) Insert the attached CD-ROM in the CD-ROM drive and input "E:\ID850NWC\DRIVER\WIN2000" in the "Copy manufacturer's files from:" field and click [OK].



(5) Click [Next].

Found New Hardware Wizard
Driver Files Search Results The wizard has finished searching for driver files for your hardware device.
The wizard found a driver for the following device:
Lightwell/ZAX PC_CardI/F32
Windows found a driver for this device. To install the driver Windows found, click Next.
e:\id850nwc\driver\win2000\cd-if.inf
< <u>B</u> ack <u>Next</u> > Cancel

(6) The [Insert Disk] window is displayed. Click [OK].



(7) The [Files Needed] window is displayed. Click [Browse] to open the [Locate File] window. Specify NECPCIF.SYS, click [Open], and then click [OK].

Files Need	ed	×
$\underline{\mathfrak{D}}$	Some files on NEC IE-PC Driver Installation Disk are needed.	OK Cancel
	Insert NEC IE-PC Driver Installation Disk into the drive selected below, and then click OK.	
	Copy files from: e:\id850nwc\driver\win2000	Browse

Locate File					<u>? ×</u>
Look jn:	🔁 WIN2000		•	+ 🗈 💣 🎟+	
History	NECPCIF.SYS				
Desktop					
My Computer					
Mu Network P	File <u>n</u> ame:	NECPCIF.SYS		~	<u>O</u> pen
My Network P	Files of <u>type</u> :	Necpcif.sys;Necpcif.sy_		7	Cancel

(8) The necessary files are automatically copied.

Copying Files	X
leif.cpl To C:\WINNT\System32	
	Cancel

(9) The message "Completing the Found New Hardware Wizard" is displayed. Click [Finish]. Activation of Windows 2000 then continues.



(1) IE-V850E1-CD-NW (unit: mm)



(2) IE connection cable (unit: mm)





(3) Connector conversion board (unit: mm)

APPENDIX C INTERNAL ROM/FLASH MEMORY SECURITY FUNCTION

A ten-byte ID code authentication function is provided in the microcontrollers with internal ROM/flash memory to prevent the memory contents from being read by an unauthorized person.

The ID code specifications are as follows. Embed the ID code in the internal ROM/flash memory in accordance with these specifications. Input the ID code in the Configuration dialog box of the integrated debugger to execute ID code authentication before starting debugging (reading the code of the internal ROM/flash memory of the target device) using the integrated debugger and the IE-V850E1-CD-NW.

[ID code specifications]

- Addresses 0x70 to 0x79 are used as the 10-byte ID code.
- Bit 7 at address 0x79 is used as the N-Wire emulator use enable flag (use disabled if "0", and enabled if "1").
- Debugging can be started if the ID code input in the integrated debugger and the ID code embedded in the internal ROM/flash memory match.
- Even if the ID code matches, debugging cannot be performed if the N-Wire emulator use enable flag is "0".

An example of the ID code setting is shown below.

Example) When the following values are set to addresses 0x70 to 0x79



The ID code input in the Configuration dialog box of the integrated debugger ID850NWC is **123456789ABCDEF123D4** or **123456789abcdef123d4**.