

# ST7MDTx-KIT

# ST7 MCU STARTER KIT

Each ST7 Starter kit includes all you need to get started with the selected ST7 devices.

#### **Hardware Features**

- EPROM Programming Board (EPB)
- 13.5 V Power Supply
- Interface Cable for connection to PC parallel port (LPT)
- EPROM Sample Devices:
  - MDT1:
    - 2 x ST72E251G2 (CERDIP 32-pin)
  - MDT2: ST72E311N4D0S (CERDIP 56-pin) ST72E311J4D0S (CERDIP 42-pin)
  - MDT4: ST72E272K4D0 (CERDIP 32-pin) ST72E372J4D0 (CERDIP 42-pin) ST72E671N6D0 (CERDIP 56-pin)

#### Software Features (ST7 CDROM)

- Software Development Tools for Windows 3.11, Windows 95 and Windows NT:
- ST Assembler, Linker, Librarian and Formatter
- WGDB7 Simulator/Debugger
- EPROMer Utility
- Demo Version of Hiware C Toolchain
- Application Notes with source code software examples.
- ST7 Instruction Set Help File



# Table of Contents

ST7	MDTx-KIT	1
1 OVE	RVIEW	3
1.1	MDT1 BOARD LAYOUT	3
1.2	MDT2 BOARD LAYOUT	4
1.3	MDT4 BOARD LAYOUT	5
1.4	SOFTWARE	6
	1.4.1 Tools	6
	1.4.2 ST Assembly Chain for the ST7 Family	6
2 MET	HOD OF OPERATION	7
2.1	SOFTWARE INSTALLATION	7
2.2	USING THE ST ASSEMBLY CHAIN 1	1
2.3	STARTING THE WGDB7 DEBUGGER 1	1
2.4	PROGRAMMING ST7 DEVICES 1	2
	2.4.1 Target Devices	2
	2.4.2 Board and Device Setting Up 1	2
	2.4.3 Starting the Windows Epromer 1	3
	2.4.4 Configuring the Epromer 1	4



### **1 OVERVIEW**

57

#### **1.1 MDT1 BOARD LAYOUT**



3/17

#### **1.2 MDT2 BOARD LAYOUT**



#### **1.3 MDT4 BOARD LAYOUT**



#### **1.4 SOFTWARE**

#### 1.4.1 Tools

To help you design and program your applications, the following software has been included in the Starter Kit:

- ST Assembly Chain
- ST7 Simulator
- Windows Epromer for ST7 MCUs

A stand-alone ST7 instruction help file is also available. In many circumstances, it will help you select the most suitable code for your programs and improve the overall performance of your applications.

#### 1.4.2 ST Assembly Chain for the ST7 Family

The ST Assembly Chain is a cross development system for ST7-driven applications. It includes an assembler, a linker, a formatter and a librarian.

The information flow is summarized in the chart below:



## **2 METHOD OF OPERATION**

#### 2.1 SOFTWARE INSTALLATION

67/

To install and setup the Starter Kit software, follow these steps:

- 1 Insert the delivery CD-ROM into your CD-ROM drive.
- 2 Using Windows Explorer, open the root directory of your CDROM drive.

IF	THEN
Acrobat Reader is already installed on your system.	Double-Click WELCOME.pdf. When the Welcome screen is displayed, click FREEWARE
Acrobat Reader is not yet	1. Open the folder /PROGRAM/ACROBAT3
installed on your system.	<ol> <li>Select and install the approriate language version of Acrobat (for more details refer to the readme.txt in the CDROM root directory)</li> </ol>
	3. When Acrobat is installed, double-click WELCOME.pdf. When the Welcome screen is displayed, click FREEWARE



#### ST7MDTX-KIT

The *ST7 Tool Chain Setup* introductory window appears on your screen, referring to the three software components of the Starter Kit:

- WGDB7 Debugger
- ST Assembly Chain for the ST7 Family
- ST7 Epromer

Click Next to continue.

3 In the next window, *Choose Destination Location*, you will specify the folder (or directory) where to copy the whole Starter Kit software. Use the default folder (or directory) or choose another folder (or directory):

Choose Destination Loc	cation
	Setup will install ST7 Toolchain in the following folder.
	To install to this folder, click Next.
	To install to a different folder, click Browse and select another folder.
	You can choose not to install ST7 Toolchain by clicking Cancel to exit Setup.
	Click here to select another pa
<b>N</b>	This is the default path
	Destination Folder
	C:\St7toolsBIOWSE
	< <u>Back</u> <u>Next&gt;</u> Cancel
Retu	rn to previous window Abort installation process
	Continue installation process

Click Next to continue.

4 In the next window, *Select Components*, you will select the software components that are to be copied from the CD-ROM into the folder (directory) you specified before:

Select Components         Select a component, check the appropriate box you do not want to install.	Selecting the WGDB7 Debugger cause these subcomponents to be displayed
Components         Wgdb7 Debugger 4352 K         St Assembly Chain 794 K         Windows Epromer 584 K         Description         This component includes Wgdb7 application files.         Space Required: 5732 K	When WGDB7 is selected, this line is always highlighted Option applicable only to emulation-aided debugging (not supported in this version of the Starter Kit)
< Back     Next>     Cancel       Return to previous window     Abor       Continue installation proce	t installation process

Click Next to continue.

- 5 The next window, *Check Setup Information*, displays the settings you have specified:
- Destination folder (directory)
- Components to be installed

Click **Next** to confirm. Click **Back** to change any settings.

**6** The copying process takes place. A progress indicator keeps you informed of the status of the operation.

When the copying process terminates, and if you didn't select the *ST Assembly Chain* as a component to be installed, you are directed to the *Setup Complete* window (see further on).

If you selected the *ST Assembly Chain*, you are prompted to modify your AUTOEXEC.BAT file (or your system registry).

**[]** 

These changes affect:

- the **PATH** option, where the path for the components of the Assembly Chain should be added,
- the **METAI** and **DOS4G** environment variables that have to be set to the following values, respectively:

```
SET METAI=C:\<install folder>\asm
```

```
where <install folder> is the installation root folder (directo-
ry), St7tools by default.
SET DOS4G=QUIET
```

You may let the system proceed to the changes or make the changes by yourself. In any case, for the modifications to be effective, you will have to reboot the system. If you make the changes by yourself, the values to be typed can be found in:

```
C:\<install folder>\asm\St7vars.bat
where <install folder> is the installation root folder (directo-
ry), St7tools by default.
```

For more information refer to the ST7 Software Tools for the ST7 Family User Manual.

You are then directed to the *Setup Complete* window.



By checking the appropriate box, you may display a Release Note for the WGDB7 Debugger, Version 2.0, and/or start a debugging session, immediately after the installation is completed.



### 2.2 USING THE ST ASSEMBLY CHAIN

The **ST** Assembly Chain components are installed in a subdirectory of the installation root directory, named asm.

By default, you will find all the software development tools that constitute the *ST* Assembly *Chain* in:

#### C:\St7tools\asm

For more information on how to develop applications or programs for the ST7 microcontroller, refer to the *Software Tools for the ST7 Family* User Manual included in the CD-ROM.

#### 2.3 STARTING THE WGDB7 DEBUGGER

The WGDB7 debugger is installed in the installation root directory. By default, you will find it in:

C:\St7tools

To start WGDB7, just click the corresponding icon (or name in the cascading menus) in the Windows desktop. The WGDB7 Introductory window appears:



You will notice that this is the simulation-aided version of the debugger in which the behaviour of your program is just *simulated*, using a special software, as if it were running on an actual microcontroller. To debug it, you don't need any external hardware.

The debugging session starts a few seconds later.

To get accustomed to the product, you may start one of the sample programs provided with the package, via the *File/Open* debugger menu chain.

The sample programs can be found in:

C:\<install folder>\sample

where <install folder> is the installation root folder (directory), st7tools by default.

For more information on how to use the WGDB7 Debugger, refer to the WGDB7 Windows Debugger for the ST7 Family User Manual included in the CD-ROM.

#### 2.4 PROGRAMMING ST7 DEVICES

#### 2.4.1 Target Devices

Once bug-free and ready for operation, the program you just developed needs to be transferred into an ST7 MCU program space.

With the ST7 MDT1 Starter Kit, you may program these MCUs(\*):

```
ST72101G1 or G2
ST72212G2
ST72213G1
ST72251G1 or G2
```

With the ST7 MDT2 Starter Kit, you may program these MCUs (\*):

```
      ST72121J2
      or
      J4

      ST72311J2
      or
      J4

      ST72311N2
      or
      N4

      ST72331J2
      or
      J4

      ST72331J2
      or
      J4
```

With the ST7 MDT4 Starter Kit, you may program these MCUs (\*):

```
ST72272K2 or K4
ST72372J4
ST72371N4
ST72671N4 or N6
```

(\*) These lists are subject to modifications

#### 2.4.2 Board and Device Setting Up

Proceed as follows:

- Place the device into the Zero Insertion Force (ZIF) socket mounted on the board.
   CAUTION. Ensure correct device orientation when plugging it into the ZIF socket. Incorrect insertion may damage the device and/or the board.
- **2** Using the parallel interface cable, connect the parallel port of the PC (LPT1 or LPT2) to the board connector (PI).

**ل رکم** 

**3** Power on the PC and the board. The board power LED (LD1) lights up.

#### Notes

**لركم** 

The parallel port of your PC should have been configured as a Centronics parallel port.

The supplied interface cable has been tested in order to operate properly on most PCs. Do not use any other cable, especially if it is longer than the one provided by STMicroelectronics: the board may not operate properly.

The cable should be connected directly to the DB-25 female connector of the PC parallel port. This connector is similar to the one installed on the board. Do not insert any additional cables or switchboxes between the PC and the board: a malfunctioning of the board may result.

If a dongle is mounted on the PC parallel port, it should not interfere with the programming board. Should you notice a dysfunctioning of the board, remove the dongle and restart the installation procedure.

#### 2.4.3 Starting the Windows Epromer

The Windows Epromer (Winee) is installed in the installation root directory. By default, you will find it in:

#### C:\St7tools\Epromer

To start the Windows Epromer, just click the corresponding icon (or name in the cascading menus) in the Windows desktop. The Epromer main window appears:



13/17

#### 2.4.4 Configuring the Epromer

Follow these steps:

1 In the main window tool bar, click the dow<sup>.</sup> dow:

icon to select the epromer configuration win-

57

Epromer Configuration	×
Attached EPROMER hardware: ST7MDT1-KIT ST7MDT2-KIT ST7MDT4-KIT ST7MDT1-EPB ST7MDT2-EPB ST7MDT3-EPB ST7MDT4-EPB	Connected on :
Epromer : ST7MDT1-KIT Chip: ST72101G1-SDIP32	Port: LPT1
OK Cancel	Apply Help

2 In the list, select the programming board for the Starter Kit:

ST7MDT1-KIT, ST7MDT2-KIT or ST7MDT4-KIT,

3 Click the Select Chip tab to display the list of the devices that can be programmed with this Starter Kit.

A list box similar to the one shown below appears.

Epromer Configuration	×
Select Hardware & Port Select Chip	1
Chip plugged in : ST7210161-SDIP32	
ST72101G2-SDIP32 ST72212G2-SDIP32	
ST72213G1-SDIP32 ST72251G1-SDIP32 ST72251G2-SDIP32	
Epromer: ST7MDT1-KIT Port: LPT1 Chip: ST72101G1-SDIP32	
OK Cancel Apply Help	

4 In the list, select the device to be programmed.

Click **OK** to confirm. The list box closes.

The memory mapping of the specified device now appears in the display area of the main window. It is made up of "FFs", as one may expect, since programming has not taken place yet.

#### ST7MDTX-KIT

To view in turn the memory mapping of a selection of devices plugged in, open the configuration window again, then the *Select Chip* list box, and click **Apply**. The display area of the main window changes while the list box stays open, for you to choose another chip if necessary.



5 Start your programming session.

For more information on how to use the Windows Epromer, click the **Help** command in the main menu bar.

Notes:

Information furnished is believed to be accurate and reliable. However, STMicroelectronics assumes no responsibility for the consequences of use of such information nor for any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of STMicroelectronics. Specifications mentioned in this publication are subject to change without notice. This publication supersedes and replaces all information previously supplied. STMicroelectronics products are not authorized for use as critical components in life support devices or systems without the express written approval of STMicroelectronics.

The ST logo is a trademark of STMicroelectronics ©1998 STMicroelectronics - All Rights Reserved.

 $\label{eq:purchase} \begin{array}{l} \mathsf{Purchase} \ \text{of} \ l^2 C \ \mathsf{Components} \ \text{by STMicroelectronics} \ \text{conveys} \ \text{a license} \ \text{under the Philips} \ l^2 C \ \mathsf{Patent}. \ \mathsf{Rights} \ \text{to use these components in an} \\ \ l^2 C \ \mathsf{system} \ \text{is granted provided that the system conforms to the} \ l^2 C \ \mathsf{Standard} \ \mathsf{Specification} \ \text{as defined by Philips}. \end{array}$ 

STMicroelectronics Group of Companies

Australia - Brazil - Canada - China - France - Germany - Italy - Japan - Korea - Malaysia - Malta - Mexico - Morocco - The Netherlands -Singapore - Spain - Sweden - Switzerland - Taiwan - Thailand - United Kingdom - U.S.A.