



Silicon PIN Diode

- High voltage current controlled
RF resistor for RF attenuator and switches
- Frequency range above 1 MHz up to 3 GHz
- Low resistance and long carrier lifetime
- Very low capacitance at zero volts reverse bias at frequencies above 1 GHz
- Very low signal distortion




BAR64-04W




EHA07181

BAR64-05W



EHA07179

BAR64-06W



EHA07187

Type	Marking	Pin Configuration			Package
BAR64-04W	PPs	1 = A1	2 = C2	3 = C1/A2	SOT323
BAR64-05W	PRs	1 = A1	2 = A2	3 = C1/2	SOT323
BAR64-06W	PSs	1 = C1	2 = C2	3 = A1/2	SOT323

Maximum Ratings

Parameter	Symbol	Value	Unit
Diode reverse voltage	V_R	150	V
Forward current	I_F	100	mA
Total power dissipation	P_{tot}	250	mW
$T_S \leq 115^\circ\text{C}$			
Junction temperature	T_j	150	$^\circ\text{C}$
Operating temperature range	T_{op}	-55 ... 150	
Storage temperature	T_{stg}	-55 ... 150	

Thermal Resistance

Parameter	Symbol	Value	Unit
Junction - soldering point ¹⁾	R_{thJS}	≤ 140	K/W


¹For calculation of R_{thJA} please refer to Application Note Thermal Resistance

Electrical Characteristics at $T_A = 25^\circ\text{C}$, unless otherwise specified


Parameter	Symbol	Values			Unit
		min.	typ.	max.	
DC Characteristics					
Breakdown voltage $I_{(BR)} = 5 \mu\text{A}$	$V_{(\text{BR})}$	150	-	-	V
Reverse current $V_R = 20 \text{ V}$	I_R	-	-	50	nA
Forward voltage $I_F = 50 \text{ mA}$	V_F	-	-	1.1	V
AC Characteristics					
Diode capacitance- $V_R = 20 \text{ V}, f = 1 \text{ MHz}$	C_T	-	0.23	0.35	pF
Forward resistance $I_F = 1 \text{ mA}, f = 100 \text{ MHz}$	r_f	-	12.5	20	Ω
$I_F = 10 \text{ mA}, f = 100 \text{ MHz}$		-	2.1	2.8	
$I_F = 100 \text{ mA}, f = 100 \text{ MHz}$		-	0.85	1.35	
Charge carrier life time $I_F = 10 \text{ mA}, I_R = 6 \text{ mA}, I_R = 3 \text{ mA}$	τ_{rr}	-	1.55	-	μs
Series inductance	L_S	-	1.2	-	nH

Diode capacitance $C_T = f (V_R)$

$f = 1\text{MHz}$




Forward current $I_F = f (T_S)$




Forward resistance $r_f = f (I_F)$

$f = 100\text{MHz}$




Forward current $I_F = f (V_F)$

T_A = Parameter




Intermodulation intercept point

$IP_3 = f(I_F)$; f = Parameter



Permissible Pulse Load

$I_{Fmax}/I_{FDC} = f(t_p)$



Permissible Puls Load $R_{thJS} = f(t_p)$

