


**MiniSKiiP® 2 PIM**
**Output Inverter Application**
**1200V / 25A**
**General conditions**
**3phase SPWM**

$V_{GEon}$	=	15 V
$V_{GOff}$	=	-15 V
$R_{gon}$	=	32 Ω
$R_{goff}$	=	32 Ω


**Figure 1**
**IGBT**
**Typical average static loss as a function of output current**

$$P_{loss} = f(I_{out})$$


**At**
 $T_j = 150^\circ C$ 
 $Mi \cdot \cos \phi$  from -1 to 1 in steps of 0,2


**Figure 2**
**FRED**
**Typical average static loss as a function of output current**

$$P_{loss} = f(I_{out})$$


**At**
 $T_j = 150^\circ C$ 
 $Mi \cdot \cos \phi$  from -1 to 1 in steps of 0,2

**Figure 3**
**IGBT**
**Typical average switching loss as a function of output current**

$$P_{loss} = f(I_{out})$$



**At**
 $T_j = 150^\circ C$ 

DC link = 600 V

 $f_{sw}$  from 2 kHz to 16 kHz in steps of factor 2

**Figure 4**
**FRED**
**Typical average switching loss as a function of output current**

$$P_{loss} = f(I_{out})$$


**At**
 $T_j = 150^\circ C$ 


DC link = 600 V

 $f_{sw}$  from 2 kHz to 16 kHz in steps of factor 2

**MiniSKiiP® 2 PIM**
**Output Inverter Application**
**1200V / 25A**
**Figure 5**

Typical available 50Hz output current  
as a function  $M_i \cos \varphi$

$$I_{out} = f(M_i \cos \varphi)$$



**At**

$T_j = 150^\circ\text{C}$   
DC link = 600 V  
 $f_{sw} = 4 \text{ kHz}$   
 $T_h$  from  $60^\circ\text{C}$  to  $100^\circ\text{C}$  in steps of  $5^\circ\text{C}$

**Figure 7**

Typical available 50Hz output current as a function of  
 $M_i \cos \varphi$  and switching frequency

$$I_{out} = f(f_{sw}, M_i \cos \varphi)$$



**At**

$T_j = 150^\circ\text{C}$   
DC link = 600 V  
 $T_h = 80^\circ\text{C}$

**Figure 6**

Typical available 50Hz output current  
as a function of switching frequency

$$I_{out} = f(f_{sw})$$



**At**

$T_j = 150^\circ\text{C}$   
DC link = 600 V  
 $M_i \cos \varphi = 0.8$   
 $T_h$  from  $60^\circ\text{C}$  to  $100^\circ\text{C}$  in steps of  $5^\circ\text{C}$


**Figure 8**

Typical available 0Hz output current as a function  
of switching frequency


$$I_{outpeak} = f(f_{sw})$$


**At**


$T_j = 150^\circ\text{C}$   
DC link = 600 V  
 $T_h$  from  $60^\circ\text{C}$  to  $100^\circ\text{C}$  in steps of  $5^\circ\text{C}$   
 $M_i = 0$

**MiniSKiiP® 2 PIM**
**Output Inverter Application**
**1200V / 25A**
**Figure 9**

**At**

$T_j = 150 \text{ } ^\circ\text{C}$   
 DC link = 600 V  
 $M_i = 1$   
 $\cos \varphi = 0,80$   
 $f_{sw}$  from 2 kHz to 16 kHz in steps of factor 2

**Figure 10**

**At**

$T_j = 150 \text{ } ^\circ\text{C}$   
 DC link = 600 V  
 $M_i = 1$   
 $\cos \varphi = 0,80$   
 $f_{sw}$  from 2 kHz to 16 kHz in steps of factor 2

**Figure 11**

**At**

$T_j = 150 \text{ } ^\circ\text{C}$   
 DC link = 600 V  
 $M_i = 1$   
 $\cos \varphi = 0,8$   
 $f_{sw}$  from 1 kHz to 16 kHz in steps of factor 2  
 $T_h = 80 \text{ } ^\circ\text{C}$   
 Motor eff = 0,85