

General conditions


Vout= 230 VAC

half bridge IGBT	
V_{GEon}	= 15 V
V_{GEoff}	= -15 V
R_{gon}	= 4
R_{goff}	= 4

neutral point IGBT	
V_{GEon}	= 15 V
V_{GEoff}	= -15 V
R_{gon}	= 4
R_{goff}	= 4

Figure 1. half bridge IGBT


Typical average static loss as a function of output current I_{oRMS}



Conditions: $T_j = 150$ °C
parameter: ϕ from 0° to 180°
in 12 steps

Figure 2. neutral point FWD


Typical average static loss as a function of output current I_{oRMS}



Conditions: $T_j = 125$ °C
parameter: ϕ from 0° to 180°
in 12 steps

Figure 3. half bridge IGBT


Typical average static loss as a function of phase displacement ϕ



Conditions: $T_j = 150$ °C
parameter: I_{oRMS} from 6,67 A to 100 A
in steps of 13 A

Figure 4. neutral point FWD

Typical average static loss as a function of phase displacement ϕ




Conditions: $T_j = 125$ °C
parameter: I_{oRMS} from 6,67 A to 100 A
in steps of 13 A

flowMNPC 1 mixed voltage NPC Application 1200V/160A

Figure 5. half bridge IGBT

Typical average switching loss as a function of phase displacement ϕ

$P_{loss}=f(\phi)$




Conditions: $T_j= 150 \text{ }^\circ\text{C}$
 $f_{sw}= 16 \text{ kHz}$
DC link= 700 V
parameter: I_{oRMS} from 6,67 A to 100 A
in steps of 13 A

Figure 6. neutral point FWD

Typical average switching loss as a function of phase displacement ϕ

$P_{loss}=f(\phi)$




Conditions: $T_j= 125 \text{ }^\circ\text{C}$
 $f_{sw}= 16 \text{ kHz}$
DC link= 700 V
parameter: I_{oRMS} from 6,67 A to 100 A
in steps of 13 A

Figure 7. half bridge IGBT

Typical total loss as a function of phase displacement ϕ and output current I_{oRMS}

$P_{loss}=f(I_{oRMS};\phi)$




Conditions: $T_j= 150 \text{ }^\circ\text{C}$
DC link= 700 V
 $f_{sw}= 16 \text{ kHz}$

Figure 8. neutral point FWD

Typical total loss as a function of phase displacement ϕ and output current I_{oRMS}

$P_{loss}=f(I_{oRMS};\phi)$




Conditions: $T_j= 125 \text{ }^\circ\text{C}$
DC link= 700 V
 $f_{sw}= 16 \text{ kHz}$

flowMNPC 1 mixed voltage NPC Application 1200V/160A

Figure 9. for half bridge IGBT + neutral point FWD

Typical available output current as a function of phase displacement φ

$I_{out}=f(\varphi)$




Conditions: $T_j = 150/125 \text{ }^\circ\text{C}$ $f_{sw} = 16 \text{ kHz}$
 DC link = 700 V
 parameter: Heatsink temp.
 T_h from 50 $^\circ\text{C}$ to 100 $^\circ\text{C}$
 in 10 $^\circ\text{C}$ steps

Figure 10. for half bridge IGBT + neutral point FWD

Typical available output current as a function of switching frequency f_{sw}

$I_{out}=f(f_{sw})$




Conditions: $T_j = 150/125 \text{ }^\circ\text{C}$ $\varphi = 0^\circ$
 DC link = 700 V
 parameter: Heatsink temp.
 T_h from 50 $^\circ\text{C}$ to 100 $^\circ\text{C}$
 in 10 $^\circ\text{C}$ steps

Figure 11. for half bridge IGBT + neutral point FWD

Typical available 50Hz output current as a function of f_{sw} and phase displacement φ

$I_{out}=f(f_{sw},\varphi)$



Conditions: $T_j = 150/125 \text{ }^\circ\text{C}$
 DC link = 700 V
 $T_h = 80 \text{ }^\circ\text{C}$

Figure 12. neutral point IGBT
Typical average static loss as a function of output current

$$P_{\text{loss}}=f(I_{\text{out}})$$



 Conditions: $T_j = 150$ °C
 parameter: φ from 0° to 180°
 in 12 steps

Figure 13. half bridge FWD
Typical average static loss as a function of output current

$$P_{\text{loss}}=f(I_{\text{out}})$$



 Conditions: $T_j = 125$ °C
 parameter: φ from 0° to 180°
 in 12 steps

Figure 14. neutral point IGBT
Typical average static loss as a function of phase displacement

$$P_{\text{loss}}=f(\varphi)$$




 Conditions: $T_j = 150$ °C
 parameter: I_{ORMS} from 7 A to 100 A
 in steps of 13 A

Figure 15. half bridge FWD
Typical average static loss as a function of phase displacement

$$P_{\text{loss}}=f(\varphi)$$



 Conditions: $T_j = 125$ °C
 parameter: I_{ORMS} from 7 A to 100 A
 in steps of 13 A

flowMNPC 1 mixed voltage NPC Application 1200V/160A

Figure 16. neutral point IGBT

Typical average switching loss as a function of phase displacement

$$P_{loss} = f(\varphi)$$




Conditions: $T_j = 150$ °C $f_{sw} = 16$ kHz
DC link = 700 V
parameter: I_{oRMS} from 7 A to 100 A
in steps of 13 A A

Figure 17. half bridge FWD

Typical average switching loss as a function of phase displacement

$$P_{loss} = f(\varphi)$$




Conditions: $T_j = 125$ °C $f_{sw} = 16$ kHz
DC link = 700 V
parameter: I_{oRMS} from 7 A to 100 A
in steps of 13 A A

Figure 18. neutral point IGBT

Typical total loss as a function of phase displacement and I_{outRMS}

$$P_{loss} = f(I_{oRMS}; \varphi)$$




Conditions: $T_j = 150$ °C
DC link = 700 V
 $f_{sw} = 16$ kHz

Figure 19. half bridge FWD

Typical total loss as a function of phase displacement and I_{outRMS}

$$P_{loss} = f(I_{oRMS}; \varphi)$$




Conditions: $T_j = 125$ °C
DC link = 700 V
 $f_{sw} = 16$ kHz

Figure 20. for neutral point IGBT + half bridge FWD

Typical available output current as a function of phase displacement

$$I_{out}=f(\varphi)$$




Conditions: $T_j = 150/125 \text{ } ^\circ\text{C}$ $f_{sw} = 16 \text{ kHz}$
 DC link = 700 V

parameter: Heatsink temp.
 T_h from 50 $^\circ\text{C}$ to 100 $^\circ\text{C}$
 in 10 $^\circ\text{C}$ steps

Figure 21. for neutral point IGBT + half bridge FWD

Typical available output current as a function of switching frequency

$$I_{out}=f(f_{sw})$$




Conditions: $T_j = 150/125 \text{ } ^\circ\text{C}$ $\varphi = 90^\circ$
 DC link = 700 V

parameter: Heatsink temp.
 T_h from 50 $^\circ\text{C}$ to 100 $^\circ\text{C}$
 in 10 $^\circ\text{C}$ steps

Figure 22. for neutral point IGBT + half bridge FWD

Typical available 50Hz output current as a function of fsw and phase displacement

$$I_{out}=f(f_{sw},\varphi)$$




Conditions: $T_j = 150/125 \text{ } ^\circ\text{C}$
 DC link = 700 V
 $T_h = 80 \text{ } ^\circ\text{C}$

flowMNPC 1 mixed voltage NPC Application 1200V/160A

Figure 23. per PHASE

Typical available output current as a function of heat sink temperature

$I_{out}=f(T_h)$




Conditions: $T_j = 150/125 \text{ } ^\circ\text{C}$
 DC link = 700 V
 $\phi = 0^\circ$
 parameter: Switching freq.
 fsw from 2 kHz to 128 kHz
 in steps of factor 2

Figure 24. per PHASE

Typical available output current as a function of phase displacement

$I_{out}=f(\phi)$




Conditions: $T_j = 150/125 \text{ } ^\circ\text{C}$
 DC link = 700 V
 $f_{sw} = 16 \text{ kHz}$
 parameter: Heatsink temp.
 Th from 50 °C to 100 °C
 in 10 °C steps

Figure 25. per PHASE

Typical available output current as a function of switching frequency

$I_{out}=f(f_{sw})$




Conditions: $T_j = 150/125 \text{ } ^\circ\text{C}$ $\phi = 0^\circ$
 DC link = 700 V
 parameter: Heatsink temp.
 Th from 50 °C to 100 °C
 in 10 °C steps

Figure 26. per PHASE

Typical available 50Hz output current as a function of fsw and phase displacement

$I_{out}=f(f_{sw},\phi)$




Conditions: $T_j = 150/125 \text{ } ^\circ\text{C}$
 DC link = 700 V
 $T_h = 80 \text{ } ^\circ\text{C}$

flowMNPC 1 mixed voltage NPC Application 1200V/160A

Figure 27. per PHASE

Typical efficiency as a function of output power

$\eta=f(P_{out})$




Conditions: $T_j = 150/125 \text{ } ^\circ\text{C}$
 $f_{sw} = 16 \text{ kHz}$
 DC link = 700 V
 parameter: phase displacement
 φ from 0° to 180°
 in steps of 30°

Figure 28. per PHASE

Typical efficiency as a function of output power

$\eta=f(P_{out})$




Conditions: $T_j = 150/125 \text{ } ^\circ\text{C}$ $\varphi = 0^\circ$
 DC link = 700 V
 parameter: Switching freq.
 fsw from 2 kHz to 128 kHz
 in steps of factor 2

Figure 29. per PHASE

Typical available output power as a function of heat sink temperature

$P_{out}=f(T_h)$




Conditions: $T_j = 150/125 \text{ } ^\circ\text{C}$
 DC link = 700 V
 $\varphi = 0^\circ$
 parameter: Switching freq.
 fsw from 2 kHz to 128 kHz
 in steps of factor 2

Figure 30. per PHASE

Typical loss distribution as a function of output current

$P_{out}=f(I_{out})$




Conditions: $T_j = 150/125 \text{ } ^\circ\text{C}$
 $f_{sw} = 16 \text{ kHz}$
 DC link = 700 V
 $\varphi = 0^\circ$

Figure 31. per PHASE

Typical relative loss distribution as a function of output current

$$P_{out} = f(T_h)$$



Conditions:

 $T_j = 150/125$ °C
 $f_{sw} = 16$ kHz
 DC link = 700 V
 $\varphi = 0^\circ$
Figure 32. Schematic
