
Description	Material	Finish	
Body	Brass	Nickel	
Socket	BE CU	Gold	
Insulation	Teflon	Teflon	
Washer	PH Bronze	Nickel	
Gasket	SI Rubber	Rubber	
Crimp Ring	Brass	Nickel	
Insulator	Teflon	Teflon	
Cover	Brass	Nickel	
Heat Shrink	Polyolefin	Black	


COVER

**INSULATOR** 


	REVISIONS		
REV	DESCRIPTION	DATE	APPV
В	Add Heat Shrink to Drawing	28-Jul-09	CJ

## SIDE VIEW





## **HEAT SHRINK**




## **Assembly Instructions**

- 1. Strip coax as shown. Put heat shrink, then crimp ring onto cable.
- 2. Slide the coax into the body until the center conductor is centered in the fork.
- 3. Push the shield over the barrel.
- 4. Solder the center conductor into center of the fork.
- 5. Slide the crimp ring over the shield and crimp with a 0.128" crimp die.
- 6. Trim off any excess shield wire sticking out from the ring.
- 7. Slip the heat shrink tube over the crimp ring until it is against the body and then heat shrink.
- 8. Slip insulator into body.
- 9. Push cover into the opening.

## NOTES: (UNLESS OTHERWISE SPECIFIED)

- 1. ALL DIMENSIONS ARE IN INCHES [mm].
- 2. DIMENSIONS APPLY AFTER FINISHING.
- 3. MANUFACTURE TO BE COMPLIANT WITH EU ROHS DIRECTIVE.
- 4. SAFETY BREAK ALL SHARP CORNERS AND EDGES .02 MAXIMUM.



WARNING: THIS DRAWING CONTAINS PROPRIETARY INFORMATION THAT IS THE SOLE PROPERTY OF CONNECTOR CITY, AND SHALL BE TREATED AS SUCH. NO DISCLOSURE OR REPRODUCTION OF THIS DOCUMENT IS PERMITTED. IN WHOLE OR IN PART, WITHOUT THE EXPRESS WRITTEN PERMISSION OF CONNECTOR CITY OR ITS DESIGNATED AGENTS.

MATERIAL: TOLERANCES: PROJECTION: .020 [0.50]-.200 [5.00] = ±.008 [0.20] .200 [5.00]-1.200 [30.00]= ±.016 [0.40] 4.75 [120.0]-12.40 [315.0]=±.024 [0.60] ANGLES: ±1° SIZE ANGLES: ±1° ANGLES: ±

DRAWN:  $C^{1}$ DT: 7/28/09 ENGR: DT:

FINISH:

159 ORT LANE MERLIN, OR 97532

RP-SMA MALE RIGHT ANGLE CABLE END CRIMP FOR RG174 CABLE

DO NOT SCALE DRAWING

SCALE: 2:1

CONREVSMA012

REV В SHEET 1 OF 1