General purpose small signal amplifier (50V, 0.15A)

2SC4081UB

Applications

ROHM

General purpose small signal amplifier


Features

 Low Cob. Cob=2.0pF (Typ.)
Complements the 2SA4081.

Structure

NPN silicon epitaxial planar transistor

•Dimensions (Unit : mm)



Data Sheet

•Absolute maximum (Ta=25°C)

| Parameter | Symbol | Limits | Unit |
|------------------------------|--------|-------------|------|
| Collector-base voltage | Vсво | 60 | V |
| Collector-emitter voltage | Vceo | 50 | V |
| Emitter-base voltage | Vebo | 7 | V |
| Collector current | lc | 150 | mA |
| Collector current | ICP *1 | 200 | mA |
| Power dissipation | PD *2 | 200 | mW |
| Junction temperature | Tj | 150 | ٥C |
| Range of storage temperature | Tstg | -55 to +150 | °C |

*1 Pw=1ms Single pulse

*2 Each terminal mounted on a recommended land


•Electrical characteristics (Ta=25°C)


| Parameter | Symbol | Min. | Тур. | Max. | Unit | Conditions |
|--------------------------------------|----------|------|------|------|------|----------------------------|
| Collector-emitter breakdown voltage | BVCEO | 50 | - | - | V | Ic=1mA |
| Collector-base breakdown voltage | ВУсво | 60 | - | - | V | Ic=50μA |
| Emitter-base breakdown voltage | BVebo | 7 | - | - | V | Iε=50μA |
| Collector cutoff current | Ісво | _ | - | 100 | nA | Vcb=60V |
| Emitter cutoff current | Іево | - | - | 100 | nA | VEB=7V |
| Collector-emitter saturation voltage | VCE(sat) | - | - | 400 | mV | Ic/IB=50mA/5mA |
| DC current gain | hfe | 120 | - | 390 | - | Vce=6V, Ic=1mA |
| Transition frequency | fт | _ | 180 | _ | MHz | Vce=12V, Ie=-2mA, f=100MHz |
| Output capacitance | Cob | _ | 2.0 | 3.5 | pF | Vсв=12V, Ie=0A, f=1MHz |


h_{FE} rank categories


| Rank | Q | R |
|------|------------|------------|
| hfe | 120 to 270 | 180 to 390 |

2SC4081UB













Fig.9 Gain bandwidth product vs. emitter current






Fig.11 Base-collector time constant vs. emitter current

| | Notes |
|--|---|
| | ng or reproduction of this document, in part or in whole, is permitted without the f ROHM Co.,Ltd. |
| The conte | nt specified herein is subject to change for improvement without notice. |
| "Products | nt specified herein is for the purpose of introducing ROHM's products (hereinafte "). If you wish to use any such Product, please be sure to refer to the specifications be obtained from ROHM upon request. |
| illustrate t | of application circuits, circuit constants and any other information contained herein he standard usage and operations of the Products. The peripheral conditions mus nto account when designing circuits for mass production. |
| However, | e was taken in ensuring the accuracy of the information specified in this document should you incur any damage arising from any inaccuracy or misprint of sucl n, ROHM shall bear no responsibility for such damage. |
| examples implicitly, other part | ical information specified herein is intended only to show the typical functions of and of application circuits for the Products. ROHM does not grant you, explicitly o any license to use or exercise intellectual property or other rights held by ROHM and ies. ROHM shall bear no responsibility whatsoever for any dispute arising from the h technical information. |
| equipmen | icts specified in this document are intended to be used with general-use electronic t or devices (such as audio visual equipment, office-automation equipment, commu evices, electronic appliances and amusement devices). |
| The Produ | cts specified in this document are not designed to be radiation tolerant. |
| | HM always makes efforts to enhance the quality and reliability of its Products, a ay fail or malfunction for a variety of reasons. |
| against th failure of a shall bear | sure to implement in your equipment using the Products safety measures to guard e possibility of physical injury, fire or any other damage caused in the event of the any Product, such as derating, redundancy, fire control and fail-safe designs. ROHM no responsibility whatsoever for your use of any Product outside of the prescribed not in accordance with the instruction manual. |
| system wi may result instrument fuel-contro any of the | acts are not designed or manufactured to be used with any equipment, device on hich requires an extremely high level of reliability the failure or malfunction of which t in a direct threat to human life or create a risk of human injury (such as a medica t, transportation equipment, aerospace machinery, nuclear-reactor controller oller or other safety device). ROHM shall bear no responsibility in any way for use o Products for the above special purposes. If a Product is intended to be used for an ial purpose, please contact a ROHM sales representative before purchasing. |
| be control | nd to export or ship overseas any Product or technology specified herein that may led under the Foreign Exchange and the Foreign Trade Law, you will be required to cense or permit under the Law. |



Thank you for your accessing to ROHM product informations. More detail product informations and catalogs are available, please contact us.

ROHM Customer Support System

http://www.rohm.com/contact/